

---

# **ARES-1500-A10**

# **ARES-1500-B10**

**Robust Box Computers with AMD G-T40N  
Platform**

## **User's Manual**

### **Version 1.0**



---

This page is intentionally left blank.

---

---

## Revision History

Version	Date	Description
1.0	Dec 2013	Initial release for ARES-1500-A10 & ARES-1500-B10

<b>Revision History .....</b>	<b>i</b>
<b>Preface.....</b>	<b>v</b>
Copyright Notice .....	v
Declaration of Conformity .....	v
CE .....	v
FCC Class A.....	v
RoHS .....	vi
SVHC / REACH .....	vi
Important Safety Instructions.....	vii
Warning .....	viii
Replacing Lithium Battery.....	viii
Technical Support .....	viii
Warranty .....	ix
<b>Chapter 1 - Introduction.....</b>	<b>1</b>
1.1. Product Highlights .....	2
1.2. About this Manual .....	2
1.3. Specifications .....	3
1.4. Inside the Package .....	4
1.5. Ordering Information.....	5
1.5.1. Optional Accessories .....	5
1.5.2. Configure-to-Order Service.....	5
<b>Chapter 2 - Getting Started.....</b>	<b>7</b>
2.1. Dimensions .....	8
2.2. Take A Tour .....	9
2.3. Driver Installation Notes .....	11
<b>Chapter 3 - System Configuration .....</b>	<b>13</b>
3.1. Board Layout .....	14
3.1.1. Mother Board: FMB-a50M3 .....	14
3.1.2. Daughter Board: SCDB-1277 .....	16
3.2. Jumpers and Connectors .....	17
3.2.1. Mother Board Jumpers .....	17
3.2.2. Mother Board Connectors.....	21
3.2.3. Daughter Board Connectors (ARES-1500-B10 only).....	39
<b>Chapter 4 - Installation and Maintenance.....</b>	<b>43</b>
4.1. Install Hardware.....	44
4.1.1. Open the Computer .....	44
4.1.2. Install Memory Module.....	48
4.1.3. Install mSATA Storage .....	51
4.1.4. Install SIM Card .....	53
4.1.5. Install Wireless Modules .....	55

---

4.2. Mount the Computer .....	56
4.2.1. VESA-Mount .....	56
4.2.2. Wall-Mount .....	57
4.3. Wire DC-Input Power Source .....	58
<b>Chapter 5 - BIOS .....</b>	<b>59</b>
5.1. Main .....	62
5.2. Advanced .....	64
5.2.1. ACPI Settings .....	66
5.2.2. CPU Configuration .....	67
5.2.3. IDE Configuration .....	68
5.2.4. USB Configuration .....	68
5.2.5. Super IO Configuration .....	69
5.2.6. H/W Monitor .....	72
5.3. Chipset .....	73
5.3.1. North Bridge Configuration .....	74
5.3.2. South Bridge Configuration .....	75
5.4. Boot .....	76
5.5. Security .....	78
5.6. Save & Exit .....	79
<b>Appendices .....</b>	<b>81</b>
Appendix A: Watchdog Timer (WDT) Setting .....	82
Appendix B: 3G Module HSPA-SI1400 Hardware/Software Installation .....	83
B.1. Install HSPA-SI1400 .....	83
B.2. Install Device Driver .....	89
B.3. Install Application Program .....	91
Appendix C: Wi-Fi Module WIFI-IN1300 Hardware/Software Installation .....	94
C.1. Install WIFI-IN1300 .....	94
C.2. Install Device Driver & Application Program .....	101

---

This page is intentionally left blank.

## Copyright Notice

All Rights Reserved.

The information in this document is subject to change without prior notice in order to improve the reliability, design and function. It does not represent a commitment on the part of the manufacturer.

Under no circumstances will the manufacturer be liable for any direct, indirect, special, incidental, or consequential damages arising from the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

## Declaration of Conformity

### CE

The CE symbol on the computer indicates that it is in compliance with the directives of the Union European (EU). A Certificate of Compliance is available by contacting Technical Support.

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from ARBOR. Please contact your local supplier for ordering information.

### Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

## FCC Class A

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## Preface

---

### NOTE:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### RoHS

ARBOR Technology Corp. certifies that all components in its products are in compliance and conform to the European Union's Restriction of Use of Hazardous Substances in Electrical and Electronic Equipment (RoHS) Directive 2002/95/EC.

The above mentioned directive was published on 2/13/2003. The main purpose of the directive is to prohibit the use of lead, mercury, cadmium, hexavalent chromium, polybrominated biphenyls (PBB), and polybrominated diphenyl ethers (PBDE) in electrical and electronic products. Member states of the EU are to enforce by 7/1/2006.

ARBOR Technology Corp. hereby states that the listed products do not contain unintentional additions of lead, mercury, hex chrome, PBB or PBDB that exceed a maximum concentration value of 0.1% by weight or for cadmium exceed 0.01% by weight, per homogenous material. Homogenous material is defined as a substance or mixture of substances with uniform composition (such as solders, resins, plating, etc.). Lead-free solder is used for all terminations (Sn(96-96.5%), Ag(3.0-3.5%) and Cu(0.5%)).

### SVHC / REACH

To minimize the environmental impact and take more responsibility to the earth we live, Arbor hereby confirms all products comply with the restriction of SVHC (Substances of Very High Concern) in (EC) 1907/2006 (REACH --Registration, Evaluation, Authorization, and Restriction of Chemicals) regulated by the European Union.

All substances listed in SVHC < 0.1 % by weight (1000 ppm)



## Important Safety Instructions

Read these safety instructions carefully

1. Read all cautions and warnings on the equipment.
2. Place this equipment on a reliable surface when installing. Dropping it or letting it fall may cause damage
3. Make sure the correct voltage is connected to the equipment.
4. For pluggable equipment, the socket outlet should be near the equipment and should be easily accessible.
5. Keep this equipment away from humidity.
6. The openings on the enclosure are for air convection and protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
7. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
8. Never pour any liquid into opening. This may cause fire or electrical shock.
9. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
10. If one of the following situations arises, get the equipment checked by service personnel:
  - a. The power cord or plug is damaged.
  - b. Liquid has penetrated into the equipment.
  - c. The equipment has been exposed to moisture.
  - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
  - e. The equipment has been dropped or damaged.
  - f. The equipment has obvious signs of breakage.
11. Keep this User's Manual for later reference.

## Product Heat



The computer generates heat during operation. Contact the computer's chassis with your body could cause discomfort or even a skin burn.

### **Warning**

The Box PC and its components contain very delicately Integrated Circuits (IC). To protect the Box PC and its components against damage caused by static electricity, you should always follow the precautions below when handling it:

1. Disconnect your Box PC from the power source when you want to work on the inside.
2. Use a grounded wrist strap when handling computer components.
3. Place components on a grounded antistatic pad or on the bag that came with the Box PC, whenever components are separated from the system.

### **Replacing Lithium Battery**

Incorrect replacement of the lithium battery may lead to a risk of explosion.

The lithium battery must be replaced with an identical battery or a battery type recommended by the manufacturer.

Do not throw lithium batteries into the trash can. It must be disposed of in accordance with local regulations concerning special waste.

### **Technical Support**

If you have any technical difficulties, please consult the user's manual first at: <ftp://ftp.arbor.com.tw/pub/manual>

Please do not hesitate to call or e-mail our customer service when you still cannot find out the answer.

<http://www.arbor.com.tw>

E-mail: [info@arbor.com.tw](mailto:info@arbor.com.tw)

## **Warranty**

This product is warranted to be in good working order for a period of one year from the date of purchase. Should this product fail to be in good working order at any time during this period, we will, at our option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster.

Vendor assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, or inability to use this product. Vendor will not be liable for any claim made by any other related party.

Vendors disclaim all other warranties, either expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose, with respect to the hardware, the accompanying product's manual(s) and written materials, and any accompanying hardware. This limited warranty gives you specific legal rights.

Return authorization must be obtained from the vendor before returned merchandise will be accepted. Authorization can be obtained by calling or faxing the vendor and requesting a Return Merchandise Authorization (RMA) number. Returned goods should always be accompanied by a clear problem description.

---

This page is intentionally left blank.

---

# Chapter 1

## Introduction

### 1.1. Product Highlights

- Fanless Design
- Ultra Low Profile Enclosure
- AMD G-T40N Dual-Core 1.0 GHz Processor
- Rich I/O (4 x USB ports, 4 x serial ports, 2 x GbE LAN ports, 1 x DVI-I connector)
- Aluminum Chassis for Harsh Environment
- Optional WiFi or 3G networking
- Slim, Compact & Cable-free Design



### 1.2. About this Manual

This manual is meant for the experienced users and integrators with hardware knowledge of personal computers. If you are not sure about the description herein, consult your vendor before further handling.

We recommend that you keep one copy of this manual for the quick reference for any necessary maintenance in the future. Thank you for choosing ARBOR products.

### 1.3. Specifications

<b>System Kernel</b>	
<b>Processor</b>	Soldered onboard AMD G-T40N Dual Core 1.0GHz processor
<b>BIOS</b>	AMI BIOS
<b>Chipset</b>	AMD A50M
<b>Graphics</b>	Graphics Integrated AMD G-Series
<b>System Memory</b>	1 x 204-pin DDR3 SO-DIMM socket, supporting 800/1066 MHz SDRAM, up to 4GB
<b>Serial ATA</b>	1 x serial ATA port for mSATA
<b>Ethernet Controller</b>	2 x Realtek 8111E Gigabit Ethernet controllers
<b>Watchdog Timer</b>	1 ~ 255 levels reset
<b>I/O Ports</b>	
<b>Serial Port</b>	4 x RS-232 serial ports (RS-232/422/485 selectable for COM1)
<b>USB Port</b>	4 x USB 2.0 ports
<b>LAN Port</b>	2 x RJ-45 ports for Gigabit Ethernet
<b>Video Port</b>	1 x DVI-I female connector for digital video output
<b>Audio</b>	Mic-in/Line-out
<b>Expansion Bus</b>	1 x MiniCard socket interconnected with SIM card socket for optional WiFi or HSUPA module 1 x SIM card socket
<b>Storage</b>	
Type	1 x mSATA
<b>Qualification</b>	
<b>Certification</b>	CE, FCC Class A
<b>Environment</b>	
<b>Operating Temp.</b>	-25 ~ 55°C (-3 ~ 131°F), ambience w/ air flow
<b>Storage Temp.</b>	-40 ~ 80°C (-40 ~ 176°F)
<b>Relative Humidity</b>	10 ~ 95% @ 40°C (non-condensing)
<b>Vibration</b>	3 Grms/5 ~ 500Hz/random operation
<b>Shock</b>	Operating 20G (11ms); Non-operating 60G with HDD Operating 40G (11ms); Non-operating 80G with SSD

## Introduction

---

Mechanical	
<b>Construction</b>	Aluminum alloy
<b>Mounting</b>	VESA-mount / wall-mount
<b>Weight</b>	0.93 kg (2.05 lb) 1.1 kg (2.42 lb)
<b>Dimensions (W x D x H)</b>	System = 188 x 149.5 x 30 mm (7.4" x 5.88" x 1.18") Packing = 304 x 294 x 355 mm (11.97" x 11.57" x 13.98")
Power Requirement	
<b>Power Input</b>	DC12V input by 2.5mm power jack for A10 DC 9-36V by 3-pin terminal block for B10
<b>Power Consumption</b>	Max. 14W (12V/1.14A)

### 1.4. Inside the Package

Upon opening the package, carefully inspect the contents. If any of the items is missing or appears damaged, contact your local dealer or distributor. The package should contain the following items:





## 1.5. Ordering Information

<b>ARES-1500-A10-16S2G</b>	Box PC w/ 16GB SSD and 2GB memory
<b>ARES-1500-A10</b>	Barebone system w/o storage device and memory
<b>ARES-1500-B10-16S2G</b>	Box PC w/ 16GB SSD and 2GB memory
<b>ARES-1500-B10</b>	Barebone system w/o storage device and memory

### 1.5.1. Optional Accessories

The following items are normally optional, but some vendors may include them as a standard package, or some vendors may not carry all the items.

<b>ARES-1500-A10</b>	<b>PAC-P060W-01</b>	12V/5A 60W AC/DC adapter kit	
	<b>VMK-1000</b>	VESA mount kit	
<b>ARES-1500-B10</b>	<b>PAC-P065W</b>	19V/3.4A 65W AC/DC adapter kit	
	<b>VMK-1000</b>	VESA mount kit	



### 1.5.2. Configure-to-Order Service

Make the computer more tailored to your needs by selecting one or more components from the list below to be fabricated to the computer.

<b>4GB SO-DIMM</b>	DDR3-1333 4GB SDRAM	
<b>2GB SO-DIMM</b>	DDR3-1333 2GB SDRAM	

## Introduction

---

<b>WIFI-IN1130</b>	Intel® Centrino® Advanced-N 6205 WiFi module w/ 10cm & 20cm internal wiring	
<b>ANT-H11</b>	1 x 2dBi HSUPA antenna	
<b>ANT-D11</b>	1 x WiFi Dual-band 2.4G/5G antenna	
<b>HSPA-SI1400</b>	HSUPA 3.75G module kit & internal wiring	
<b>SSD</b>	mSATA MLC 16GB	
	mSATA MLC 32GB	


---

# Chapter 2

## Getting Started

## 2.1. Dimensions

The following illustration shows the dimensions of ARES-1500-A10, with the measurements in width, depth, and height called out.




Unit: mm

## 2.2. Take A Tour


The computer has some I/O ports, status LED light and controls on the front and rear panels. The following illustrations show all the components called out for ARES-1500-A10..

### Front View

#### ARES-1500-A10



#### ARES-1500-B10



- **Power button** 


Press-and-hold the power button to power on the computer. The power button features a dual-color LED to signify the following conditions:

## Getting Started

---

LED Color	Description
Red	External power is connected.
Green	The computer is powered on.

### Rear View



### Side View

#### ARES-1500-A10



#### ARES-1500-B10



---

## 2.3. Driver Installation Notes

The ARES-1500-A10 supports the operating systems of Windows XP and Windows 7. For these operating systems, find the necessary device drivers on the CD that comes with your purchase. For different operating systems, the installation of drivers/utilities may vary slightly, but generally they are similar. **DO** follow the sequence below to install the drivers to prevent errors:

**Chipset**→**.NET Framework**→**Audio**→**LAN**

Paths to find various drivers on the CD:

### Windows XP

Device	Driver Path
Chipset	Chipset\setup
LAN	LAN\PCIE_Install_5810_01222013\setup
Audio	Audio\Windows 2000,XP,2003(32,64 bits)\WDM_R270
.NET Framework	Net framework 4.0\dotNetFx40_Full_x86_x64

### Windows 7

Device	Driver Path
Chipset	Chipset\setup
LAN	LAN\Install_Win7_7067_01222013\setup
Audio	Audio\Windows Vista,7,8(32,64bits)\Vista_Win7_Win8_R270
.NET Framework	Net framework 4.0\dotNetFx40_Full_x86_x64

---

This page is intentionally left blank.



---

# Chapter 3

## System Configuration


# System Configuration

## 3.1. Board Layout


The main board FMB-a50M3 solely forms the engine of the ARES-1500-A10 while the ARES-1500-B10 relies on both the said main board and the daughter (power) board SCDB-1277 for its engine. This section will provide an thorough view of these boards.

### 3.1.1. Mother Board: FMB-a50M3

#### Board Top




Board Bottom




### 3.1.2. Daughter Board: SCDB-1277

#### Board Top



#### Board Bottom



### 3.2. Jumpers and Connectors

The mother board FMB-a50M3 comes with some connectors to join some devices and jumpers to alter hardware configuration. The daughter (power) board SCDB-1277 also comes with some connectors. The following in this chapter will explicate each of these components one-by-one.

#### 3.2.1. Mother Board Jumpers



This section will guide you through the jumpers on the mother board FMB-a50M3.

##### J1


**Function:** CMOS Setting

**Jumper Type:** Onboard 2.54mm pitch 1x3-pin header

**Setting:**

Pin	Function	Setting
1-2	Clears CMOS	
2-3	Keeps CMOS (Default)	

##### Board Top



## System Configuration



---

### JV1

**Function:** Controls power supply mode


**Jumper Type:** Onboard 2.54mm pitch 1x3-pin header

**Setting:**

Pin	Description	Setting
1-2	Sets the power supply to ATX mode (default)	
2-3	Sets the power supply to AT mode	



- ▶ Note this setting should be consistent with **BIOS | Advanced | ACPI Settings | AC Power Shutdown mode** to prevent conflict. See [5.2.1. ACPI Settings](#) on page [66](#).

### Board Top



**JV2 & JV3**

**Function:** COM1 RS232/RS422/RS485 setting  
**Jumper Type:** Onboard 2.54mm pitch 1x3-pin header



• **COM1 Settings**

Serial Port	Protocol	Jumpers	Pin	Setting
COM1	loop-back	JV2	1 & 2	JV2
		JV3	1 & 2	JV3
	RS232	JV2	2 & 3	JV2
		JV3	1 & 2	JV3
	RS422	JV2	2 & 3	JV2
		JV3	2 & 3	JV3
	RS485	JV2	1 & 2	JV2
		JV3	2 & 3	JV3

## System Configuration


---

### JV4


**Function:** Reserved

**Jumper Type:** Onboard 2.54mm pitch 1x3-pin header

**Rear Panel**



**Board Top**






### 3.2.2. Mother Board Connectors

This section will guide you through the connectors on the mother board FMB-a50M3.

#### LPC1


**Function:** Board debugging (for factory use only)

**Jumper Type:** Onboard 2.00mm pitch 2x5-pin header



Pin	Description	Pin	Description
1	PCLK_FWH	6	NC
2	GND	7	LAD3
3	LFRAME#	8	LAD2
4	LAD0	9	3V3S
5	BUF_PLTRST_N	10	LAD1


#### Board Top



## System Configuration

### COM1


**Function:** Serial port 1, configurable for RS232/RS422/RS485. See [JV2](#) & [JV3](#) for the configuration.




**Connector Type:** 9-pin male DB connector

Pin	Description	Pin	Description
1	DCD	6	DSR
2	RXD	7	RTS
3	TXD	8	CTS
4	DTR	9	RI
5	GND		

Rear Panel




Board Top



### COM2, COM3 and COM4


**Function:** Serial ports 2/3/4, all are RS232-interfaced.

**Connector Type:** 9-pin male DB connector




Pin	Description	Pin	Description
1	DCD	6	DSR
2	RXD	7	RTS
3	TXD	8	CTS
4	DTR	9	RI
5	GND		

Rear Panel



Board Top




# System Configuration


## USB3 & USB4

**Destription:** Connectors for the internal USB ports  
**Connector Type:** Pitch 2.00mm 5-pin wafer connectors

USB3		USB4	
Pin	Desc.	Pin	Desc.
1	5V	1	5V
2	USBP_12N_CON	2	USBP_13N_CON
3	USBP_12P_CON	3	USBP_13P_CON
4	GND	4	GND
5	GND	5	GND




### Board Top




MC1

**Description:** PCI Express Mini-card socket  
**Connector Type:** Onboard 0.8mm pitch 52-pin edge card connector interconnected with SIM card socket



Pin	Desc.	Pin	Desc.	Pin	Desc.
1	Wake	20	W_Disable#	36	USB D-
2	+3.3V	21	GND	37	GND
3	COEX1	22	PERST#	38	USB D+
4	GND	23	PERn0	39	+3.3V
5	COEX2	24	+3.3V	40	GND
6	+1.5V	25	PERp0	41	+3.3V
7	CLKREQ#	26	GND	42	LED WWAN#
8	UIM_PWR	27	GND	43	GND
9	GND	28	+1.5V	44	LED WLAN#
10	UIM_DATA	29	GND	45	Reserved
11	REFCLK-	30	SMB_CLK	46	LED WPAN#
12	UIM_CLK	31	PETn0	47	Reserved
13	REFCLK+	32	SMB_DATA	48	+1.5V
14	UIM_RESET	33	PETp0	49	Reserved
15	GND	34	GND	50	GND
16	UIM_VPP	35	GND	51	Reserved
17	UIM_C8/Reserved			52	+3.3V
18	GND				
19	UIM_C4/Reserved				

Board Top



## System Configuration


---

### SIM1


**Destription:** SIM card socket

**Connector Type:** 6-pin SIM card socket with a hinged cover

Pin	Description
C1	VCC
C2	RST
C3	CLK
C5	GND
C6	VPP
C7	I/O




### Board Top




MC3

**Description:** PCI Express Mini-card socket  
**Connector Type:** Onboard 0.8mm pitch 52-pin edge card connector



Pin	Desc.	Pin	Desc.	Pin	Desc.
1	WAKE#	20	W_DISABLE#	36	USB D-
2	+3.3Vaux	21	GND	37	GND
3	COEX1	22	PERST#	38	USB D+
4	GND	23	PERn0	39	+3.3V
5	COEX2	24	+3.3V	40	GND
6	+1.5V	25	PERp0	41	+3.3V
7	CLKREQ#	26	GND	42	LED WWAN#
8	None	27	GND	43	GND
9	GND	28	+1.5V	44	LED WLAN#
10	None	29	GND	45	Reserved
11	REFCLK-	30	SMB_CLK	46	LED WPAN#
12	None	31	PETn0	47	Reserved
13	REFCLK+	32	SMB_DATA	48	+1.5V
14	None	33	PETp0	49	Reserved
15	GND	34	GND	50	GND
16	None	35	GND	51	Reserved
17	None			52	+3.3V
18	GND				
19	None				

Board Top




## System Configuration

### GIF2

**Description:** PCI Express bus

**Connector Type:** 164-pin PCI Express edge connector


#### Board Top



Pin	Desc.	Pin	Desc.	Pin	Desc.	Pin	Desc.
A1	PRSN1#	A22	HSIN_1	A43	HSIP_6	A63	GND60
A2	+12V4	A23	GND17	A44	HSIN_6	A64	HSIP_11
A3	+12V5	A24	GND18	A45	GND35	A65	HSIN_11
A4	GND6	A25	HSIP_2	A46	GND36	A66	GND61
A5	JTAG2	A26	HSIN_2	A47	HSIP_7	A67	GND62
A6	JTAG3	A27	GND19	A48	HSIN_7	A68	HSIP_12
A7	JTAG4	A28	GND20	A49	GND37	A69	HSIN_12
A8	JTAG5	A29	HSIP_3	A50	RSVD8	A70	GND63
A9	+3.3V2	A30	HSIN_3	A51	GND54	A71	GND64
A10	+3.3V3	A31	GND21	A52	HSIP_8	A72	HSIN_13
A11	PWRGD	A32	RSVD6	A53	HSIN_8	A73	HSIN_13
A12	GND7	A33	RSVD7	A54	GND55	A74	GND65
A13	REF CLK+	A34	GND30	A55	GND56	A75	GND66
A14	REF CLK-	A35	HSIP_4	A56	HSIP_9	A76	HSIP_14
A15	GND8	A36	HSIN	A57	HSIN_9	A77	HSIN_14
A16	HSIP_0	A37	GND31	A58	GND57	A78	GND67
A17	HSIN_0	A38	GND32	A59	GND58	A79	GND68
A18	GND9	A39	HSIP_5	A60	HSIP_10	A80	HSIP_15
A19	RSVD5	A40	HSIN_5	A61	HSIN_10	A81	HSIN_15
A20	GND16	A41	GND33	A62	GND59	A82	GND69
A21	HSIP_1	A42	GND34				



Board Bottom



Pin	Desc.	Pin	Desc.	Pin	Desc.	Pin	Desc.
B1	+12V1	B22	GND11	B43	GND26	B63	HSON_11
B2	+12V2	B23	HSOP_2	B44	GND27	B64	GND44
B3	+12V3	B24	HSOP_2	B45	HSOP_7	B65	GND45
B4	GND1	B25	GND12	B46	HSOP_7	B66	HSOP_12
B5	SMCLK	B26	GND13	B47	GND28	B67	HSOP_12
B6	SMDAT	B27	HSOP_3	B48	PRSNT2#2	B68	GND46
B7	GND2	B28	HSOP_3	B49	GND29	B69	GND47
B8	+3.3V1	B29	GND14	B50	HSOP_8	B70	HSOP_13
B9	JTAG1	B30	RSVD3	B51	HSOP_8	B71	HSOP_13
B10	3.3VAUX	B31	PRSNT2#1	B52	GND38	B72	GND48
B11	WAKE#	B32	GND15	B53	GND39	B73	GND49
B12	RSVD2	B33	HSOP_4	B54	HSOP_9	B74	HSOP_14
B13	GND3	B34	HSOP_4	B55	HSOP_9	B75	HSOP_14
B14	HSOP_0	B35	GND22	B56	GND40	B76	GND50
B15	HSOP_0	B36	GND23	B57	GND41	B77	GND51
B16	GND4	B37	HSOP_5	B58	HSOP_10	B78	HSOP_15
B17	PRSNT2#	B38	HSOP_5	B59	HSOP_10	B79	HSOP_15
B18	GND5	B39	GND24	B60	GND42	B80	GND52
B19	HSOP_1	B40	GND25	B61	GND43	B81	PRSNT2#1
B20	HSOP_1	B41	HSOP_6	B62	HSOP_11	B82	RSVD4
B21	GND10	B42	HSOP_6				

# System Configuration


## MIC1

**Destination:** Mic-in Port


**Connector Type:** Pink 3.5mm audio jack




Pin	Description
1	MICL
2	N/A
3	MIC_R
4	MIC1_JD
5	AU_GND
6	AU_GND



## Board Top



## Front Panel




## LOUT1

**Description:** Line-out Port


**Connector Type:** Lime green 3.5mm audio jack





Pin	Description
1	LOUT-L
2	LOUT-L
3	LOUT-R
4	FRONT_JD
5	AU_GND
6	AU_GND



### Board Top



### Front Panel




# System Configuration


## USB1 & USB2

**Destription:** USB Ports


**Connector Type:** Double-stacked type-A USB connectors




Pin	Description	Pin	Description
1	VCC-1	2	DNEG-1
3	DPOS-1	4	GND-1
5	VCC-2	6	DNEG-2
7	DPOS-2	8	GND-2
H1	MNT-HOLE1	H2	MNT-HOLE2
H3	MNT-HOLE3	H4	MNT-HOLE4



### Board Top




### Front Panel




LAN1

**Decription:** LAN Ports

**Connector Type:** Two 8P8C RJ-45 connectors with LED and shield




Pin	Description	Pin	Description
A1	LAN1_MDIP0	B1	LAN2_MDIP0
A2	LAN1_MDIN0	B2	LAN2_MDIN0
A3	LAN1_MDIP1	B3	LAN2_MDIP1
A4	LAN1_MDIN1	B4	LAN2_MDIN1
A5	GND	B5	GND
A6	GND	B6	GND
A7	LAN1_MDIP2	B7	LAN2_MDIP2
A8	LAN1_MDIN2	B8	LAN2_MDIN2
A9	LAN1_MDIP3	B9	LAN2_MDIP3
A10	LAN1_MDIN3	B10	LAN2_MDIN3
LA1	LA_1	LB1	LB_1
LA2	LA_2	LB2	LB_2
LA3	LA_3	LB3	LB_3
LA4	LA_4	LB4	LB_4




Pin	Description
H1	MNT-HOLE1
H2	MNT-HOLE2
X1	CGND1
X2	CGND2

Board Top



Front Panel




# System Configuration

## DVI1


The computer features a DVI (digital visual interface) port, supporting DVI-I (digital and analog).

**Description:** DVI-I port (digital and analog)  
**Connector Type:** 29-pin DIP-type female connector



Pin	Desc.	Pin	Desc.	Pin	Desc.
1	T.M.D.S DATA 2-	11	T.M.D.S DATA 1/3 SHIELD	21	T.M.D.S DATA 5+
2	T.M.D.S DATA 2+	12	T.M.D.S DATA 3-	22	T.M.D.S CLOCK SHIELD
3	T.M.D.S DATA 2/4 SHIELD	13	T.M.D.S DATA 3+	23	T.M.D.S CLOCK+
4	T.M.D.S DATA 4-	14	+5V Power	24	T.M.D.S CLOCK-
5	T.M.D.S DATA 4+	15	GND	C1	ANALOG RED
6	DDC CLOCK	16	HOT PLUG DETECT	C2	ANALOG GREEN
7	DDC DATA	17	T.M.D.S DATA 0-	C3	ANALOG BLUE
8	ANALOG VERT. SYNC	18	T.M.D.S DATA 0+	C4	ANALOG HORZ SYNC
9	T.M.D.S DATA 1-	19	T.M.D.S DATA 0/5 SHIELD	C5	ANALOG GROUND
10	T.M.D.S DATA 1+	20	T.M.D.S DATA 5-		


### Board Top



### Front Panel A10




### B10



**PWBT1**


**Decription:** Power Button

**Connector Type:** LED tact switch with green and red colors




Pin	Description	Pin	Description
1	GND	2	N/A
3	BTN	4	N/A
L1	SW1_LED_N	L2	SW1_LED_P


**Board Top**



**Front Panel**  
A10



B10



## System Configuration

---

### BTN1

**Description:** Connector for power button

**Connector Type:** Onboard 1x2-pin header


Pin	Description
-----	-------------

1	PWR_IN_SW#
---	------------

2	GND
---	-----



### Board Top






**PWR1**


**Destription:** Connectors for DC-in power.

**Connector Type:** Onboard 4-pin one-wall wafer connector

Pin	Description	Pin	Description
1	PWRINV+	2	PWRINV+
3	GND	4	GND



**Board Top**




## System Configuration


### MC2

**Description:** mSATA socket  
**Connector Type:** Onboard 0.8mm pitch 52-pin edge card connector

Pin Desc.	Pin Desc.	Pin Desc.
1 NC	20 NC	36 NC
2 +3.3V	21 GND	37 GND
3 NC	22 NC	38 NC
4 GND	23 TX+	39 +3.3V
5 NC	24 +3.3V	40 GND
6 NC	25 TX-	41 +3.3V
7 NC	26 GND	42 NC
8 NC	27 GND	43 GND
9 GND	28 NC	44 NC
10 NC	29 GND	45 NC
11 NC	30 NC	46 NC
12 NC	31 RX-	47 NC
13 NC	32 NC	48 NC
14 NC	33 RX+	49 NC
15 GND	34 GND	50 GND
16 NC	35 GND	51 NC
17 NC		52 +3.3V
18 GND		
19 NC		



### Board Top




### 3.2.3. Daughter Board Connectors (ARES-1500-B10 only)

This section will guide you through the connectors on the daughter board SCDB-1277.


#### PWRIN1

**Description:** DC-in power receptacle  
**Connector Type:** 5.00mm-pitch 3-pole Euro-Type terminal block




Pin	Desc.
1	PWRINV+
2	GND
3	PWR_IN_SW#

#### SCDB-1277 Board Top



#### Front Panel



## System Configuration

---

### PWR1

**Description:** Computer's power jack

**Connector Type:** Onboard 1x4-pin header


Pin	Description
-----	-------------

1	PWRINV+
---	---------


2	PWRINV+
---	---------

3	GND
---	-----

4	GND
---	-----



### SCDB-1277 Board Top



## BTN1

**Description:** Connector for power button

**Connector Type:** Onboard 1x2-pin header


Pin	Description
-----	-------------

1	PWR_IN_SW#
---	------------

2	GND
---	-----



## SCDB-1277 Board Top



---

This page is intentionally left blank.

---

# Chapter 4

## Installation and Maintenance

### 4.1. Install Hardware

The ARES-1500-A10 is constructed based on modular design to make it easy for users to add hardware or to maintain the computer. The following sections will guide you to the simple hardware installations for the computer.

#### 4.1.1. Open the Computer

For the computer, removing the bottom cover is essential to open the computer and access the inside. Follow through the steps below to remove the bottom cover from the computer.

##### 4.1.1.1. Remove Bottom Cover

All jumpers, connectors, PCI Express Mini-card sockets and SDRAM SO-DIMM slot are built on the top side of the main board. To access these components, the computer's bottom cover has to go. Follow through the steps below to remove the bottom cover.

1. Place the computer on a flat surface. Loosen and remove the 4 screws from the front panel of the computer as marked in the illustration below.




ARES-1500-A10




ARES-1500-B10



- Loosen and remove the 3 screws from the rear panel of the computer as marked in the illustration below.




- Turn the computer over.



- For ARES-1500-A10, hoist the bottom and disconnect the cable from the power connector. Then part the bottom cover completely from the main board. For ARES-1500-B10, simply remove the bottom cover.


ARES-1500-A10



## Installation & Maintenance


---

ARES-1500-B10




The inside of the computer comes to view.

ARES-1500-A10




ARES-1500-B10



- ▶ To adjust jumpers or connect/disconnect devices to/from the main board, see [3.2. Jumpers and Connectors](#) on page [17](#).
- ▶ To install a memory module to the computer, see [4.1.2. Install Memory Module](#) on page [48](#).
- ▶ To install the wireless modules based on **PCI Express Mini-card** form factor, see [4.1.5. Install Wireless Modules](#) on page [55](#).

### 4.1.2. Install Memory Module


The main board has one dual inline memory module (DIMM) sockets. Load the computer with a memory module of higher capacity to make programs run faster. The memory module for the computer's SO-DIMM socket should be a 204-pin DDR3 with a "key notch" off the centre among the pins, which enables the memory module for particular applications. There are another two notches at each left and right side of the memory module to help fix the module in the socket.




#### To install a DDR3 memory module:

1. Remove the bottom cover from the computer as described in [4.1.1.1. Remove Bottom Cover](#) on page 44.
2. Find the SO-DIMM socket on the board as marked in the illustration below.

ARES-1500-A10




ARES-1500-B10




The SO-DIMM socket is horizontal type, and it has two spring-loaded locks to fix the memory module.


3. Confront the memory module's edge connector with the SO-DIMM slot connector. Align the memory module's key notch at the break on the SO-DIMM slot connector.



4. Fully plug the memory module until it cannot be plugged any more.



5. Press down the memory module until it gets auto-locked in place.



6. Restore the bottom cover to the computer.
-

### **To uninstall the DDR3 memory module:**


1. Pull back both locks from the memory module.  
The DDR3 memory module will be auto-released from the socket.
2. Remove the memory module.
3. Restore the bottom cover to the computer.

### 4.1.3. Install mSATA Storage


To install an mSATA storage module to the computer:

1. Remove the bottom cover from the computer as described in [4.1.1. Open the Computer](#) on page [44](#).
2. See the illustration below and find the **PCI Express Mini-card** socket for an mSATA storage.

ARES-1500-A10



ARES-1500-B10



3. Confront the mSATA module's edge connector with the socket's connector. Align the module's key notch the connector's break.



The module's key notch should meet the connector's break.

## Installation & Maintenance

---

4. Fully plug the module until it cannot be plugged any more.



Fully plug the module.

5. Press down the module and fix the module in place using two screws.



6. Restore the bottom cover to the computer.



#### 4.1.4. Install SIM Card


The computer comes with a SIM socket for 3G networking. Follow through the guide below to install a SIM card to the computer.

Note: To make use of a SIM card for 3G networking, a 3G module is also needed on the computer, see [Appendix B](#) to install the 3G module **HSPA-SI1400**.

1. Remove the bottom cover from the computer as described in [4.1.1. Open the Computer](#) on page 44.

The inside of the computer comes to view.


2. See the illustration below and find the **SIM Card** socket for 3G networking.




## Installation & Maintenance

---

3. Push back the hinged cover to open the socket.




4. Swivel the hinged cover.



5. The hinged cover is also the card holder. Slide a SIM card along the hinged cover. Note the notch on the SIM card should meet the notch on the socket.



6. Put down the hinged cover and push it forward to lock the SIM card in place.



#### 4.1.5. Install Wireless Modules

The computer comes with two **Mini-card** sockets to load the computer with the wireless modules of **PCI Express Mini-card** form factor. The configure-to-order wireless modules available with the computer are the 3G module **HSPA-SI1400** and the Wi-Fi module **WIFI-IN1300**:



HSPA-SI1400  
HSUPA 3.75G module kit & internal wiring



WIFI-IN1300  
Intel® Centrino® Advanced-N 6205 Wi-Fi module w/ 20cm internal wiring

(See also [1.5.2. Configure-to-Order Service](#) on page [5](#).)

- If you have ordered the 3G module **HSPA-SI1400**, see [Appendix B](#) to know how to install the hardware and software for the module.
- If you have ordered the Wi-Fi module **WIFI-IN1300**, see [Appendix C](#) to know how to install the hardware and software for the module.


### 4.2. Mount the Computer

Integrate the computer to where it works by mounting it to a wall in the surroundings or to the rear of a display monitor.

#### 4.2.1. VESA-Mount

Mounting the computer to the rear of a display monitor relies on VMK-1000, a VESA mount kit, which is available on your option. Follow the guide below to mount the computer to a display monitor using VMK-1000.


1. Prepare the VMK-1000 VESA mount kit, which includes two adapters. Halfway fasten two screws to each of the adapters as marked in the illustration below.



2. Mount the two adapters to the rear of the display monitor by fastening the four screws as marked in the illustration below:




3. Hang the computer onto the VMK-1000 VESA mount kit, and fully tighten the four halfway-fastened screws as previously mentioned.



#### 4.2.2. Wall-Mount

Follow through the guide below to mount the computer to a wall.

1. Find the four cutouts as marked in the illustration below:



2. Mount the computer to a wall by the said cutouts.


### 4.3. Wire DC-Input Power Source



**Warning** Only trained and qualified personnel are allowed to install or replace this equipment.

Follow the instructions below for connecting the computer to a DC-input power source.

1. Before wiring, make sure the power source is disconnected.
2. Find the terminal block in the accessory box.
3. Use the wire-stripping tool to strip a short insulation segment from the output wires of the DC power source.
4. Identify the positive and negative feed positions for the terminal block connection. See the symbols printed on the rear panel indicating the polarities and DC-input power range in voltage.
5. Insert the exposed wires into the terminal block plugs. Only wires with insulation should extend from the terminal block plugs. Note that the polarities between the wires and the terminal block plugs must be positive to positive and negative to negative.
6. Use a slotted screwdriver to tighten the captive screws. Plug the terminal block firmly, which wired, into the receptacle on the rear panel.



---

# Chapter 5

## BIOS

## BIOS

The BIOS Setup utility for the computer is featured by American Megatrends Inc to configure the system settings stored in the system's BIOS ROM. The BIOS is activated once the computer powers on. When the computer is off, the battery on the main board supplies power to BIOS RAM.

To enter the BIOS Setup utility, keep hitting the “Delete” key upon powering on the computer.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Main Advanced Chipset Boot Security Save & Exit		
BIOS Information		Choose the system default language.
BIOS Vendor	American Megatrends	
Core Version	4.6.5.1	
BIOS Version	ARES-1500 1.00	
Build Date and Time	02/21/2013 19:11:53	
Memory Information		
Total Memory	4080 MB (DDR3)	
System Language	[English]	
System Date	[Sat 03/15/2008]	←→: Select Screen
System Time	[20:28:31]	↑↓: Select Item
Access Level	Administrator	Enter: Select
		+/-: Change Option
		F1: General Help
		F2: Previous Values
		F9: Optimized Defaults
		F10: Save & Exit
		ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

The BIOS' featured menus are:

Menu	Description
<b>Main</b>	See <a href="#">5.1. Main</a> on page <a href="#">62</a> .
<b>Advanced</b>	See <a href="#">5.2. Advanced</a> on page <a href="#">64</a> .
<b>Chipset</b>	See <a href="#">5.3. Chipset</a> on page <a href="#">73</a> .
<b>Boot</b>	See <a href="#">5.4. Boot</a> on page <a href="#">76</a> .
<b>Security</b>	See <a href="#">5.5. Security</a> on page <a href="#">78</a> .
<b>Save &amp; Exit</b>	See <a href="#">5.6. Save &amp; Exit</a> on page <a href="#">79</a> .



## Key Commands

The BIOS Setup utility relies on a keyboard to receive user's instructions. Hit the following keys to navigate within the utility and configure the utility.

Keystroke	Function
← →	Moves left/right between the top menus.
↓ ↑	Moves up/down between highlight items.
<b>Enter</b>	Selects an highlighted item/field.
<b>Esc</b>	<ul style="list-style-type: none"> <li>▶ On the top menus: Use <b>Esc</b> to quit the utility without saving changes to CMOS. (The screen will prompt a message asking you to select <b>OK</b> or <b>Cancel</b> to exit discarding changes.</li> <li>▶ On the submenus: Use <b>Esc</b> to quit current screen and return to the top menu.</li> </ul>
<b>Page Up / +</b>	Increases current value to the next higher value or switches between available options.
<b>Page Down / -</b>	Decreases current value to the next lower value or switches between available options.
<b>F1</b>	Opens the <b>Help</b> of the BIOS Setup utility.
<b>F10</b>	Exits the utility saving the changes that have been made. (The screen then prompts a message asking you to select <b>OK</b> or <b>Cancel</b> to exit saving changes.)

**Note:** Pay attention to the "WARNING" that shows at the left pane onscreen when making any change to the BIOS settings.

This BIOS Setup utility is updated from time to time to improve system performance and hence the screenshots hereinafter may not fully comply with what you actually have onscreen.

# BIOS

## 5.1. Main

The **Main** menu features the settings of **System Date** and **System Time** and displays some BIOS info and system info.

The BIOS info displayed are:

Info	Description
<b>BIOS Vendor</b>	Delivers the provider of the BIOS Setup utility.
<b>Core Version</b>	Delivers the version of the core.
<b>BIOS Version</b>	Delivers the computer's BIOS version.
<b>Build Date and Time</b>	Delivers the date and time when the BIOS Setup utility was created/updated.
<b>Memory Information</b>	Delivers the capacity of the DDR3 SDRAM present in the system.
<b>Access Level</b>	Delivers the level that the BIOS is being accessed at the moment. (Only <b>Administrator Level</b> is available.)


The featured settings are:

Setting	Description
<b>System Language</b>	Sets the BIOS Setup utility's default language. ▶ Only <b>English</b> is available.
<b>System Time</b>	Sets system time.
<b>System Date</b>	Sets system date.

# BIOS

## 5.2. Advanced

Access the **Advanced** menu to manage the computer's system configuration including the Super IO chip.



The featured settings and submenus are:

Setting	Description
<b>Launch PXE OpROM</b>	Enables/disables the boot option for legacy network devices. ▶ <b>Disabled</b> is the default ▶ "PXE" means "Preboot Execution Environment", a series of methods to get a typical Windows-based computer to boot up without a hard drive or boot diskette.
<b>Restore AC Power</b>	Sets the AC power state when power is resumed after a power failure. ▶ Options available are <b>Always on</b> and <b>Always off</b> (default).
<b>ACPI Settings</b>	See <a href="#">5.2.1. ACPI Settings</a> on page <a href="#">66</a> .
<b>CPU Configuration</b>	See <a href="#">5.2.2. CPU Configuration</a> on page <a href="#">67</a> .
<b>IDE Configuration</b>	See <a href="#">5.2.3. IDE Configuration</a> on page <a href="#">68</a> .

---

<b>USB Configuration</b>	See <a href="#">5.2.4. USB Configuration</a> on page <a href="#">68</a> .
<b>Super IO Configuration</b>	See <a href="#">5.2.5. Super IO Configuration</a> on page <a href="#">69</a> .
<b>H/W Monitor</b>	See <a href="#">5.2.6. H/W Monitor</a> on page <a href="#">72</a> .

### 5.2.1. ACPI Settings

The submenu **ACPI Settings** allow users to configure the system's ACPI (Advanced Configuration and Power Interface) by the following settings:

Setting	Description
<b>Enable Hibernation</b>	Enables/disables the system to/from hibernation (OS/S4 Sleep State). <ul style="list-style-type: none"><li>▶ This option may not be effective with some OS.</li><li>▶ <b>Enabled</b> is the default.</li></ul>
<b>ACPI Sleep State</b>	Sets the highest ACPI sleep state for the system to enter when the suspend button is hit. <ul style="list-style-type: none"><li>▶ Options available are: <b>Suspend Disabled</b> <b>S1 only (CPU Stop Clock)</b> (default) <b>S3 only (Suspend to RAM)</b></li></ul>
<b>AC Power Shutdown mode</b>	Sets the power-supply type. <ul style="list-style-type: none"><li>▶ Options available are <b>AT</b> and <b>ATX</b> (default).</li><li>▶ Note this setting should be consistent with jumper J1 to prevent possible conflict. See <a href="#">J1</a> on page <a href="#">44</a> for J1 jumper setting.</li></ul>

### 5.2.2. CPU Configuration

Select **CPU Configuration** to run a report of the CPU's details including: model name, processor speed, microcode revision, max./min. processor speeds, the amount of processor core(s), and CPU caches. See the depiction below:

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.	
Main <b>Advanced</b> Chipset Boot Security Save & Exit	
CPU Configuration	
Socket0: AMD G-T40N Processor Dual Core Running @ 1010 MHz 1112 mV Max Speed: 1000 MHz Intended Speed: 1000 MHz Min Speed: 800 MHz Microcode Patch Level: 500010d	
----- Cache per Core -----	
L1 Instruction Cache:	32 KB/2-way
L1 Data Cache:	32 KB/8-way
L2 Cache:	512 KB/16-way
No L3 Cache Present	
	→+: Select Screen ↓↑: Select Item Enter: Select +/-: Change Option F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.	

### 5.2.3. IDE Configuration

Select **IDE Configuration** to view the information about the mSATA storage present in the system.

### 5.2.4. USB Configuration

Select this submenu to view the status of the USB ports and configure USB features. The featured settings are:

Setting	Description
<b>Legacy USB Support</b>	Enables/disables legacy USB support. <ul style="list-style-type: none"><li>▶ Options available are <b>Enabled</b> (default), <b>Disabled</b> and <b>Auto</b>.</li><li>▶ Select <b>Auto</b> to disable legacy support if no USB device are connected.</li><li>▶ Select <b>Disabled</b> to keep USB devices available only for EFI applications.</li></ul>
<b>EHCI Hand-off</b>	Enables/disables a workaround for the operating systems that have no EHCI hand-off support <ul style="list-style-type: none"><li>▶ <b>Disabled</b> is the default..</li></ul>
<b>Device power-up delay</b>	Sets the maximum time that elapses before a USB device reports itself to the controller. <ul style="list-style-type: none"><li>▶ Select <b>Auto</b> (default) to apply a 100 ms delay to the root port and make the hub port use the delay from Hub descriptor.</li><li>▶ Select <b>Manual</b> to customize a delay from 1 to 40 seconds.</li></ul>



### 5.2.5. Super IO Configuration

This submenu configures the Super IO chip for the computer's COM1 to COM4. The featured submenus are:

Submenu	Description	
Serial Port 0 Configuration	Configures the computer's COM1, which is RS232/RS422/RS485 configurable. The featured settings are:	
	Setting	Description
	Serial Port	Enables/disables the serial port. ▶ <b>Enabled</b> is the default.
	Change Settings	Sets the optimal IO address and IRQ info for the serial port, or leaves it on BIOS auto-detection. ▶ Options available are: <b>Auto;</b> (default) <b>IO=3F8h; IRQ=4;</b> <b>IO=3F8h; IRQ=3,4,5,6,7,10,11,12;</b> <b>IO=2F8h; IRQ=3,4,5,6,7,10,11,12;</b> <b>IO=3E8h; IRQ=3,4,5,6,7,10,11,12;</b> <b>IO=2E8h; IRQ=3,4,5,6,7,10,11,12;</b> ▶ This setting is only available when the serial port is enabled.
COM1 RS485 AutoFlow	Enables/disables RS485 mode. ▶ <b>Disabled</b> is the default. ▶ Note this setting needs to be consistent with the jumpers JV2 and JV3 settings to prevent possible conflict. See also <a href="#">JV2 &amp; JV3</a> on page <a href="#">19</a> .	

<b>Serial Port 1 Configuration</b>	Configures the computer's COM2, which is fixed to RS232 and cannot be changed. The featured settings are:	
	Setting	Description
	<b>Serial Port</b>	Enables/disables the serial port. ▶ <b>Enabled</b> is the default.
<b>Serial Port 2 Configuration</b>	<b>Change Settings</b>	Sets the optimal IO address and IRQ info for the serial port, or leaves it on BIOS auto-detection. ▶ Options available are: <b>Auto</b> ; (default) <b>IO=2F8h; IRQ=3</b> ; <b>IO=3F8h; IRQ=3,4,5,6,7,10,11,12</b> ; <b>IO=2F8h; IRQ=3,4,5,6,7,10,11,12</b> ; <b>IO=3E8h; IRQ=3,4,5,6,7,10,11,12</b> ; <b>IO=2E8h; IRQ=3,4,5,6,7,10,11,12</b> ; ▶ This setting is only available when the serial port is enabled.
	Setting	Description
	<b>Serial Port</b>	Enables/disables the serial port. ▶ <b>Enabled</b> is the default.
<b>Serial Port 2 Configuration</b>	<b>Change Settings</b>	Sets the optimal IO address and IRQ info for the serial port, or leaves it on BIOS auto-detection. ▶ Options available are: <b>Auto</b> ; (default) <b>IO=3E8h; IRQ=7</b> ; <b>IO=3E8h; IRQ=3,4,5,6,7,10,11,12</b> ; <b>IO=2E8h; IRQ=3,4,5,6,7,10,11,12</b> ; <b>IO=2F0h; IRQ=3,4,5,6,7,10,11,12</b> ; <b>IO=2E0h; IRQ=3,4,5,6,7,10,11,12</b> ; ▶ This setting is only available when the serial port is enabled.
	Setting	Description
	<b>Serial Port</b>	Enables/disables the serial port. ▶ <b>Enabled</b> is the default.

<b>Serial Port 0 Configuration</b>	Configures the computer's COM4, which is fixed to RS232 and cannot be changed. The featured settings are:	
	Setting	Description
	<b>Serial Port</b>	Enables/disables the serial port. ▶ <b>Enabled</b> is the default.
<b>Change Settings</b>	Sets the optimal IO address and IRQ info for the serial port, or leaves it on BIOS auto-detection. ▶ Options available are: <b>Auto</b> ; (default) <b>IO=2E8h; IRQ=7</b> ; (default) <b>IO=3E8h; IRQ=3,4,5,6,7,10,11,12</b> ; <b>IO=2E8h; IRQ=3,4,5,6,7,10,11,12</b> ; <b>IO=2F0h; IRQ=3,4,5,6,7,10,11,12</b> ; <b>IO=2E0h; IRQ=3,4,5,6,7,10,11,12</b> ; ▶ This setting is only available when the serial port is enabled.	

# BIOS

## 5.2.6. H/W Monitor

Select this submenu to view the main board's hardware status. Select it to run a report of various info as depicted below:

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Main **Advanced** Chipset Boot Security Save & Exit


Pc Health Status	
Chipset temperature	: +50 °c
CPU temperature	: +58 °c
VCORE	: +1.112 V
+5VA	: +5.045 V
+5V	: +5.003 V
+12VA	: +12.168 V

←+: Select Screen  
↓↑: Select Item  
Enter: Select  
+/-: Change Option  
F1: General Help  
F2: Previous Values  
F9: Optimized Defaults  
F10: Save & Exit  
ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

### 5.3. Chipset

The **Chipset** menu controls the system's chipset, including the north bridge and the south bridge.



The featured submenus are **North Bridge** and **South Bridge**, which are detailed in the following of this section.

Submenu overview:

Submenu	Description
North Bridge	Configures the north bridge. See <a href="#">5.3.1. North Bridge Configuration</a> on page <a href="#">74</a> for the settings.
South Bridge	Configures the south bridge. See <a href="#">5.3.2. South Bridge Configuration</a> on page <a href="#">75</a> for the settings.

### 5.3.1. North Bridge Configuration

Select this submenu to access the north bridge configuration, which covers the submenus **GFX Configuration** and **PCIE Ports Configuration**:

Submenu	Description	
<b>GFX Configuration</b>	Configures the system's graphics. The featured setting is:	
	Setting	Description
	<b>Display Port Output</b>	Sets the system's video output: <ul style="list-style-type: none"> <li>▶ Options available are:  <b>Single Link DVI-I</b> (default)  <b>Disabled</b></li> </ul>
<b>PCIE Ports Configuration</b>	Configures the north bridge PCI Express ports by the following settings:	
	Setting	Description
	<b>Mini PCIe Slot</b>	Enables/disables the computer's PCI Express Mini-card sockets. <ul style="list-style-type: none"> <li>▶ <b>Enabled</b> is the default.</li> </ul>
	<b>ASPM Mode Control</b>	Configures the ASPM (Active State Power Management) support for the PCI Express ports. <ul style="list-style-type: none"> <li>▶ Options available are:  <b>Disabled</b>  <b>L0s Entry</b>  <b>L1 Entry</b>  <b>L0s and L1 Entry</b> (default)</li> </ul>
	<b>Link Speed</b>	Configures north bridge root port PCI Express link speed, which may be overwritten by Psppt settings. <ul style="list-style-type: none"> <li>▶ "Psppt" means the processor-supported "PCIe speed power policy", the dynamic change of the link frequency due to the changes in system configuration and power policy.</li> <li>▶ Options available are:  <b>Auto</b> (default, which means to leave the link speed on BIOS auto-detection)  <b>Pcie Gen1</b>  <b>Pcie Gen2</b></li> </ul>
<b>LAN1</b>	Enables/disables the system's LAN port 1. <ul style="list-style-type: none"> <li>▶ <b>Enabled</b> is the default.</li> </ul>	
<b>LAN2</b>	Enables/disables the system's LAN port 2. <ul style="list-style-type: none"> <li>▶ <b>Enabled</b> is the default.</li> </ul>	

### 5.3.2. South Bridge Configuration

Select this submenu to view the south bridge's CIM (common information model) version and configure the system's south bridge:


The featured submenus are:

Submenu	Description	
<b>SB SATA Configuration</b>	Configures the south bridge's SATA features by the following settings:	
	Setting	Description
	<b>OnChip SATA Channel</b>	Enables/disables the system's serial ATA features: ▶ <b>Enabled</b> is the default.
	<b>OnChip SATA Type</b>	Set's the system's SATA type: ▶ Options available are: <b>Native IDE</b> (default) <b>AHCI</b> <b>Legacy IDE</b> ▶ This setting is only available when <b>OnChip SATA Channel</b> is set to <b>Enabled</b> .
	<b>OnChip IDE mode</b>	Sets how to run the IDE: ▶ Options available are: <b>Legacy mode</b> (default) <b>Native mode</b>
	<b>SATA IDE Combined Mode</b>	Enables/disables SATA IDE combined mode: ▶ <b>Enabled</b> is the default. ▶ This setting is only available when <b>OnChip SATA Channel</b> is set to <b>Enabled</b> .
<b>Combined Mode Option</b>	Set how to combine the IDE and SATA: ▶ Options available are: <b>SATA as primary</b> (default) <b>SATA as secondary</b> ▶ This setting is only available when both <b>OnChip SATA Channel</b> and <b>SATA IDE Combined Mode</b> are set to <b>Enabled</b> .	
<b>SB USB Configuration</b>	Enables/disables the computer's USB ports.	
<b>SB HD Azalia Configuration</b>	Configures the system's high-definition audio by the following setting:	
	Setting	Description
<b>HD Audio Azalia Device</b>	Enables/disables the system's HD audio Azalia device: ▶ <b>Enabled</b> is the default.	

# BIOS

## 5.4. Boot

The **Boot** menu configures how to boot up the system such as the configuration of boot device priority.



The featured settings are:

Setting	Description
<b>Bootup NumLock State</b>	Sets whether to enable or disable the keyboard's NumLock state when the system starts up. <ul style="list-style-type: none"><li>▶ Options available are <b>On</b> (default) and <b>Off</b>.</li></ul>
<b>Quiet Boot</b>	Sets whether to display the POST (Power-on Self Tests) messages or the system manufacturer's full screen logo during booting. <ul style="list-style-type: none"><li>▶ Select <b>Disabled</b> to display the normal POST message, which is the default.</li></ul>



<p><b>Fast Boot</b></p>		<p>Enables/disables initializing only a minimal set of devices required to launch the active boot options when booting up the system.</p> <ul style="list-style-type: none"> <li>▶ <b>Disabled</b> is the default.</li> <li>▶ This setting has no effect for BBS (BIOS Boot Specification) options.</li> <li>▶ When enabled, the following settings become available:</li> </ul>				
		<table border="1"> <thead> <tr> <th data-bbox="441 392 564 427">Setting</th> <th data-bbox="564 392 953 427">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="441 427 564 512"> <p><b>Skip VGA</b></p> </td> <td data-bbox="564 427 953 512"> <p>Enables/disables skipping EFI VGA driver when booting up the system.</p> <ul style="list-style-type: none"> <li>▶ <b>Disabled</b> is the default.</li> </ul> </td> </tr> </tbody> </table>	Setting	Description	<p><b>Skip VGA</b></p>	<p>Enables/disables skipping EFI VGA driver when booting up the system.</p> <ul style="list-style-type: none"> <li>▶ <b>Disabled</b> is the default.</li> </ul>
		Setting	Description			
		<p><b>Skip VGA</b></p>	<p>Enables/disables skipping EFI VGA driver when booting up the system.</p> <ul style="list-style-type: none"> <li>▶ <b>Disabled</b> is the default.</li> </ul>			
<p><b>Skip USB</b></p>	<p>Enables/disables skipping USB devices when booting up the system.</p> <ul style="list-style-type: none"> <li>▶ When enabled, the USB devices won't be available until OS startup.</li> <li>▶ When disabled, the USB devices are available before OS startup. This is the default.</li> </ul>					
<p><b>Skip PS2</b></p>	<p>Enables/disables skipping PS2 (keyboard and mouse) devices when booting up the system.</p> <ul style="list-style-type: none"> <li>▶ <b>Disabled</b> is the default.</li> </ul>					
<p><b>Boot Option Priorities</b></p>	<p><b>Boot Option #1</b></p>	<p>Sets the very 1st boot device among the available device types.</p> <ul style="list-style-type: none"> <li>▶ Option(s) available are the available device type(s), which is the default, and <b>Disabled</b>.</li> </ul>				
<p><b>Hard Drive BBS Priority</b></p>		<p>Sets the very 1st boot device among the available hard disk drives.</p> <ul style="list-style-type: none"> <li>▶ Option(s) available are the available storage device(s) and <b>Disabled</b>.</li> </ul>				

# BIOS

## 5.5. Security

The **Security** menu sets up the password for the system's administrator account. Once the administrator password is set up, this BIOS Setup utility is limited to access and will ask for the password each time any access is attempted.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.  
Main Advanced Chipset Boot Security Save & Exit

Set Administrator Password

Password Description

Minimum length 3  
Maximum length 20

Administrator Password

HDD Security Configuration:  
HDD 0:MRMAJ5A016GC

++: Select Screen  
↑↓: Select Item  
Enter: Select  
+/-: Change Option  
F1: General Help  
F2: Previous Values  
F9: Optimized Defaults  
F10: Save & Exit  
ESC: Exit


Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

The featured setting is:

Setting	Description
<b>Administrator Password</b>	To set up an administrator password: <ol style="list-style-type: none"><li>1. Select <b>Administrator Password</b>. An <b>Create New Password</b> dialog then pops up onscreen.</li><li>2. Enter your desired password that is no less than 3 characters and no more than 20 characters.</li><li>3. Hit [Enter] key to submit.</li></ol>

## 5.6. Save & Exit

The **Save & Exit** menu features a handful of commands to launch actions from the BIOS Setup utility regarding saving changes, quitting the utility and recovering defaults.



The features settings are:

Setting	Description
<b>Save Changes and Exit</b>	Saves the changes and quits the BIOS Setup utility.
<b>Discard Changes and Exit</b>	Quits the BIOS Setup utility without saving the change(s).
<b>Save Changes and Reset</b>	Saves the changes and restarts the system.
<b>Discard Changes and Reset</b>	Restarts the system without saving the change(s).
<b>Restore Defaults</b>	Restores all settings to defaults. <ul style="list-style-type: none"> <li>▶ This is a command to launch an action from the BIOS Setup utility rather than a setting.</li> </ul>

## BIOS

---

<b>Boot Override</b>	<b>Boot Override</b> presents a list in context with the boot devices in the system. Select the device to boot up the system regardless of the currently configured boot priority. <ul style="list-style-type: none"><li>▶ This is a command to launch an action from the BIOS Setup utility rather than a setting.</li></ul>
<b>Launch EFI Shell from filesystem device</b>	Triggers the attempt to launch EFI Shell application (Shellx64.efi) from one of the available filesystem devices.

---

# Appendices

---

### Appendix A: Watchdog Timer (WDT) Setting

WDT is widely used for industry application to monitor the activity of CPU. Application software depends on its requirement to trigger WDT with adequate timer setting. Before WDT time out, the functional normal system will reload the WDT. The WDT never time out for a normal system. The WDT will not be reloaded by an abnormal system, then WDT will time out and auto-reset the system to avoid abnormal operation.

This computer supports 255 levels watchdog timer by software programming I/O ports.

Below is an assembly program example to disable and load WDT.

#### Sample Codes:

```
/*----- Include Header Area -----*/
#include "math.h"
#include "stdio.h"
#include "dos.h"

#define SIO_INDEX      0x2E          /* or index = 0x4E */
#define SIO_DATA       0x2F          /* or data  = 0x4F */

/*----- routing, sub-routing -----*/
void main()
{
    outportb(SIO_INDEX, 0x87);      /* SIO - Enable */
    outportb(SIO_INDEX, 0x87);

    outportb(SIO_INDEX, 0x07);      /* LDN - WDT */
    outportb(SIO_DATA, 0x07);

    outportb(SIO_INDEX, 0x30);      /* WDT - Enable */
    outportb(SIO_DATA, 0x01);

    outportb(SIO_INDEX, 0xF6);      /* WDT - Timeout Value : 5sec */
    outportb(SIO_DATA, 0x05);

    outportb(SIO_INDEX, 0xFA);      /* WDOUT - Enable */
    outportb(SIO_DATA, 0x01);

    outportb(SIO_INDEX, 0xF5);      /* WDT - Configuration */
    outportb(SIO_DATA, 0x31);

    outportb(SIO_INDEX, 0xAA);      /* SIO - Disable */
}

```

## Appendix B: 3G Module HSPA-SI1400 Hardware/Software Installation


To be able to network with 3G, hardware-wise the computer needs a 3G module installed and a SIM card inserted (as described in [4.1.4. Install SIM Card](#) on page [53](#)) and software-wise the computer needs the device driver and an application program. This appendix will guide you to install the 3G module **HSPA-SI1400** and the device driver. (To have a copy of the device driver, please contact ARBOR customer service as described in [Technical Support](#) on page [viii](#).)

### B.1. Install HSPA-SI1400


1. Remove the computer's bottom cover as described in [4.1.1. Open the Computer](#) on page [44](#).

The inside of the computer comes to view.

ARES-1500-A10




ARES-1500-B10



2. Find the **PCI Express Mini-card** socket for 3G modules as the illustration above shows.


The socket has a break among the connector .




## Appendices

3. Have the **HSPA-SI1400** 3G module kit. The 3G module is a full-size module of **PCI Express Mini-card** form factor, with two U.FL connectors, one is “MAIN”, and the other is “AUX”.

Two U.FL connectors, one is “MAIN”, the other is “AUX”.



4. Plug the 3G module to the socket's connector by a slanted angle. Fully plug the module, and note the notch on the wireless module should meet the break of the connector.



Fully plug the module.

5. Press down the module and fix the module in place using two screws.







6. If you are using the antenna hole on the computer's rear panel, remove the rear panel by loosening and removing the screws as shown in the illustration below:  
(If you are not using the antenna hole on the computer's rear panel, skip this step.)



7. Remove the plastic plug from the computer's rear (or front) panel to make an antenna hole. Keep the plastic plug for any possible restoration in the future.



8. Have the RF antenna. The antenna has an SMA connector on one end and an MHF connector on the other.





## Appendices

9. Connect the RF antenna's MHF connector to the 3G module's "MAIN" connector.


Connect the RF antenna's MHF connector to the 3G module's "MAIN" connector.




10. From the other end of the RF antenna, which is an SMA connector, remove the washer and the nut. Save the washer and nut for later use. Note the SMA connector has the form of a threaded bolt, with one flattened side.




11. Pull the SMA connector through the above mentioned antenna hole. Note to meet the aforesaid flattened side with the antenna hole's flat side.





12. Mount the washer first and then the nut to the SMA connector. Make sure the nut is tightened.



13. Restore the rear panel to the computer. (If you are not using the antenna hole on the computer's rear panel, skip this step.)




14. Restore the computer's bottom cover.

## Appendices

---

15. Have an external antenna. Screw and tightly fasten the antenna to the SMA connector.



16. Swivel the antenna to an angle of best signals.



## B.2. Install Device Driver

As described in [2.3. Driver Installation Notes](#) on page 11, after the drivers for the chipset, .NET Framework, audio and Ethernet are installed, you can proceed to install the driver for the wireless modules such as 3G module or Wi-Fi module.

To install the driver for the 3G module **HSPA-SI1400**:

1. Request a copy of the device driver from ARBOR customer service by the contact info as described in [Technical Support](#) on page viii.
2. Run the executable file **SWIQMISetup.exe**.

The installer then opens.




## Appendices

---

3. Click the **Next** button to proceed.

The driver installation then starts, progresses and finishes.




4. Click the **Finish** button to quit the driver installation.


### B.3. Install Application Program

1. Request a copy of the application program from ARBOR customer service by the contact info as described in [Technical Support](#) on page [viii](#).
2. Run the Windows Installer file **Watcher\_Generic.msi**.

The installer opens and prepares to install.



Once the preparation finishes, the installer prompts to install **Sierra Wireless AirCard Watcher** on the computer.



## Appendices

---


3. Click the **Next** button to proceed.

The installer then prompts the license agreement.



4. Select **I accept the terms in the license agreement**. Click the **Change...** button to browse for an alternate folder to install the application program to, or simply click the **Next** button to install the application program to the suggested folder.


The installation then starts, progresses and finishes.





5. Click the **Finish** button to quit the installation.

An **AirCard Watcher** icon  then shows up on the desktop.

6. Double-click the **AirCard Watcher** icon  to launch the application program.

The **AirCard Watcher** opens.



7. See the document of the **AirCard Watcher** to know how to use the application program.

## Appendix C: Wi-Fi Module WIFI-IN1300 Hardware/Software Installation

To use Wi-Fi, hardware-wise the computer needs a Wi-Fi module installed, and software-wise the computer needs the device driver and an application program. This appendix will guide you to install the Wi-Fi module **WIFI-IN1300** and the device driver. (To have a copy of the device driver, please contact ARBOR customer service by the contact info described in [Technical Support](#) on page [viii](#).)


### C.1. Install WIFI-IN1300

1. Remove the computer's bottom cover as described in [4.1.1.1. Remove Bottom Cover](#) on page [44](#).


The inside of the computer comes to view.

2. Find the two **Mini-card** sockets for wireless modules on the board as the illustration below shows. Either socket goes for Wi-Fi modules. However, it is suggested that you install the Wi-Fi module to the socket without a SIM card socket and reserve the socket interconnected with the SIM card socket for 3G modules.

ARES-1500-A10




ARES-1500-B10



the socket interconnected with a SIM card socket


the socket without a SIM card socket, which is recommended for the Wi-Fi module.

The socket has a break among the connector.



connector break

3. Prepare the **WIFI-IN1300** Wi-Fi module kit. The module is a half-size module of **PCI Express Mini-card** form factor, with two U.FL connectors, one is "MAIN", and the other is "AUX".



Two U.FL connectors, one is "MAIN", the other is "AUX".

## Appendices

4. In order to make the half-size Wi-Fi module compatible with the **Mini-card** socket, extend the WiFi module with a “mini half bracket”. Join them together by using two screws.



Position the WiFi module and the “mini half bracket” exactly as shown.



Join the WiFi module and the “mini half bracket” by using two screws.

5. Plug the Wi-Fi module to the socket's connector by a slanted angle. Fully plug the module, and note the notch on the wireless module should meet the break of the connector.



Fully plug the module.


6. Press down the module and fix the module in place using two screws.




7. If you are using the antenna hole on the computer's rear panel, remove the rear panel by loosening and removing the screws as shown in the illustration below:  
(If you are not using the antenna hole on the computer's rear panel, skip this step.)



8. Remove the plastic plug from the computer's rear (or front) panel to make an antenna hole. Keep the plastic plug for any possible restoration in the future.




9. Have the RF antenna. The antenna has an SMA connector on one end and an MHF connector on the other.




## Appendices

10. Connect the RF antenna's MHF connector to the Wi-Fi module's "MAIN" connector.


Connect the RF antenna's MHF connector to the Wi-Fi module's "MAIN" connector




11. From the other end of the RF antenna, which is an SMA connector, remove the washer and the nut. Save the washer and nut for later use. Note the SMA connector has the form of a threaded bolt, with one flat side.




12. Pull the SMA connector through the above mentioned antenna hole. Note to meet the aforesaid flat side with the antenna hole's flat side.





13. Mount the washer first and then the nut to the SMA connector. Make sure the nut is tightened.



14. Restore the rear panel to the computer. (If you are not using the antenna hole on the computer's rear panel, skip this step.)




15. Restore the computer's bottom cover.

## Appendices

---

16. Have an external antenna. Screw and tightly fasten the antenna to the SMA connector.



17. Swivel the antenna to an angle of best signals.






## C.2. Install Device Driver & Application Program

As described in [2.3. Driver Installation Notes](#) on page 11, after the drivers for the chipset, .NET Framework, audio and Ethernet are installed, you can proceed to install the driver for the wireless modules such as 3G module or Wi-Fi module.

The device driver of **WIFI-IN1300** will install the application program (the utility) as well. Follow the guide below to install **WIFI-IN1300** driver (and the application program):

1. Request a copy of the device driver from ARBOR customer service by the contact info as described in [Technical Support](#) on page viii.
2. Run the executable file of the device driver, for example **Advanced-N 6205 WinXP\_14.2.0.10\_x32.exe**.

The installer then opens.




## Appendices

---

3. Click the **Next** button to proceed.

The installer then starts to prepare for the setup.




When the preparation finishes, the installer prompts to install **Intel(R) PROSet/Wireless WiFi Software** on the computer.




4. Click the **Next** button to proceed.

The installer then prompts the license agreement.



5. Select **I accept the terms in the license agreement** and click the **Next** button to proceed.

The installer then asks where to install the software.




## Appendices

---


- Click the **Change...** button to browse for an alternate folder to install the software to, or simply click the **Next** button to install the software to the suggested folder.

The installer then opens a **Setup Type** selection.




- Select **Typical** to install both the driver and the application program (recommended) or select **Custom** to choose the features to install. Then click the **Next** button to proceed.

The software installation then starts, progresses and finishes.



8. Click the **Finish** button to quit the software installation.



9. The computer's Wi-Fi feature is ready-to-use, see the document of the application program to know how to connect the computer to a Wi-Fi hotspot.