ELIT-1650 Series

Robust Embedded System with Intel[®] Core[™] i7-2610UE / Celeron[®] 827E Processor

User's Manual

Version 1.0



P/N: 4012165000100P

This page is intentionally left blank.

Contents

Chapter 1 - General Information	1
1.1. Introduction	2
1.2. Product Highlights	2
1.3. Ordering Information	3
1.4. Packing List	4
1.5. Optional Accessory	4
1.6. Optional Configuration (Configure to Order Service)	4
1.8. Specifications	6
1.9. Dimensions	8
1.10. External Controls and Connectors	9
Chapter 2 - Engine of the Computer	11
2.1. Board Layout	12
2.1.1. CPU Board	12
2.1.2. Carrier Board	13
2.2. DIP Switches and Connectors	15
2.2.1. List of DIP Switches and Connectors	15
2.2.2. DIP Switch Setting	16
2.2.3. Pin Assignment for Connectors	20
Observations Oscillations and Maintenances	07
Chapter 3 - Installation and Maintenance	
3.1. Remove Bottom Cover	27 28
3.1. Remove Bottom Cover	27 28 29
3.1. Remove Bottom Cover 3.2. Install Wi-Fi Module (Optional) 3.3. Install/Uninstall CFast Card	27 28 29 30
3.1. Remove Bottom Cover 3.2. Install Wi-Fi Module (Optional) 3.3. Install/Uninstall CFast Card 3.4. Wall Mount	27 28 29 30 31
3.1. Remove Bottom Cover 3.2. Install Wi-Fi Module (Optional) 3.3. Install/Uninstall CFast Card 3.4. Wall Mount 3.5. DIN-Rail Mount	27 28 29 30 31 32
3.1. Remove Bottom Cover 3.2. Install Wi-Fi Module (Optional) 3.3. Install/Uninstall CFast Card 3.4. Wall Mount 3.5. DIN-Rail Mount 3.5.1. Dismount from DIN-rail	27 28 29 30 31 32 34
 3.1. Remove Bottom Cover	27 28 29 30 31 32 34 35
 3.1. Remove Bottom Cover	27 28 29 30 31 32 34 35 36
 3.1. Remove Bottom Cover	27 28 29 30 31 32 34 35 36 37
 3.1. Remove Bottom Cover	27 28 29 30 31 32 34 35 36 37 38
 3.1. Remove Bottom Cover	27 28 29 30 31 32 34 35 36 37 38 38 39
 3.1. Remove Bottom Cover	27 28 29 30 31 32 34 35 36 36 37 38 39 39
 3.1. Remove Bottom Cover	27 28 29 30 31 32 34 35 36 36 37 38 39 39 39 39
 3.1. Remove Bottom Cover	27 28 29 30 31 32 34 35 36 37 38 39 39 39 42 44
 3.1. Remove Bottom Cover	27 28 29 30 31 32 34 35 36 37 38 39 39 39 39 39 34 34 35 36 37 38 39 34 35 36 34 35 36 34 35 36 36 37 38 39 34 35 36 34 35 36 34 35 36 34 35 34 34 35 34 34 35 34 34 35 34 34 35 34 34 35 34 34 35 34 34 35 34 34 35 34 34 35 34 34 34 34 34 34 34 34 34 34 34 34 34 34 34
 3.1. Remove Bottom Cover	27 28 29 30 31 32 34 35 36 37 38 39 39 39 42 44 48 50

Chapter 5 - BIOS	55
5.1. Main	58
5.2. Advanced	60
5.2.1. ACPI Settings	61
5.2.2. CPU Configuration	62
5.2.3. SATA Configuration	63
5.2.4. Intel Anti-Theft Technology Configuration	67
5.2.5. AMT Configuration	68
5.2.6. USB Configuration	71
5.2.7. H/W Monitor -CPU Board	72
5.2.8. Second Super IO Configuration	72
5.2.9. Super IO Configuration	75
5.2.10. H/W Monitor -I/O Board	76
5.2.11. Sandybridge PPM Configuration	76
5.3. Chipset	78
5.3.1. System Agent (SA) Configuration	79
5.3.2. PCH-IO Configuration	87
5.4. Boot	93
5.5. Security	94
5.6. Save & Exit	95
Appendix	97
A: Watchdog Timer (WDT) Setting	98

Copyright Notice

All Rights Reserved.

The information in this document is subject to change without prior notice in order to improve the reliability, design and function. It does not represent a commitment on the part of the manufacturer.

Under no circumstances will the manufacturer be liable for any direct, indirect, special, incidental, or consequential damages arising from the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Declaration of Conformity

CE

The CE symbol on your product indicates that it is in compliance with the directives of the Union European (EU). A Certificate of Compliance is available by contacting Technical Support.

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from ARBOR. Please contact your local supplier for ordering information.

Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

FCC Class A

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the

equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

RoHS

ARBOR Technology Corp. certifies that all components in its products are in compliance and conform to the European Union's Restriction of Use of Hazardous Substances in Electrical and Electronic Equipment (RoHS) Directive 2002/95/EC.

The above mentioned directive was published on 2/13/2003. The main purpose of the directive is to prohibit the use of lead, mercury, cadmium, hexavalent chromium, polybrominated biphenyls (PBB), and polybrominated diphenyl ethers (PBDE) in electrical and electronic products. Member states of the EU are to enforce by 7/1/2006.

ARBOR Technology Corp. hereby states that the listed products do not contain unintentional additions of lead, mercury, hex chrome, PBB or PBDB that exceed a maximum concentration value of 0.1% by weight or for cadmium exceed 0.01% by weight, per homogenous material. Homogenous material is defined as a substance or mixture of substances with uniform composition (such as solders, resins, plating, etc.). Lead-free solder is used for all terminations (Sn(96-96.5%), Ag(3.0-3.5%) and Cu(0.5%)).

SVHC / REACH

To minimize the environmental impact and take more responsibility to the earth we live, Arbor hereby confirms all products comply with the restriction of SVHC (Substances of Very High Concern) in (EC) 1907/2006 (REACH --Registration, Evaluation, Authorization, and Restriction of Chemicals) regulated by the European Union.

All substances listed in SVHC < 0.1 % by weight (1000 ppm)

Important Safety Instructions

Read these safety instructions carefully

- 1. Read all cautions and warnings on the equipment.
- 2. Place this equipment on a reliable surface when installing. Dropping it or letting it fall may cause damage
- 3. Make sure the correct voltage is connected to the equipment.
- 4. For pluggable equipment, the socket outlet should be near the equipment and should be easily accessible.
- 5. Keep this equipment away from humidity.
- 6. The openings on the enclosure are for air convection and protect the equipment from overheating. DO NOT COVER THE OPENINGS.
- 7. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
- 8. Never pour any liquid into opening. This may cause fire or electrical shock.
- 9. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
- 10. If one of the following situations arises, get the equipment checked by service personnel:
 - a. The power cord or plug is damaged.
 - b. Liquid has penetrated into the equipment.
 - c. The equipment has been exposed to moisture.
 - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
 - e. The equipment has been dropped or damaged.
 - f. The equipment has obvious signs of breakage.
- 11. Keep this User's Manual for later reference.

About This User's Manual

This User's Manual is intended for experienced users and integrators with hardware knowledge of personal computers. If you are not sure about any description in this User's Manual, please consult your vendor before further handling.

Warning

The Box PC and its components contain very delicately Integrated Circuits (IC). To protect the Box PC and its components against damage caused by static electricity, you should always follow the precautions below when handling it:

- 1. Disconnect your Box PC from the power source when you want to work on the inside.
- 2. Use a grounded wrist strap when handling computer components.
- 3. Place components on a grounded antistatic pad or on the bag that came with the Box PC, whenever components are separated from the system.

Lithium Battery Replacement

Incorrect replacement of the lithium battery may lead to a risk of explosion. The lithium battery must be replaced with an identical battery or a battery type recommended by the manufacturer.

Do not throw lithium batteries into the trash can. It must be disposed of in accordance with local regulations concerning special waste.

Technical Support

If you have any technical difficulties, please consult the user's manual first at: ftp://ftp.arbor.com.tw/pub/manual

Please do not hesitate to call or e-mail our customer service when you still cannot find out the answer.

http://www.arbor.com.tw E-mail:info@arbor.com.tw

Warranty

This product is warranted to be in good working order for a period of one year from the date of purchase. Should this product fail to be in good working order at any time during this period, we will, at our option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster.

Vendor assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, or inability to use this product. Vendor will not be liable for any claim made by any other related party.

Vendors disclaim all other warranties, either expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose, with respect to the hardware, the accompanying product's manual(s) and written materials, and any accompanying hardware. This limited warranty gives you specific legal rights.

Return authorization must be obtained from the vendor before returned merchandise will be accepted. Authorization can be obtained by calling or faxing the vendor and requesting a Return Merchandise Authorization (RMA) number. Returned goods should always be accompanied by a clear problem description.

This page is intentionally left blank.



1.1. Introduction

ELIT-1650 is a digital signage player meant for service industry to deliver information to customers timely, efficiently and cost-effectively. Optionally loaded with Intel[®] Core[™] i7-2610UE or Celeron[®] 827E, the digital signage player is enhanced by Intel[®] HD Graphics 3000 to bring high-end graphics performance.

ELIT-1650 is ideal for the PIS (Passenger Information System) for the mass transportation services such as train stations and airports. It also brings the brain for the kiosks in hotels and movie theatres. It is capable of the rich multimedia contents needed for the advertisement screens in the leisure places such as shopping malls and complexes. The computer is all about hospitality enhancement and customers touting for your business.

1.2. Product Highlights

All-In-One Platform

The CPU, DRAM and even software are integrated to provide a plug-and-play machine.

Compact-sized

The brain of ELIT-1650 is either EmETXe-i65M2-827E or EmETXe-i67M2-2610UE with carrier board PBC-9004. The boards are based on non-standard form factor to make the computer compact enough and consume only a little space.

Fanless Design

By using a low power processor, the system does not have to rely on fans, which are unreliable and often cause dust to circulate inside the equipment.

Modular CPU Board

The modularized CPU board facilitates the possible maintenance or upgrades to system. Systems based on a modular CPU board can be easily modified to fit many different applications on customers' requests. Powerful Networking

The ELIT-1650 provides multiple COM ports, two Ethernet ports and six USB ports for data communication.

Numerous Display/Video Output

Integrated with an Intel[®] HD Graphics core, ELIT-1650 improves graphics and 3D rendering performance and supports the display/video output including DVI-I and HDMI.

Advanced Storage

ELIT-1650 comes with an eSATA port for fast data transfer speeds for external storage device and a CFast-card slot for better, faster and cost-effective expansibility for more applications.

Trustworthy

The onboard Watchdog Timer can invoke an NMI or system reset when your application misbehaves within the system.

1.3. Ordering Information

ELIT 1650 2610UE	Barebone system w/ Intel [®] Core [™] i7-2610UE w/o
ELI1-1050-20100E	storage and memory
	Barebone system w/ Intel® Celeron® 827E w/o
ELII-1650-627E	storage and memory
	Intel [®] Core [™] i7-2610UE Box System with 16GB
ELIT-1650-26100E-1652G	SSD and 2GB DDR3 1333MHz SDRAM
	Intel® Celeron® 827E Box System with 16GB SSD
ELII-1650-627E-1652G	and 2GB DDR3 1333MHz SDRAM

1.4. Packing List

Upon opening the package, carefully inspect the contents. If any of the items is missing or appears damaged, contact your local dealer or distributor. The package should contain the following items:



1.5. Optional Accessory



PAC-B065W-1 65W AC/DC adapter kit

1.6. Optional Configuration (Configure to Order Service)

The following items are normally optional, but some vendors may include them as a standard package, or some vendors may not carry all the items.

Minis	SSD-25016 2.5" 16GB SATAII SSD
	SSD-25032 2.5" 32GB SATAII SSD
	MM-3I-2G DDR3-1333 2GB SDRAM
	MM-3I-4G DDR3-1333 4GB SDRAM



WIFI-IN1300 Intel® Centrino® Advanced-N 6205 WiFi module w/ 20cm internal wiring



ANT-D11 1 x WiFi Dual-band 2.4G/5G antenna

1.7. CD Drivers Paths

Windows XP

Driver	Path			
Chipset	\CHIPSET\INTEL\XP_32_64_WIN7_32_64_SERIES			
VGA	\GRAPHICS\INTEL\XP_32			
LAN	\ETHERNET\XP_32			
Audio	\AUDIO\REALTEK\XP_32_64			
ME	\ME			
.NET Framework	NET FRAMEWORK			

Windows 7 32-bit

Driver	Path			
Chipset	\CHIPSET\INTEL\XP_32_64_WIN7_32_64_SERIES			
VGA	\GRAPHICS\INTEL\WIN7_32			
LAN	\ETHERNET\WIN7_32			
Audio	\AUDIO\REALTEK\WIN7_32_64			
ME	\ME			

Windows 7 64-bit

Driver	Path
Chipset	\CHIPSET\INTEL\XP_32_64_WIN7_32_64_SERIES
VGA	\GRAPHICS\INTEL\WIN7_64
LAN	\ETHERNET\WIN7_64
Audio	\AUDIO\REALTEK\WIN7_32_64
ME	\ME

1.8. Specifications

System Kernel			
Processor	Soldered onboard Intel [®] Core [™] i7-2610UE 1.5GHz or Celeron [™] 827E 1.4GHz Processor		
BIOS	AMI Flash BIOS		
Chipset	Intel [®] PCH QM67 for EmETXe-i67M2-2610UE Intel [®] PCH HM65 for EmETXe-i65M2-827E		
Graphics	Integrated Intel [®] HD Graphics 3000		
Memory	2 x 204-pin SO-DIMM sockets, supporting DDR3 1066/1333 MHz up to 8GB SDRAM		
Serial ATA	1 x Serial ATA port with 600MB/s HDD transfer rate		
Ethernet Controller • 1 x Intel [®] 82579LM Gigabit Ethernet controller w/ iAMT 7.0 • 1 x Intel [®] 82583V Gigabit Ethernet controller			
Watchdog Timer	1 ~ 255 levels reset		
I/O Ports			
Serial Port	• 4 x COM ports RS-232 • 2 x COM ports RS-232/485		
Expansion Bus	1 x Mini-card slot for optional WiFi module		
USB Port	6 x USB 2.0 ports		
LAN 2 x RJ-45 ports for Gigabit Ethernet			
Video Port	 1 x DVI-I receptacle for Digital Video output 1 x HDMI female connector for Digital Video output 		
Audio	Mic-in, Line-out		
External SATA	1 x eSATA port		
Storage			
Туре	 1 x 2.5" drive bay for HDD/SSD 1 x outside accessible CFast socket 		
Qualification			
FCC	Class A certified		
CE	Certified		
Environmental			
Operating Temp.	-20 ~ 60°C (-4 ~ 140°F), ambience w/ air flow		
Storage Temp.	-40 ~ 85°C (-40 ~ 185°F)		
Relative Humidity	5 ~ 95% @ 40°C (non-condensing)		

-					
Vibration	1 Grms/5~500Hz/random operation, CFast, 1G/SDD				
Shock	Operating 40G (11ms), Non-operating 80G with SSD Operating 20G (11ms), Non-operating 60G with HDD				
Mechanical					
Construction	Aluminum alloy				
Mounting	DIN-rail mount & wall mount				
Weight	2.87 kg (6.32 lb) (Bare-bone)				
Dimensions (W x D x H)	228.5 x 155 x 65 mm (8.99" x 6.10" x 2.55")				
Power Requirement					
Power Input	DC 9-32V input				
Power Consumption	Max. 38W				

1.9. Dimensions







1.10. External Controls and Connectors

Take a look around the computer and find the external controls and connectors.

Front View



Rear View



This page is intentionally left blank.

Chapter 2 Engine of the Computer

2.1. Board Layout

The CPU board of either EmETXe-i67M2 or EmETXe-i65M2 and the carrier board PBC-9004 together form the engine of the ELIT-1650.

2.1.1. CPU Board

Top View



Bottom View

COM Express[®] AB Connector COM Express[®] CD Connector



2.1.2. Carrier Board

PBC-9004: Board Top



PBC-9004: Board Bottom



2.2. DIP Switches and Connectors

2.2.1. List of DIP Switches and Connectors

DIP Switches

Board Side	No.	Label	Function
Bottom 1			Clears/keeps CMOS setting
	SW4	Selects the BIOS from the CPU board or carrier board.	
			Switches power supply between AT and ATX modes.
Bottom	SW1~3 Sets COM5~6 to RS-232 or RS-485.		

Connectors

Board Side	No.	Label	Description			
Bottom	1	SATA1	Serial ATA connectors			
Bottom	2	MC1	Mini-card interface connector			
Тор	3	COM A/B	COM1~4 RS-232 serial ports			
Тор	4	COM C	COM5~6 RS-232/485 serial ports			
Тор	5	LAN1~2	Ethernet connectors (including USB connectors)			
Тор	6	CF1	CFast slot			
Тор	7	ESATA1	External serial ATA connector			
Тор	8	CN3	HDMI and DVI-I connectors			
Тор	9	AUDIO2	Audio jack connector (line-out/mic-in)			
Тор	10	KBUSB1	PS/2 keyboard and mouse (including USB connectors)			
Тор	(1)	PW1	Power button			
Тор	12	PWRIN1	DC power input			
Тор	(13)	LED1	HDD status LED			
Тор	(14)	CPUF1	CPU fan connector			

2.2.2. DIP Switch Setting

2.2.2.1. SW4 1: Clears/Keeps CMOS Setting

The SW4 is a 8-pin and 4-toggle switch. It relies on its toggles 1 and 2 to clear/keep the CMOS setting of the computer.

	Toggle	Position	Function	Setting
SW4	1	On	Keeps CMOS setting	
	2	Off	(default)	Toggle 1 2 3 4
	Toggle	Position	Function	Setting
SW4	1	Off	f Clears CMOS setting	
	2	On		
				Toggle 1 2 3 4

2.2.2.2. SW4 **0**: Sets Power Supply Mode

It relies on SW4's toggles 3 to switch the power supply mode between AT and ATX modes.

	Toggle	Position	Function	Setting
SW4	3	Off	Sets the power supply to ATX mode (default)	Toggle 1 2 3 4
	3	On	Sets the power supply to AT mode	Toggle 1 2 3 4

2.2.2.3. SW4 0: Selects BIOS from CPU Board / Carrier Board

It relies on SW4's toggle 4 to select the BIOS from either the CPU board or the carrier board.

	Toggle	Position	Function	Setting
SW4	4	On	Selects the BIOS from the CPU board	Toggle 1 2 3 4
	4	Off	Selects the BIOS from te carrier boards (default)	Toggle 1 2 3 4

2.2.2.4. SW1, SW3 @: COM5 Data Transmission Interface Setting

It relies on SW1 and SW3 to set the data transmission interface for COM5. To set COM5 to RS-232 or RS-485, apply the following setting:

RS-232 (Default)

	Toggle	Pins	Position	Setting
	1	1 & 16	On	
	2	2 &15	On	16 15 14 12 12 11 10 0
CIM/A	3	3 & 14	On	16 15 14 13 12 11 10 9
2001	4	4 & 13	On	
	5	5 & 12	On	
·	6	6 & 11	On	
	7	7 & 10	On	1 2 3 4 5 6 7 8
·	8	8 & 9	On	
	Toggle	Pins	Position	Setting
	1	1 & 16	On	16 15 14 13 12 11 10 9
SW3	2	2 &15	Off	
	3	3 & 14	Off	
	4	4 & 13	Off	1 2 3 4 5 6 7 8

RS-485

	Toggle	Pins	Position	Setting
	1	1 & 16	Off	-
	2	2 &15	Off	16 15 14 13 12 11 10 9
	3	3 & 14	Off	
SW1	4	4 & 13	Off	
	5	5 & 12	Off	
	6	6 & 11	Off	1 2 3 4 5 6 7 8
	7	7 & 10	Off	1 2 3 4 3 0 7 8
	8	8&9	Off	
	Toggle	Pins	Position	Setting
	1	1 & 16	Off	16 15 14 13 12 11 10 9
SW3	2	2 &15	On	
	3	3 & 14	On	
	4	4 & 13	On	1 2 3 4 5 6 7 8

2.2.2.5. SW2, SW3 2: COM6 Data Transmission Interface Setting

It relies on SW2 and SW3 to set the data transmission interface for COM6. To set COM6 to RS-232 or RS-485, apply the following setting:

RS-232 (Default)

	Toggle	Pins	Position	Setting
	1	1 & 16	On	-
	2	2 &15	On	
	3	3 & 14	On	IG IS 14 IS 12 II IO 9
SW2	4	4 & 13	On	
	5	5 & 12	On	
	6	6 & 11	On	
	7	7 & 10	On	1 2 3 4 5 6 7 8
	8	8&9	On	

	Toggle	Pins	Position
	5	5 & 12	On
SW3	6	6 & 11	Off
	7	7 & 10	Off
	8	8 & 9	Off



▶ RS-485

	Toggle	Pins	Position
	1	1 & 16	Off
	2	2 &15	Off
	3	3 & 14	Off
SW2	4	4 & 13	Off
	5	5 & 12	Off
	6	6 & 11	Off
	7	7 & 10	Off
	8	8&9	Off
	Toggle	Pins	Position
	5	5 & 12	Off
SW3	6	6 & 11	On
	7	7 & 10	On
	8	8 & 9	On

Setting





2.2.3. Pin Assignment for Connectors

PWRIN1 12: DC Power Input

Pin	Description	9 - 32V
1	PWRIN1_VCC	\bigcirc
2	C-GND	+ _ DC IN

KBUSB1 (1): PS/2 Keyboard and USB Stacked Connectors Connector type: 6-pin Mini-DIN/Stacked USB type A connector

USB Pin	Description		
1	+5V	KB_VC	
2	USB-		
3	USB+		1 2 3 4
4	GND		

LAN1~2 (5): LAN + USB Stacked Connectors

This connector supports USB 2.0 x 2 (USB0, 1) & 10/100Mbps or Gigabit RJ-45 Ethernet connection.

LAN (RJ-45)

Pin	Description
1	MDI0+
2	MDI0-
3	MDI1+
4	MDI1-
5	MDI2+
6	MDI2-
7	MDI3+
8	MDI3-



USB (Type A Connector)

Pin	Description
1	+5V
2	USB-
3	USB+
4	GND

AUDIO2 (9): Audio Jacks

The jacks support HD '97 audio. The green jack is line-out jack while the pink one is the mic-in.

Pin	Description		1
1	GND	Line-out	
2	R		
3	HP-IN	Õ	
4	GND	MIC-in	0
5	L		5

COM A/B/C (3)(4): Stacked Male Type DSUB9 Connectors Serial ports 1 ~ 6

	Pin	Description	Pin	Description	
RS232 (COM 1~6)	1	DCD1	2	RXD1	
	3	TXD1	4	DTR1	600009
	5	GND	6	DSR1	
	7	RTS1	8	CTS1	_
	9	RI1	10	NC	

	Pin	Description	Pin	Description
	1	485-	2	485+
RS485	3	NC	4	NC
(CON 5~6	5	GND	6	NC
only)	7	NC	8	NC
	9	NC	10	NC

CPUF1 (4): Reserved Fan Connector

Connector Type: Onboard 3-pin wafer connector for the system fan. The fan must be a +12V fan.

Pin Description

- 1 GND
- 2 +12V
 - 12 V
- 3 Fan_Detect

3	2	1
0	0	

MC1 2: Mini-card Slot



Pin	Description	Pin	Description
1	Wake	2	+3.3V
3	COEX1	4	GND
5	COEX2	6	+1.5V
7	CLKREQ#	8	UIM_PWR
9	GND	10	UIM_DATA
11	REFCLK-	12	UIM_CLK
13	REFCLK+	14	UIM_RESET
15	GND	16	UIM_VPP
17	UIM_C8/Reserved	18	GND
19	UIM_C4/Reserved	20	W_Disable#
21	GND	22	PERST#
23	PERn0	24	+3.3V
25	PERp0	26	GND
27	GND	28	+1.5V
29	GND	30	SMB_CLK
31	PETn0	32	SMB_DATA
33	PETp0	34	GND
35	GND	36	USB_D-
37	GND	38	USB_D+
39	+3.3V	40	GND
41	+3.3V	42	LED_WWAN#
43	GND	44	LED_WLAN#
45	Reserved	46	LED_WPAN#
47	Reserved	48	+1.5V
49	Reserved	50	GND
51	Reserved	52	+3.3V

SATA1 ①: Serial ATA Connector

Connector Type: Standard 15-pin Serial ATA Connector that supports two SATA ports at 6 Gb/s (SATA1,2)

Pin	Description	Pin	Description
S1	GND	P1	+V3.3S
S2	TX+	P2	+V3.3S
S3	TX-	P3	+V3.3S
S4	GND	P4	GND
S5	RX+	P5	GND
S6	RX-	P6	GND
S7	GND	P7	+V5S
		P8	+V5S
		P9	+V5S
		P10	GND
		P11	NC
		P12	GND
		P13	NC
		P14	NC
		P15	NC

CF1 6: CFast Card Connector

This connector supports two SATA ports at 6 Gb/s (SATA1, 2)



ESATA1 ⑦: External SATA Connector

Pin	Description
1	GND
2	TX+
3	TX-
4	GND
5	RX+
6	RX-
7	GND



CN3 ⑧: HDMI and DVI-I Connectors

HDMI Connector

Pin	Description	Pin	Description
1	DATA2	2	GND
3	DATA2#	4	DATA1
5	GND	6	DATA1#
7	DATA0	8	GND
9	DATA0#	10	CLK
11	GND	12	CLK#
13	NC	14	NC
15	SPC	16	SPD
17	GND	18	+5V
19	HPD	20	GND
21	GND	22	GND
23	GND		



DVI-I Connector

Pin	Description	Pin	Description	11 18	C1 C2
11	TX2-	12	TX2+		818
13	GND	14	NC		
15	NC	16	DVI DDC CLK	117 124	C4 C3
17	DVI DDC DATA	18	CRT VSYNC		
19	TX1-	I10	TX1+		
111	GND	l12	NC	-	
I13	NC	114	+5V	-	
l15	CRT HPD	I16	HTPLG	-	
117	TX0-	l18	TX0+	-	
119	GND	120	CRT DDC CLK	_	
121	CRT DDC DATA	122	GND	-	
123	TXC+	124	TXC-	-	
C1	CRT RED	C2	CRT RED	-	
C3	CRT BLUE	C4	CRT HSYNC	-	
C5	GND	C6	GND	-	


Installation & Maintenance

ELIT-1650 is based on modular design for easy setup and maintenance. The following sections will guide you to the simple hardware installations.

3.1. Remove Bottom Cover

- 1. Place the Box PC upside down on a flat surface.
- 2. See the picture below. Loosen and remove the eight screws that fixes the bottom cover.



3. Dismount the bottom cover from the computer.



Then the storage bracket and mini-card socket come into view.

3.2. Install Wi-Fi Module (Optional)

- 1. Remove the bottom cover as described in <u>3.1. Remove Bottom Cover</u> on page <u>28</u>.
- 2. Find the mini-card socket. There is a break on the socket's connector.



3. Plug a Wi-Fi module to the socket's connector by a slanted angle. Note the notch on the Wi-Fi module should meet the break on the connector.



4. Press down the module and fix it in place using two screws.



3.3. Install/Uninstall CFast Card

- Note: Be sure to power off the computer before installing or removing the CFast card if the OS is installed on it.
- 1. Find the door to CFast card socket on the front panel of the computer. Loosen and remove the screw that fixes the door.



2. Once the door is removed, the socket shows.



3. Install a CFast card to the socket.

4



4. Restore the card door.

If later it is necessary to uninstall the CFast card, remove the card as described in step 1 and push-eject the card.



Push-eject the card to remove it.

3.4. Wall Mount

The computer comes with 4 cutouts at the four corners on the bottom plate. Use these cutouts to mount the computer to a wall where the computer works.





3.5. DIN-Rail Mount

The computer supports only landscape orientation on the DIN-Rail.



Landscape orientation

Prepare the DIN-rail adapters, screws and a screwdriver. Each DIN-rail adapter is equipped with a clip to integrate with the DIN-rail.



Follow through the steps below to use DIN-rail on the computer:

- 1. Place the computer upside down on a flat surface.
- 2. Find the 8 screw holes for mounting the DIN rail adapters.



3. Mount the adapters to the computer. Fix them place with 8 screws.







down side

4. Confront the adapter-side with the DIN-rail. Hang the computer onto the DIN-rail by the adapters' clips.



5. Push the down side of the computer to snap the computer completely onto the DIN-rail.



6. If the computer cannot be fixed on the DIN-rail, try again the other side around.

3.5.1. Dismount from DIN-rail

Power off the computer and disconnect all cables from it before dismouting the computer off the DIN-rail.

1. Push down the computer by the top side with both hands.

Then the DIN-rail can be parted from the computer.



2. Completely dismount the computer off the DIN-rail by lifting the computer's bottom side.

3.6. Ground the Computer

Follow the instructions below to ground the computer onto land. Be sure to follow every grounding requirement in your place.

Warning Whenever installing the unit, the ground connection must always be made first of all and disconnected lastly.

- 1. See the illustration below. Remove the ground screw from the bottom-left of the rear panel.
- 2. Attach a ground wire to the rear panel with the screw.



3.7. Wire the DC-Input Power Source

Warning Only trained and qualified personnel are allowed to install or replace this equipment.

Follow the instructions below for connecting the computer to a DC-input power source.

- 1. Before wiring, make sure the power source is disconnected.
- 2. Locate the terminal block that shipped in the accessory box with your computer.
- 3. Using the wire-stripping tool, strip a short piece of insulation from the output wires of the DC power source. The wire guage must be in the range between 14-22 AWG.
- 4. Identify the positive and negative feed positions for the terminal block connection. See the symbols printed on the rear panel indicating the polarities and DC-input power range in voltages.
- 5. Insert the exposed wires into the terminal block plugs. Only wires with insulation should extend from the terminal block plugs. Note that the polarities between the wires and the terminal block plugs must be positive to positive and negative to negative.
- 6. Use a slotted screwdriver to tighten the captive screws. Plug the terminal block firmly, which wired, into the receptacle on the rear panel.





terminal block



4.1. Before Installation

After everything aforementioned is done, proceed to install the necessary drivers and the application so the computer can function for you. The following instructions take Windows XP as the exemplary OS. Different OS may vary slightly regarding driver/AP installation, but generally they are similar. Note to install the drivers as the sequece below:

$Chipset {\rightarrow}. NET \ Framework {\rightarrow} VGA {\rightarrow} Audio {\rightarrow} LAN {\rightarrow} ME$

Follow This Procedure to install all necessary pieces of software in most cases to prevent errors.

Find the drivers & AP for Windows XP and Windows 7 on the CD that goes with your purchase. The paths to find them on CD are tabulated as below.

Windows XP

Driver	Path
Chipset	\CHIPSET\INTEL\XP 32 64 WIN7 32 64 SERIES
VGA	\GRAPHICS\INTEL\XP 32
LAN	\ETHERNET\XP 32
Audio	\AUDIO\REALTEK\XP 32 64
ME	
.NET Framework	NET FRAMEWORK

Windows 7 32-bit

Driver	Path
Chipset	\CHIPSET\INTEL\XP_32_64_WIN7_32_64_SERIES
VGA	\GRAPHICS\INTEL\WIN7 32
LAN	\ETHERNET\WIN7 32
Audio	\AUDIO\REALTEK\WIN7 32 64
ME	\ME

Windows 7 64-bit

Driver	Path
Chipset	\CHIPSET\INTEL\XP_32_64_WIN7_32_64_SERIES
VGA	\GRAPHICS\INTEL\WIN7 64
LAN	\ETHERNET\WIN7_64
Audio	\AUDIO\REALTEK\WIN7 32 64
ME	\ME

4.2. Install Drivers

4.2.1. Chipset

1. Run the executable file "setup.exe" at the folder \CHIPSET\INTEL\ XP_32_64_WIN7_32_64_SERIES as described in <u>4.1. Before Installation</u> on page <u>38</u>.

The installation wizard then opens. Click Next to proceed.



2. Read the license agreement and click **Yes** to proceed.



3. Read the readme file and click **Next** to proceed.



The installation wizard then starts with some setup operations.

intel
Root Port 1 - 1C10 Root Port 5 - 1C18 Root Port 7 - 1C1C roller - 1C49
=
Next

4. Once the setup operations are through, click **Next** to proceed.



5. Click **Finish** to finish and quit the driver installation.



4.2.2. .Net Framework

1. Run the executable file "dotnetfx35.exe" at the folder \NET Framework 3.5 as described in <u>4.1. Before Installation</u> on page <u>38</u>.

Files extraction is then triggered for the driver installation.

Extracting Files		×
Extracting File: To Directory:	.\setupres.dll d:\15e03a837f8c1222186dc7e5b18b	

Once the files extraction is through, the installation wizard opens.

2. Select I have read and ACCEPT the terms of the License Agreement and click Install to proceed.

🤯 Microsoft .NET Framewor	k 3.5 Setup	_	
Welcome to Setup	.Nicrosc	t Framewo	ork
Be sure to carefully read and und license terms. You must accept th MICROSOFT SOF LICENSE TERMS	erstand all the rights and restri e license terms before you can TWARE SUPPLE	tions described in the install the software.	
Press the Page Down key to see n I have read and ACCEPT the to I DO NOT ACCEPT the terms o	nore text. erms of the License Agreement f the License Agreement	Pri	nt
Send information about my set Details regarding the <u>data collecti</u>	up experiences to Microsoft Cc on policy	rporation.	
Download File Size:	60 MB		
Download Time Estimate:	2 hr 27 min (56 kbps) 16 min (512 kbps)		
		Install > Can	cel

3. The driver installation then starts and progresses.



4. Once the installation is through, click **Exit** to finish and quit the installation.



4.2.3. VGA

1. Run the executable file "setup.exe" at the folder \GRAPHICS\INTEL\XP_32 as described in <u>4.1. Before Installation</u> on page <u>38</u>.

The installation wizard then opens.

🔊 Intel(R) Graphics Driver So	oftware - InstallShield Wizard	×
	Production Version Releases Microsoft Windows XP* Package: 145148 Graphics: 6.14.10.5394 Display Audio Driver: 5.14.00.3074 November 28,2011 NOTE: This document refers to systems containing to following Intel(R) processors:	
	<back next=""> Cancel</back>	

2. Click Next to proceed.

The installation wizard then starts to extract the files required for the installation.

Extracting Files	ontware - mstat	ionieta v	12414	
The contents of this packag	e are being extracte	ed.		
Please wait while the InstallS Graphics Driver Software on	ihield Wizard extrac your computer. Th	ts the files r s may take	needed to inst a few moment	all Intel(R) ts.
Extracting hkcmd.exe				
Extracting hkmd.exe				

3. Once the files extraction is through, click **Next** to proceed.



4. Read the license agreement and click **Yes** to proceed.



5. Read the readme file and click **Next** to proceed.



Setup then starts and progresses.



6. Once the setup is through, click **Next** to proceed.



7. Select Yes, I want to restart this computer now and click Finish.



4.2.4. Audio

 Run the executable file "XP_2000 WDM_R261 32_64 bit.exe" at the folder \AUDIO\REALTEK\XP_32_64 as described in <u>4.1. Before Installation</u> on page <u>38</u>.

The install wizard then opens and starts to extracts the files needed for driver installation.

🔉 Realtek HD Audio - InstallShield Wizard 🛛 🗙
Extuacting Files The contents of this package are being extracted.
Please wait while the InstallShield Wizard extracts the files needed to install Realtek HD Audio on your computer. This may take a few moments.
Extracting AMBFilt.sys
InstallShield

2. Once the file extraction is though, the install wizard prompts to install the audio driver. Click **Next** to proceed.



The installation then starts, progresses and finishes.



3. Select **Yes**, **I** want to restart my computer now. and click **Finish** button to restart the system to immediately apply the change, or select **No**, **I** will restart my computer later.



4.2.5. LAN

1. Run the executable file "PROWin32.exe" at the folder \ETHERNET\XP_32 as described in <u>4.1. Before Installation</u> on page <u>38</u>.

Files extraction then starts and progresses.

🛃 DriverInstaller - InstallShield Wizard		X
Extracting Files The contents of this package are being ex	xtracted.	44
Please wait while the InstallShield Wizard (DriverInstaller on your computer. This ma	extracts the files needed to in y take a few moments.	nstall
Extracting WdfCx32F.dll		
InstallShield	< Back Next >	Cancel

2. Once the files extraction is through, click **Next** to proceed.



3. Read the agreement. Select I accept the terms in the License agreement and click Next to proceed.

License Agreement Please read the following license agreement carefully.	(intel)
INTEL SOFTWARE LICENSE AGREE	MENT
IMPORTANT - READ BEFORE COPYING, INSTAL	LING OR USING.
1	
Do not copy, install, or use this software and any assoc (collectively, the "Software") provided under this licens ("Agreement") until you have carefully read the followir By copying, installing, or otherwise using the Software, the terms of this Agreement. If you do not agree to the t do not copy, install, or use the Software.	iated materials e agreement ig terms and conditions. you agree to be bound by terms of this Agreement,
Do not copy, install, or use this software and any assoc (collectively, the "Software") provided under this licens ("Agreement") until you have carefully read the followin By copying, installing, or otherwise using the Software, the terms of this Agreement. If you do not agree to the t do not copy, install, or use the Software. ③ I accept the terms in the license agreement	iated materials e agreement ng terms and conditions. you agree to be bound by terms of this Agreement, Print
Do not copy, install, or use this software and any assoc (collectively, the "Software") provided under this licens ("Agreement") until you have carefully read the followin By copying, installing, or otherwise using the Software, the terms of this Agreement. If you do not agree to the t do not copy, install, or use the Software. ③ I accept the terms in the license agreement) I do not accept the terms in the license agreement	iated materials is agreement og terms and conditions. you agree to be bound by terms of this Agreement, Print

4. Select the program features to install and click **Next** to proceed.

ntel(R) Network Connections	×
Setup Options Select the program features you want installed.	(intel)
Install:	
Intel(R) PROSet for Windows* Device Manager Advanced Network Services Intel(R) Network Connections SNMP Agent	
Feature Description Drivers for all wired Intel Network Connections	
< Back N	Vext > Cancel

5. Click **Install** to proceed.



The driver installation then starts and progresses.

🛃 Intel(R)	Network Connections - InstallShield Wizard	
Installing The proc	Intel(R) Network Connections ram features you selected are being installed.	(intel)
1 5	Please wait while the InstallShield Wizard installs Intel(R) Network Connections. This may take several minutes. Status: Compling MOFs	
InstallShield	< Back Next >	Cancel

6. Once the driver installation is through, click **Finish** to finish and quit the installation.



4.2.6. Intel[®] Management Engine

Intel[®] Management Engine (Intel[®] ME) is a microcontroller embedded in the PCH chipset. It uses host-invisible resources to runs the management firmware to deliver capable management. The firmware is digitally signed and authenticated by Intel[®] ME before it is executed so the connection to an authentic device can be sure when a remote management console connects to a client via the network.

Intel[®] ME-capable chipsets and associated firmware formed the architecture of Intel[®] AMT. When a remote management console connects to a client through the network, the Intel[®] ME firmware interacts with the host OS drivers through virtualized PCI devices to deliver the functionality even in the absence of the OS (the "out-of-band" capability). This capability to function even in low host power states (S3, S4 and S5) requires Intel[®] ME to be able to manage all the resources it needs independent of the host, which is supported by the integrated hardware and software solutions that the PCH chipset brings.

The PCH chipset has an management engine to enable the platform manageability and the key components for the manageability including the interface to LAN and SPI flash components through its integrated Gigabit Ethernet controller (GbE) and SPI flash controller. Intel[®] Management Engine includes the following manageability functions:

- **IDE-R** for remote boot and software installation
- SOL redirecting keyboard and text-based display over network connection
- **KVM** redirecting keyboard, video and mouse over network connection, supersedes SOL when support.
- **ASF** Alert Specification Format, the PC industry specification.

See also <u>5.2.5. AMT Configuration</u> on page <u>68</u>.

4.2.6.1. Driver Installation

To make $\mathsf{Intel}^{\texttt{®}}$ ME features work correctly on the computer, install the driver by following the steps below.

- 1. Run the executable file "Setup.exe" at the folder \ME as described in <u>4.1.</u> <u>Before Installation</u> on page <u>38</u>.
- 2. Follow the onscreen instructions to go through the installation.



The BIOS Setup utility for ELIT-1650 is featured by American Megatrends Inc to configure the system settings stored in the system's BIOS ROM. The BIOS is activated once the computer powers on. When the computer is off, the battery on the main board supplies power to BIOS RAM.

To enter the BIOS Setup utility, press-and-hold the "Delete" key upon powering on the computer.

Aptio Setup Utility - Copyright (C) 2010 American Megatrends, Inc.		
Main Advanced Chipset Boot	Security Save & Exit	
BIOS Information BIOS Vendor Core Version Compliency BIOS Version Build Date and Time System Date System Time	American Megatrends 4.6.4.0 UEFI 2.1 ELit-1650 1.00 08/03/2012 17:35:42 [Thu 10/18/2012] [17:14:06]	Set the Date. Use Tab to switch between Data elements.
Access Level	Administrator	 →←: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit
Version 2.10.1208. Copyright (C) 2010 American Megatrends, Inc.		

The featured settings are:

Menu	Description
Main	See <u>5.1. Main</u> on page <u>58</u> .
Advanced	See <u>5.2. Advanced</u> on page <u>60</u> .
Chipset	See <u>5.3. Chipset</u> on page <u>78</u> .
Boot	See <u>5.4. Boot</u> on page <u>93</u> .
Security	See <u>5.5. Security</u> on page <u>93</u> .
Save & Exit	See <u>5.6. Save & Exit</u> on page <u>95</u> .

Key Commands

The BIOS Setup utility relies on a keyboard to receive user's instructions. Hit the following keys to navigate within the utility and use the utility.

Keystroke	Function
$\leftarrow \rightarrow$	Moves left/right between the top menus.
$\downarrow \uparrow$	Moves up/down between highlight items.
Enter	Selects an highlighted item/field.
Esc	 On the top menus Use Esc to quit the utility without saving changes to CMOS. (The screen will prompt a message asking you to select OK or Cancel to exit discarding changes. On the submenus Use Esc to quit current screen and return to the top menu.
Page Up / +	Increases current value to the next higher value or switches between available options.
Page Down / -	Decreases current value to the next lower value or switches between available options.
F1	Opens the Help of the BIOS Setup utility.
F10	Exits the utility saving the changes that have been made. (The screen then prompts a message asking you to select OK or Cancel to exit saving changes.)

Note: Pay attention to the "WARNING" that shows at the left pane onscreen when making any change to the BIOS settings.

5.1. Main

The $\ensuremath{\text{Main}}$ menu features the settings of $\ensuremath{\text{System}}$ $\ensuremath{\text{Date}}$ and $\ensuremath{\text{System}}$ $\ensuremath{\text{Time}}$ and also displays some BIOS info.

Aptio Setup Utilit Main Advanced Chipset	y - Copyright (C) 2010 America Boot Security Save & Exit	an Megatrends, Inc.
BIOS Information BIOS Vendor Core Version Compliency BIOS Version Build Date and Time System Date System Time	American Megatrends 4.6.4.0 UEFI 2.1 ELit-1650 1.00 08/03/2012 17:35:42 [Thu 10/18/2012] [17:14:06]	Set the Date. Use Tab to switch between Data elements.
Access Level	Administrator	 →←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit

The BIOS info displayed are:

Info Item	Description
BIOS Vendor	Delivers the provider of the BIOS Setup utility.
Core Version	Delivers the version info of the core.
Compliency	Delivers the UEFI support.
Project Version	Delivers the computer's BIOS version info.
Build Date and Time	Delivers the date and time the BIOS Setup utility was made/updated.
Access Level	Delivers the level that the BIOS is being accessed at the moment.

The featured settings are:

Setting	Description
System Time	Sets system time.
System Date	Sets system date.

5.2. Advanced

The **Advanced** menu configures the system's Super IO chip.

Aptio Setup Utility - Copyright (C) 2010 American Megatrends, Inc.		
Main Advanced Chipset Bo	ot Security Save & Ex	lit
Legacy OpROM Support Launch PXE OpROM Launch Storage OpROM	[Disabled] [Enabled]	Enable or Disable Boot Option for Legacy Network Devices.
 ACPI Settings CPU Configuration SATA Configuration Intel Anti-Theft Technology Configuration AMT Configuration USB Configuration H/W Monitor -CPU Board Second Super IO Configuration Super IO Configuration H/W Monitor -I/O Board Sandybridge PPM Configuration 		
		 →+: Select Screen ↓ ↑: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit
Version 2.10.1208. Copyright (C) 2010 American Megatrends, Inc.		

The featured settings and submenus are:

Setting	Description	
Launch PXE OpROM	Enables/disables the boot option for legacy network devices.▶ Disabled is the default.	
Launch Storage OpROM	 Enables/disables the boot option for the legacy mass storage devices with Option ROM. Enabled is the default. 	
ACPI Settings	See 5.2.1. ACPI Settings on page 61.	
CPU Configuration	See 5.2.2. CPU Configuration on page 62.	
SATA Configuration	See 5.2.3. SATA Configuration on page 63.	
Intel Anti-Theft Technology Configuration	y See <u>5.2.4. Intel® Anti-Theft Technology</u> Configuration on page <u>67</u> .	
AMT Configuration	See <u>5.2.5. AMT Configuration</u> on page <u>68</u> .	
USB Configuration	See 5.2.6. USB Configuration on page 71.	

H/W Monitor -CPU Board	See <u>5.2.7. H/W Monitor -CPU Board</u> on page <u>72</u> .
Second Super IO Configuration	See <u>5.2.8. Second Super IO Configuration</u> on page <u>72</u> .
Super IO Configuration	See <u>5.2.9. Super IO Configuration</u> on page <u>75</u> .
H/W Monitor -I/O Board	See <u>5.2.10. H/W Monitor -I/O Board</u> on page <u>76</u> .
Sandybridge PPM Configuration	See <u>5.2.11. Sandybridge PPM Configuration</u> on page <u>76</u> .

5.2.1. ACPI Settings

ACPI Settings enable users to change the system's ACPI (Advanced Configuration and Power Interface). The featured settings are:

Setting	Description		
Enable ACPI Auto Configuration	 Enables/disables BIOS' auto configuration of ACPI. Disabled is the default. 		
Enable Hibernation	 Enables/disables the system to/from hibernation (OS/ S4 Sleep State). This setting is only available when Enable ACPI Auto Configuration is disabled. This option may not be effective with some OS. This setting is enabled by default. 		
ACPI Sleep State	 Sets the highest ACPI sleep state that system enters when the suspend button is hit. This setting is only available when Enable ACPI Auto Configuration is disabled. Options available are Suspend Disabled, S1 (CPU Stop Clock) and S3 (Suspend to RAM). S1 (CPU Stop Clock) is the default. 		
Lock Legacy Resources	 Enables/disables locking legacy resources. Disabled is the default. 		
Power-Supply Type	 Sets the power-supply type. ▶ Options available are AT (default) and ATX. 		

5.2.2. CPU Configuration

Select **CPU Configuration** to identify the CPU and its capabilities by running a report listing the CPU's model name, processor stepping, processor speed, microcode revision, max. processor speed, min. processor speed, processor cores, Intel[®] Hyper-Threading Technology support, EMT64 support and so on.

And CPU Configuration features two	o settings as below:
------------------------------------	----------------------

Setting	Description
Limit CPUID Maximum	 Sets whether the processor should limit the maximum CPUID input value to 03h when the operating system queries it upon startup. Select Enabled to allow a processor with Intel[®] Hyper-Threading technology to work with an operating system that doesn't support it. Disabled is the default.
Intel Virtualization Technology	 Enables/disables Intel[®] Virtualization Technology (IVT) extensions that allow multiple operating systems to simultaneously run on the same computer by creating virtual machine, each running its own x86 operating system. Disabled is the default.
5.2.3. SATA Configuration

SATA Configuration delivers SATA device(s) information and features the settings to control SATA device(s). Featured settings are:

Setting	Description		
SATA Controller(s)	Enables/disables SATA device(s).Enabled is the default.		
SATA Mode Selection	 Configures how SATA controller(s) operate. Options available are IDE (default) and AHCI. 		
Aggressive LPM Support	 Enables/disables PCH to aggressively enter LPM (link power management), a power-saving state that helps the disk save power by setting a SATA link to the disk to low-power state when the disk idles (, which means there is no input/output). Enabled is the default. This setting is available only when SATA Mode Selection is set to AHCI. 		
	This is a submer (Redundant Arra ROM) and RST This subme Selection is	u to feature the settings regarding RAID y of Inexpensive Disks), OROM (Option (Rapid Storage Technology). nu is available only when SATA Mode set to AHCI .	
	i ne teatured set	tings are:	
	Setting	tings are: Description	
	Setting RAID0	tings are: Description See 5.2.3.1, RAID0 on page 64.	
	Setting RAID0 RAID1	tings are: Description See 5.2.3.1. RAID0 on page 64. See 5.2.3.2. RAID1 on page 64.	
	RAID1 RAID1	tings are: Description See 5.2.3.1. RAID0 on page 64. See 5.2.3.2. RAID1 on page 64. See 5.2.3.3. RAID10 on page 64.	
Software Feature	RAID0 RAID1 RAID1 RAID5	tings are: Description See 5.2.3.1. RAID0 on page 64. See 5.2.3.2. RAID1 on page 64. See 5.2.3.3. RAID10 on page 64. See 5.2.3.4. RAID5 on page 64.	
Software Feature Mask Configuration	RAID0 RAID1 RAID1 RAID5 Intel Rapid	tings are: Description See 5.2.3.1. RAID0 on page 64. See 5.2.3.2. RAID1 on page 64. See 5.2.3.3. RAID10 on page 64. See 5.2.3.4. RAID5 on page 64. See 5.2.3.5. Intel Rapid Recovery	
Software Feature Mask Configuration	SettingRAID0RAID1RAID10RAID5Intel RapidRecoveryTechnology	tings are: Description See 5.2.3.1. RAID0 on page 64. See 5.2.3.2. RAID1 on page 64. See 5.2.3.3. RAID10 on page 64. See 5.2.3.4. RAID5 on page 64. See 5.2.3.5. Intel Rapid Recovery Technology on page 65.	
Software Feature Mask Configuration	Ine featured set Setting RAID0 RAID1 RAID5 Intel Rapid Recovery Technology OROM UI and	tings are: Description See 5.2.3.1. RAID0 on page 64. See 5.2.3.2. RAID1 on page 64. See 5.2.3.3. RAID10 on page 64. See 5.2.3.4. RAID5 on page 64. See 5.2.3.5. Intel Rapid Recovery Technology on page 65. See 5.2.3.6. OROM UI and Banner on	
Software Feature Mask Configuration	Ine featured set Setting RAID0 RAID1 RAID5 Intel Rapid Recovery Technology OROM UI and Banner	tings are: Description See 5.2.3.1. RAID0 on page 64. See 5.2.3.2. RAID1 on page 64. See 5.2.3.3. RAID10 on page 64. See 5.2.3.4. RAID5 on page 64. See 5.2.3.5. Intel Rapid Recovery Technology on page 65. See 5.2.3.6. OROM UI and Banner on page 65.	
Software Feature Mask Configuration	Ine featured set Setting RAID0 RAID1 RAID5 Intel Rapid Recovery Technology OROM UI and Banner HDD Unlock	tings are: Description See 5.2.3.1. RAID0 on page 64. See 5.2.3.2. RAID1 on page 64. See 5.2.3.3. RAID10 on page 64. See 5.2.3.4. RAID5 on page 64. See 5.2.3.5. Intel Rapid Recovery Technology on page 65. See 5.2.3.6. OROM UI and Banner on page 65. See 5.2.3.7. HDD Unlock on page 65.	
Software Feature Mask Configuration	Setting RAID0 RAID1 RAID10 RAID5 Intel Rapid Recovery Technology OROM UI and Banner HDD Unlock LED Locate	tings are: Description See 5.2.3.1. RAID0 on page 64. See 5.2.3.2. RAID1 on page 64. See 5.2.3.3. RAID10 on page 64. See 5.2.3.4. RAID5 on page 64. See 5.2.3.5. Intel Rapid Recovery Technology on page 65. See 5.2.3.6. OROM UI and Banner on page 65. See 5.2.3.7. HDD Unlock on page 65. See 5.2.3.8. LED Locate on page 65.	
Software Feature Mask Configuration	Ine featured set Setting RAID0 RAID1 RAID5 Intel Rapid Recovery Technology OROM UI and Banner HDD Unlock LED Locate IRRT Only on	tings are: Description See 5.2.3.1. RAID0 on page 64. See 5.2.3.2. RAID1 on page 64. See 5.2.3.3. RAID10 on page 64. See 5.2.3.4. RAID5 on page 64. See 5.2.3.5. Intel Rapid Recovery Technology on page 65. See 5.2.3.6. OROM UI and Banner on page 65. See 5.2.3.7. HDD Unlock on page 65. See 5.2.3.8. LED Locate on page 65. See 5.2.3.9. IRRT Only on eSATA on	

Serial ATA Port 1	Controls Serial features the follo	ATA features. Each Serial ATA port wing setting:
	Setting	Description
	Port #	See <u>5.2.3.10. Port # on page 65</u> .
Serial ATA Port 2	Hot Plug	See <u>5.2.3.11. Hot Plug</u> on page <u>66</u> .
	External	See 5.2.3.12. External SATA on page
	SATA	<u>66</u> .
Sorial ATA Port 3	SATA Device	See 5.2.3.13. SATA Device Type on
Senai AIA Fort S	Туре	page <u>66</u> .
	Spin Up	See 5.2.3.14. Spin Up Device on page
Serial ATA Port 4	Device	<u>66</u> .
	 These settin 	gs are available only when SATA Mode
	Selection is	set to AHCI.

5.2.3.1. RAID0

Enables/disables RAID 0 scheme, which features blocks striped, no mirror and no parity.

Enabled is the default.

5.2.3.2. RAID1

Enables/disables RAID 1 scheme, which features blocks mirrored, no stripe and no parity.

Enabled is the default.

5.2.3.3. RAID10

Enables/disables RAID 10 scheme, which features blocks mirrored and striped.

Enabled is the default.

5.2.3.4. RAID5

Enables/disables RAID 5, which features block striped and distributed parity.

Enabled is the default.

5.2.3.5. Intel Rapid Recovery Technology

Enables/disables Intel[®] Rapid Recovery Technology, which auto-switches the storage to the mirrored disk in case the primary disk fails. IRRT also duplicates all data on the mirrored disk back to the newly installed primary disk.

Enabled is the default.

5.2.3.6. OROM UI and Banner

Controls the behavior of Intel[®] RST OROM UI and the banner splash screen that displays during POST at system boot-up.

- Select **Enabled** to show the OROM UI of SATA devices.
- Select **Disabled** to show neither OROM banner nor information if all disks and RAID volumes are normal.

5.2.3.7. HDD Unlock

If the HDD password unlock is enabled in the OS, select **Enabled** (, which is also the default).

5.2.3.8. LED Locate

If the LED/SGPIO hardware is attached and the ping to locate the feature is enabled in the OS, select **Enabled** (, which is also the default).

5.2.3.9. IRRT Only on eSATA

Select **Enabled** to have only the IRRT volume span the internal and eSATA drives.

Select **Disabled** to have any RAID volume span the internal and eSATA drives.

Enabled is the default.

5.2.3.10. Port

Enables/disables the SATA port.

Enabled is the default.

5.2.3.11. Hot Plug

Sets whether to make the SATA port an hot pluggable one.

Disabled is the default.

5.2.3.12. External SATA

Enables/disables external SATA support.

Disabled is the default.

5.2.3.13. SATA Device Type

Defines whether the SATA port is connected to a **Solid State Drive** or **Hard Disk Drive**.

Hard Disk Drive is the default.

5.2.3.14. Spin Up Device

For the platforms with numerous Serial ATA hard disk drives, the power issue regarding the electrical current load during system power-up is often critical. This setting enables/disables "Staggered Spin Up", which provides a simple mechanism for SATA HBAs (host bus adapters) to sequence disk drive initialization and spin-up.

Disabled is the default.

5.2.4. Intel[®] Anti-Theft Technology Configuration

The computer is Intel[®] Anti-Theft Technology-enabled. When working with an Intel[®] AT-enabled service, the technology can keep the data stored in the computer safe and secure when the computer is lost or stolen.

See <u>http://www.intel.com/content/www/us/en/architecture-and-technology/anti-theft/anti-theft-service-providers.html</u> to know the Intel[®] AT service providers.

The submenu features the following settings regarding Intel® AT:

Setting	Description
Intel Anti-Theft Technology	 Enables/disables Intel[®] AT in BIOS for testing only. Disabled is the default.
Intel Anti-Theft Technology Recovery	 Sets how many times is recovery attempted. 3 is the default.
Enter Intel AT Suspend Mode	Sets whether the platform can enter Intel [®] AT suspend mode. Disabled is the default.

5.2.5. AMT Configuration

Intel[®] Active Management Technology (Intel[®] AMT) is a hardware-based solution that uses out-of-band communication for basic management of client systems, which allows a system administrator to monitor and manage the computers and other network equipment by remote control even if the hard drive is crashed, the system is turned off or the operation system is locked.

This submenu features the necessary BIOS extension settings as listed below to make use of Intel $^{\ensuremath{\mathbb{R}}}$ AMT.

Setting	Description			
Intel AMT	 Enables/disables Intel[®] Active Management Technology BIOS extensions. iAMT hardware is always enabled. This setting only controls BIOS extension execution. Enabled is the default. When enabled, additional firmware is required in the SPI device. 			
Intel AMT Setup Prompt	 Sets whether to show the prompt to enter Intel[®] AMT setup during POST. Enabled is the default. Select Disabled to disable accessing Intel[®] AMT setup. 			
BIOS Hotkey Pressed	 Enables/disables the hotkey for AMT BIOS setting, which is normally Ctrl + P. When enabled, AMT setup is presented each time the system boots up. Disabled is the default. 			
MEBx Selection Screen	 Enables/disables MEBx (Intel[®] Management Engine BIOS extension) selection screen. Disabled is the default. 			
Verbose MEBx Output	 Enables/disables verbose MEBx output. Enabled is the default. 			
Hide Un-Configure ME Confirmation	 Enables/disables the password confirmation when undoing ME configuration. Disabled is the default. 			

MEBx Debug Message Output	 Enables/disables MEBx debug message output. Disabled is the default. 		
Un-configure ME	 Enables/disables undoing ME configuration. Disabled is the default. 		
Intel AMT Password Write Enabled	 Sets whether to make Intel[®] AMT password writable. Select Enabled to make the password writable, which is the default. 		
AMT Wait Timer	Sets the time to wait before sending ASF_GET_ BOOT_OPTIONS. Enabled is the default.		
ASF	 Enables/disables Alert Specification Format, a DMTF (Distributed Management Task Force) standard for remote monitoring, management and control of computer system in both OS-present and OS-absent environments. Enabled is the default. 		
Activate Remote Assistance Process	Enables/disables CIRA (Client-Initiated Remote Access) boot. Disabled is the default.		
USB Configure	 Enables/disables USB configure function. Enabled is the default. 		
PET Progress	 Sets whether to receive PET (Platform Event Traps) or not. PET is an event arising directly from platform firmware (BIOS) or platform hardware (ASIC, chipset or microcontroller) independently of the state of the operating system or system management hardware. Enabled is the default. 		
Intel AMT SPI Protected	Enables/disables the write protect of Intel [®] AMT SPI (Serial Peripheral Interface). Disabled is the default.		

AMT CIRA Timeout	 Customizes the timeout for the establishment of MPS connection. This setting is only available when Activate Remote Assistance Process is enabled. Set it to 0 to use the default timeout value of 60 seconds. Set it to 255 to have MEBx wait until the connection succeeds. CIRA means "Client Initiated Remote Access".
WatchDog	 Enables/disables watchdog timer. Disabled is the default.
OS Timer	 Defines OS watchdog timer. This setting is only available when WatchDog is enabled.
BIOS Timer	 Defines BIOS watchdog timer. This setting is only available when WatchDog is enabled.

5.2.6. USB Configuration

USB Configuration displays the info of the connected USB devices and sets USB parameters. The featured settings are:

Setting	Description			
Legacy USB Support	 Enables/disables legacy USB support. Options available are Enabled (default), Disabled and Auto. Select Auto to disable legacy support if no USB device are connected. Select Disabled to keep USB devices available only for EFI applications. 			
EHCI Hand-off	Enables/disables a workaround for the operating systems that have no EHCI hand-off support. Disabled is the default. 			
USB Beep Switch	Enables/disables USB beep sound. Enabled is the default.			
USB transfer time-out	 Sets the timeout for Control/Bulk/Interrupt transfers. Options available are 1 sec, 5 sec, 10 sec and 20 sec (default). 			
Device reset time-out	 Sets the time for POST to wait for a USB device to start. Options available are 10 sec, 20 sec (default), 30 sec and 40 sec. 			
Device power-up delay	 Sets the maximum time elapses before a USB device reports itself to the controller. Select Auto (default) to apply a 100 ms delay to the root port and make the hub port use the delay from Hub descriptor. Select Manual to customize a delay from 1 to 40 seconds. 			

5.2.7. H/W Monitor -CPU Board

H/W Monitor -CPU Board monitors the CPU board's hardware status. Select it to run a report of the info including CPU temperature, system temperature, VCC, VCORE and so on.

5.2.8. Second Super IO Configuration

Second Super IO Configuration is a submenu to configure the Super IO chip Fintek F81216. It configures the serial port 3, 4, 5 and 6 on the system. The featured settings are:

Setting	Description	
	The featured settings are:	
	Setting	Description
	Serial Port	Enables/disables the serial port.Enabled is the default.
Serial Port 3 Configuration	Change Settings	 Sets the optimal IO address and IRQ info for the serial port, or leaves it on BIOS autodetection. Options available are: Auto IO=3E8h; IRQ=10; (default) IO=3F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=3E8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12;

	The featured settings are:	
	Setting	Description
	Serial Port	 Enables/disables the serial port. Enabled is the default.
Serial Port 4 Configuration	Change Settings	 Sets the optimal IO address and IRQ info for the serial port, or leaves it on BIOS autodetection. ▶ Options available are: Auto IO=2E8h; IRQ=10; (default) IO=3F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12;
	The featured settings are:	
	Setting	Description
	Serial Port	 Enables/disables the serial port. Enabled is the default.
Serial Port 5 Configuration	Change Settings	 Sets the optimal IO address and IRQ info for the serial port, or leaves it on BIOS autodetection. Options available are: Auto IO=2E0h; IRQ=10; (default) IO=3F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2F0h; IRQ=3,4,5,6,7,9,10,11,12; IO=2F0h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E0h; IRQ=3,4,5,6,7,9,10,11,12;
	COM5 RS485 AutoFlow	Enables/disables RS485 autoflow control for COM5. ► Disabled is the default.

	The featured settings are:	
	Setting	Description
	Serial Port	 Enables/disables the serial port. Enabled is the default.
Serial Port 6 Configuration	Change Settings	 Sets the optimal IO address and IRQ info for the serial port, or leaves it on BIOS autodetection. ▶ Options available are: Auto IO=2F0h; IRQ=10; (default) IO=3F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2F0h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E0h; IRQ=3,4,5,6,7,9,10,11,12;
	COM6 RS485 AutoFlow	Enables/disables RS485 autoflow control for COM6. ► Disabled is the default.

5.2.9. Super IO Configuration

Super IO Configuration is a submenu to control the system's Super IO chip Fintek F71869E. It configures the serial port 1 and 2 on the system. The featured settings are:

Setting	Description	
Serial Port 1 Configuration	The featured settings are:	
	Setting	Description
	Serial Port	 Enables/disables the serial port. Enabled is the default.
	Change Settings	 Sets the optimal IO address and IRQ info for the serial port, or leaves it on BIOS autodetection. ▶ Options available are: Auto (default) IO=3F8h; IRQ=4; IO=3F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12;
	The featured	settings are:
	Setting	Description
	Serial Port	 Enables/disables the serial port. Enabled is the default.
Serial Port 2 Configuration	Change Settings	 Sets the optimal IO address and IRQ info for the serial port, or leaves it on BIOS autodetection. ▶ Options available are: Auto (default) IO=2F8h; IRQ=3; IO=3F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=3E8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12;
Power On After Power Fail	Defines the st resumed after ► Options a On.	ate for the computer to go to when power is a power failure. vailable are Power Off (default) and Power

5.2.10. H/W Monitor -I/O Board

H/W Monitor -I/O Board monitors the carrier board's hardware status. Select it to run a report of various voltage info.

5.2.11. Sandybridge PPM Configuration

This submenu controls processor power management by the following settings:

Submenu	Description
EIST	Enables/disables EIST (Enhanced Intel SpeedStep [®] Technology), which enables the system to dynamically adjust processor voltage and core frequency to reduce power consumption and heat production. ► Enabled is the default.
CPU C3 Report	 Enables/disables CPU C3 (ACPI C2) report to the OS. Enabled is the default.
CPU C6 Report	Enables/disables CPU C6 (ACPI C3) report to the OS. ► Enabled is the default.
CPU C7 Report	 Enables/disables CPU C7 (ACPI C3) report to the OS. Enabled is the default.
Long duration power limit	 Sets the power limit when Intel[®] Turbo Boost Technology is applied during a long duration of time. Intel[®] Turbo Boost Technology allows the processor to operate at a power level higher than its rated upper power limit (TDP) for short durations. The default setting is 0, which means the factory default.
Long duration maintained	Sets the time to maintain long duration power.The default setting is 28 milliseconds.

Short duration power limit	 Sets the power limit when Intel[®] Turbo Boost Technology is applied during a short duration of time. After that, the Long Duration Power Limit will be honored. The default setting is 0, which means the factory default.
TCC active offset	 Sets the offset (in degrees Celsius) that activates the TCC (Thermal Control Circuit), a thermal protection mechanism for Intel[®] Turbo Boost Technology operation since ACPI passive throttling states will pull the processor out of turbo operation when triggered. The default setting is 0, which means the factory default.

5.3. Chipset

The **Chipset** menu controls the system's chipset.



The featured submenu are **System Agent (SA) Configuration** and **PCH-IO Configuration**, which are covered in the following sections.

Submenu overview:

Submenu	Description
System Agent (SA) Configuration	See <u>5.3.1. System Agent (SA) Configuration</u> on page <u>79</u> .
PCH-IO Configuration	See 5.3.2. PCH-IO Configuration on page 87.

5.3.1. System Agent (SA) Configuration

This submenu configures **System Agent (SA)** parameters. The featured settings are:

Setting / Submenu	Description
CHAP Device (B0:D7:F0)	 Enables/disables SA CHAP device. Disabled is the default.
Thermal Device (B0:D4:F0)	 Enables/disables SA thermal device. Disabled is the default.
Enable NB CRID	 Enables/disables NB (northbridge) CRID (Compatible Revision ID) workaround. CRID makes it flexible for the BIOS to load OS drivers optimized for a previous revision of the silicon instead of the current revision of the silicon in order to reduce drivers updates and minimize change to the OS image for the minor optimizations for the silicon such as yield improvement or the feature enhancement reasons that do not negatively impact the OS driver functionality. Disabled is the default.
Graphics Configuration	See 5.3.1.1. Graphics Configuration on page 80.
DMI Configuration	See 5.3.1.2. DMI Configuration on page 82.
NB PCIe Configuration	See 5.3.1.3. NB PCIe Configuration on page 82.
Memory Configuration	See 5.3.1.4. Memory Configuration on page 83.
Memory Thermal Configuration	See <u>5.3.1.5. Memory Thermal Configuration</u> on page <u>86</u> .
GT - Power Management Control	See <u>5.3.1.6. GT - Power Management Control</u> on page <u>86</u> .

5.3.1.1. Graphics Configuration

Select **Graphics Configuration** to view graphics info and accesses graphics settings. The featured settings are:

Setting	Description
Graphics	Sets the graphics turbo IMON current values.
Turbo IMON	Options available are 14 to 31.
Current	31 is the default.
Primary IGFX Boot Display	 Sets the graphics device to activate during POST. This setting has no effect if an external graphics is present. The setting for the secondary boot display will become available depending on your selection. VGA modes are only supported on the primary display. Options available are CRT, DVI (default) and HDMI.
GTT Size	 Sets the size of the GTT, which means "graphics translation table", an I/O memory management unit (IOMMU) used by AGP and PCI Express graphics cards. Options available are 1MB and 2MB (default).
Aperture Size	Sets the aperture size, the maximum amount of system memory available to the graphics port. Deptions available are 128MB , 256MB (default) and 512MB .
DVMT Pre- Allocated	Sets the DVMT 5.0 fixed (pre-allocated) memory size for the internal graphics device. Options available are:0M 32M 64M (default) 96M 128M 160M 192M 224M 256M 288M 320M 352M 384M 416M 448M 480M 512M

	Sets the DVMT 5.0 total memory size for the internal graphics
DVMT Total	device.
	Options available are:
Gfx Memory	128M
	256M (default)
	MAX
Gfx Low Power Mode	Enables/disables graphics low power mode.
	This setting is applicable to SFF (small form factor) only.
	Enabled is the default.

5.3.1.2. DMI Configuration

Use this submenu to control various DMI (Direct Media Interface) features such as the following:

Setting	Description	
DMI VC1 Control	 Enables/disables DMI vc1. "vc" means "virtual channel". Enabled is the default. 	
DMI VCp Control	 Enables/disables DMI vcp. "vc" means "virtual channel". Enabled is the default. 	
DMI VCm Control	 Enables/disables DMI vcm. "vc" means "virtual channel". Enabled is the default. 	
DMI Link ASPM Control	 Enables/disables the Active State Power Management on the southbridge side of the DMI link. Options available are: Disabled, L0s, L1 and L0sL1 (default). 	
DMI Extended Synch Control	 Enables/disables DMI extended synchronization. Disabled is the default. 	
DMI Gen 2	Enables/disables DMI Gen2. Enabled is the default. 	

5.3.1.3. NB PCIe Configuration

Configures northbridge PCI Express Graphics (PEG). Featured settings are:

Setting	Description
PEG0 - Gen X	 Configures PEG0 B0:D1:F0 Gen1-Gen2, or leaves it on BIOS auto-detection. Options available are Auto, Gen1 (default) and Gen2.
PEG1 - Gen X	 Configures PEG1 B0:D1:F1 Gen1-Gen2, or leaves it on BIOS auto-detection. Options available are Auto (default), Gen1 and Gen2.
PEG2 - Gen X	Configures PEG2 B0:D1:F2 Gen1-Gen2. ► Options available are Auto (default), Gen1 and Gen2 .

PEG3 - Gen X	Configures PEG3 B0:D6:F0 Gen1-Gen2. ► Options available are Auto (default), Gen1 and Gen2 .
Always Enable PEG	Enables/disables the PEG slot.Enabled is the default.
PEG ASPM	 Sets ASPM (Active State Power Management) support for the PEG device, or leaves it on BIOS auto-detection. This setting has no effect if the PEG device isn't active at the moment. Options available are: Disabled, Auto (default), ASPM L0s, ASPM L1 and ASPM L0sL1.
De-emphasis Control	Configures the de-emphasis control on PEG. ► Options available are: -6 dB and -3.5 dB (default).

5.3.1.4. Memory Configuration

Select **Memory Configuration** to view the system's memory information that includes memory RC version, memory frequency, total memory, DIMM presence, CAS latency and minimum delay time.

Memory Configuration is also a submenu to configure the memory with the following settings:

Setting	Description
DIMM profile	 Sets the DIMM timing profile to use. Options available are: Default DIMM profile (default), XMP profile 1 and XMP profile 2.
Memory Frequency	 Sets the maximum memory frequency (in MHz), or leaves it on BIOS auto-detection. > Options available are: Auto (default) 1067 1333 1600 1867 2133
ECC Support	 Enables/disables ECC (Error Checking & Correcting) support for the DDR memory. Disabled is the default.

Max TOLUD	 Sets the maximum value of TOLUD (Top of Low Usable DRAM), the lowest address above both the graphics stolen memory and TSEG (Top of Memory Segment). Select Dynamic to auto-adjust TOLUD based on the largest MMIO (memory mapped input/output) length of the installed graphics controller. Options available are: Dynamic (default) 1 GB 1.25 GB 2.25 GB 2.5 GB 2.75 GB 3 GB 3.25 GB
NMode Support	 Sets memory timing parameters, or leaves it on BIOS auto-detection. Options available are: Auto (default) 1N Mode 2N Mode Both 1N Mode and 2N Mode are command rates. Each is the time it takes for a signal to be issued from the memory to a RAM module.
Memory Scrambler	 Enables/disables the support of memory scrambler, which randomizes the content of the memory to complicate data retrieval from the memory. ▶ Options available are: Enabled (default) Disabled
RMT Crosser Support	 Enables/disables RmtCrosserEnable support. Disabled is the default.

MRC Fast Boot	 Enables/disables MRC (Memory Reference Code) fast boot, which restores memory data from the valid NVRAM without hardware training to speed up booting. Options available are: Enabled (default) Disabled
Force Cold Reset	 Force cold reset or choose MRC cold reset mode, when cold boot is required during MRC execution. Note: If ME 5.0MB-sized firmware is present, force cold reset is required. ▶ Options available are: Enabled (default) Disabled
Scrambler Seed Generation Off	 Controls memory scrambler seed generation. Select Enabled to turn off scrambler seed generation. Select Disabled to always generate scrambler seed. (Default)
Memory Remap	Enables/disables remapping the memory above 4G.Enabled is the default.
Channel A DIMM Control	 Sets how to enable the DIMMs on channel A. Options available are: Enable Both DIMMs (default) Disable DIMM0 Disable DIMM1 Disable Both DIMMs
Channel B DIMM Control	 Sets how to enable the DIMMs on channel B. Options available are: Enable Both DIMMs (default) Disable DIMM0 Disable DIMM1 Disable Both DIMMs

5.3.1.5. Memory Thermal Configuration

This submenu configures the memory thermal parameters by the following settings:

Setting	Description
Memory Thermal Management	 Enables/disables memory thermal management. Enabled is the default.
PECI Injected Temperature	 Enables/disables memory temperatures to be injected to the processor via PECI (Platform Environment Controller Interface. Disabled is the default.
EXTTS# via TS-on- Board	 Enables/disables routing TS-on-Board ALERT# (signal) and THERM# to EXTTS# pin on the PCH. "TS" means thermal sensor. Disabled is the default.
EXTTS# via TS-on- DIMM	 Enables/disables routing TS-on-DIMM ALERT# (signal) to EXTTS# pin on the PCH.
Virtual Temperature Sensor (VTS)	 Enables/disables Virtual Temperature Sensor (VTS). Disabled is the default.

5.3.1.6. GT - Power Management Control

Select this submenu to manage the memory power for GT (integrated graphics engine).

Setting	Description
RC6 (Render Standby)	 Enables/disables render standby support, a technique that optimizes the average power to the graphics render engine during the engine's idleness. Enabled is the default.
GT OverClocking Support	 Enables/disables GT overclocking support. Disabled is the default.

5.3.2. PCH-IO Configuration

PCH-IO Configuration sets PCH parameters. The featured settings are:

Setting / Submenu	Description		
PCH LAN Controller	 Enables/disables the onboard NIC (network interface controller). Enabled is the default. 		
Wake on LAN	 Enables/disables the integrated LAN to wake the system. Disabled is the default. 		
PCIE Wake Up	 Enables/disables PCIE Wake# (signal) to wake the system. Disabled is the default. 		
Wake on Ring	 Enables/disables the RI# (signal) to wake the system. Disabled is the default. 		
Azalia	 Enables/disables Intel High Definition Audio. "Azalia" is the codename for Intel's High Definition Audio during development stage. Select Disabled to unconditionally disable Azalia. Select Auto to enable Azalia if it is present and to disable it if otherwise. Select Enabled to unconditionally enable Azalia. When enabled the following settings available: 		
	Setting Description		
	AzaliaSee 5.3.2.1. Azalia Docking Support on page 90.		
	Azalia Internal HDMI CodecSee 5.3.2.2. Azalia Internal HDMI Codec on page 90.		
SLP_S4 Assertion Width	 Sets the minimum assertion width of the SLP_S4# signal. Options available are: 1-2 Seconds 2-3 Seconds 3-4 Seconds 4-5 Seconds (default) 		

	Controls USB devices. Featured settings are:		
USB Configuration	Setting	Description	
	EHCI1	 Enables/disables the USB EHCI (USB2.0) functions. Enabled is the default. One EHCI controller must always be enabled. 	
	EHCI2	 Enables/disables the USB EHCI (USB2.0) functions. Enabled is the default. One EHCI controller must always be enabled. 	
	USB Ports Per-Port Disable Control	 Enables/disables disabling each of the USB ports (0~9) . Disabled is the default. 	

PCI Express	Setting	Description		
Configuration	PCI Express Clock Gating	Enables/disables the PCI Express root port Enabled is the default.		
	DMI Link ASPM Control	Controls the Management of southbridge sid Interface) link. Options available and L0sL1	Active State Power n both northbridge side and e of the DMI (Direct Media ailable are: Disabled , L0s (default).	
	DMI Link Extended Synch Control	Enables/disable the southbridge Disabled is	es the extended synch on side of the DMI link. the default.	
	PCI Express	Each PCI Express root port features the following settings:		
	ROOLPOILT	Setting	Description	
	PCI Express	PCI Express Root Port #	See <u>5.3.2.3. PCI</u> Express Root Port # on page 90	
		PEG - Gen X	See <u>5.3.2.4. PEG - Gen X</u> on page 90	
	PCI Express Root Port 3	ASPM Support	See <u>5.3.2.5. ASPM</u> Support on page 91.	
		Extra Bus Reserved	See <u>5.3.2.6. Extra Bus</u> Reserved on page 91.	
	PCI Express	Reserved Memory	See <u>5.3.2.7. Reserved</u> Memory on page 92.	
	Root Port 5	Reserved I/O	See <u>5.3.2.8. Reserved I/O</u> on page <u>92</u> .	

5.3.2.1. Azalia Docking Support

Enables/disables Azalia docking support of audio controller.

Disabled is the default.

5.3.2.2. Azalia Internal HDMI Codec

Enables/disables internal HDMI codec for Azalia.

- **Enabled** is the default.
- When enabled, the following settings are available:

Setting	Description
Azalia HDMI codec Port B	Enables/disables the internal HDMI codec port for Azalia. Disabled is the default.
Azalia HDMI codec Port C	Enables/disables the internal HDMI codec port for Azalia. Enabled is the default.
Azalia HDMI codec Port D	Enables/disables the internal HDMI codec port for Azalia. Disabled is the default.

5.3.2.3. PCI Express Root Port

Enables/disables the port.

Enabled is the default.

5.3.2.4. PEG - Gen X

Controls PEG1 B0:D28:F0 Gen1-Gen2, or leaves it on BIOS auto-detection.

> Options are Auto, Gen1 (default) and Gen2.

5.3.2.5. ASPM Support

Sets ASPM level.

- Options are Disabled, L0s, L1, L0sL1 and Auto (default).
- > When enabled, the following settings become available:

Setting	Description
URR	Enables/disables PCI Express unsupported request
	reporting.
	Disabled is the default.
EED	Enables/disables PCI Express fatal error reporting.
FER	Disabled is the default.
	Enables/disables PCI Express non-fatal error reporting.
NFER	Disabled is the default.
CER	Enables/disables PCI Express correctable error reporting.
GER	Disabled is the default.
сто	Enables/disables PCI Express completion timeout.
010	Disabled is the default.
	Enables/disables Root PCI Express system error on fatal
SEFE	error.
	Disabled is the default.
	Enables/disables Root PCI Express system error on non-
SENFE	fatal error.
	Disabled is the default.
	Enables/disables Root PCI Express system error on
SECE	correctable error.
	Disabled is the default.
	Enables/disables PCI Express PME (power management
PME SCI	event) SCI (system control interrupt).
	Enabled is the default.
Hot Plug	Enables/disables PCI Express hot plug.
not Flug	Disabled is the default.

5.3.2.6. Extra Bus Reserved

Sets the extra bus reserved for the bridge behind this root bridge.

- 0 is the default.
- 0-7 customizable.

5.3.2.7. Reserved Memory

Sets the reserved memory and prefetchable memory range (1~20MB) for this root bridge.

5.3.2.8. Reserved I/O

Sets the reserved I/O range (4K/8K/12K/16K/20K) for this root bridge.

5.4. Boot

The **Boot** menu configures how to boot up the system such as boot device priority.

Aptio Setup Utility - Copyright (C) 2010 American Megatrends, Inc. Main Advanced Chipset Boot Security Save & Exit		
Boot Configuration Bootup NumLock State Quiet Boot Boot Option Priorities	[On] [Disabled]	Select the keyboard NumLock state
		 →←: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit
Version 2 10 1208	Convright (C) 2010 America	an Megatrends Inc

The featured settings are:

Setting	Description		
Bootup NumLock State	 Sets keyboard's NumLock state when the system boots up. Options available are On (default) and Off. 		
Quiet Boot	 Sets whether to display the POST (power on self tests) messages or the system manufacturer's full screen logo during booting. ▶ Select Disabled to display the normal POST messages, which is the default setting. 		
Boot Option Priority	 Sets boot device priority. This item opens in context with the storage installed in the systems. 		

5.5. Security

The **Security** menu sets up the administrator password. Once an administrator password is set up, this BIOS SETUP utility is limited to access and will ask for the password each time any access is attempted.

Aptio Setup Utility - Copyright (C) 2010 America Main Advanced Chipset Boot Security Save & Exit	an Megatrends, Inc.
Password Description If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup. If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights. The password must be 3 to 20 characters long. Administrator Password	Set Setup Adminstrator Password →←: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit
Version 2.10.1208. Copyright (C) 2010 American Megatrends, Inc.	

The featured setting is:

Setting	Description	
Administrator	 To set up an administrator password: Select Administrator Password.	
Password	An Create New Password dialog then pops up onscreen. Enter your desired password that is no less than 3 characters and no more than 20 characters. Hit [Enter] key to submit.	

5.6. Save & Exit

The **Save & Exit** menu features a handful of commands to launch actions from the BIOS Setup utility regarding saving changes, quitting the utility and recovering defaults.

Aptio Setup Utility - Copyright (C) 2010 America Main Advanced Chipset Boot Security Save & Exit	an Megatrends, Inc.
Save Changes and Reset Restore Defaults	Reset the system after saving the changes.
Boot Override	
	 →+: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit
Version 2.10.1208. Copyright (C) 2010 America	n Megatrends, Inc.

Features settings are:

Setting	Description
Save Changes and Reset	 Saves the changes and resets the system. This is a command to launch action from the BIOS Setup utility.
Restore Defaults	 Restores the factory defaults. This is a command to launch action from the BIOS Setup utility.
Boot Override	 Boot Override presents a list in context with the boot devices installed in the system. Select the device to boot up the system regardless of the currently configured boot priority. This is a command to launch action from the BIOS Setup utility.

This page is intentionally left blank.



A: Watchdog Timer (WDT) Setting

WDT is widely applied to industry computers to monitor CPU activities. The programmed application triggers WDT by adequate timer setting depending on its requirement. Before WDT counts down to zero, the functional system will reset the counter. In case the WDT counter is not reset by an abnormal system, it will count down to zero and then reset the system automatically.

This computer supports the watchdog timer up to 255 levels for users for software programming. Hereunder is the source code written in C for a WDT application example.

Sample code:

```
outportb(0x2e, 0x87);
                         /* initial IO port */
                         /* twice, */
outportb(0x2e, 0x87);
outportb(0x2e, 0x07);
                          /* point to logical device */
outportb(0x2e+1, 0x07);
                         /* select logical device 7 */
                         /* select offset f5h */
outportb(0x2e, 0xf5);
outportb(0x2e+1, 0x40);
                         /* set bit5 = 1 to clear bit5 */
                         /* select offset f0h */
outportb(0x2e, 0xf0);
outportb(0x2e+1, 0x81);
                         /* set bit7 =1 to enable WDTRST# */
outportb(0x2e, 0xf6);
                         /* select offset f6h */
                         /* update offset f6h to Oah :10sec */
outportb(0x2e+1, 0x05);
outportb(0x2e, 0xF5);
                         /* select offset f5h */
outportb(0x2e+1, 0x20);
                         /* set bit5 = 1 enable watch dog time */
outportb(0x2e, 0xAA);
                         /* stop program F71869E, Exit */
```
This page is intentionally left blank.