

USER MANUAL

VB7008

Mini-ITX embedded board

Copyright

Copyright © 2011-2012 VIA Technologies Incorporated. All rights reserved.

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise without the prior written permission of VIA Technologies, Incorporated.

Trademarks

All trademarks are the property of their respective holders.

Disclaimer

No license is granted, implied or otherwise, under any patent or patent rights of VIA Technologies. VIA Technologies makes no warranties, implied or otherwise, in regard to this document and to the products described in this document. The information provided in this document is believed to be accurate and reliable as of the publication date of this document. However, VIA Technologies assumes no responsibility for the use or misuse of the information in this document and for any patent infringements that may arise from the use of this document. The information and product specifications within this document are subject to change at any time, without notice and without obligation to notify any person of such change.

VIA Technologies, Inc. reserves the right to make changes to the products described in this manual at any time without prior notice.

Regulatory Compliance

FCC-A Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his personal expense.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and A.C. power cord, if any, must be used in order to comply with the emission limits.



Tested To Comply
With FCC Standards
FOR HOME OR OFFICE USE

Battery Recycling and Disposal

- Only use the appropriate battery specified for this product.
- Do not re-use, recharge, or reheat an old battery.
- Do not attempt to force open the battery.
- Do not discard used batteries with regular trash.
- Discard used batteries according to local regulations.



Safety Precautions

- Always read the safety instructions carefully.
- Keep this User's Manual for future reference.
- All cautions and warnings on the equipment should be noted.
- Keep this equipment away from humidity.
- Lay this equipment on a reliable flat surface before setting it up.
- Make sure the voltage of the power source and adjust properly 110/220V before connecting the equipment to the power inlet.
- Place the power cord in such a way that people cannot step on it.
- Always unplug the power cord before inserting any add-on card or module.
- If any of the following situations arises, get the equipment checked by authorized service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the equipment.
 - The equipment has been exposed to moisture.
 - The equipment has not worked well or you cannot get it work according to User's Manual.
 - The equipment has dropped and damaged.
 - The equipment has obvious sign of breakage.
- Do not leave this equipment in an environment unconditioned or in a storage temperature above 60°C (140°F). The equipment may be damaged.
- Do not leave this equipment in direct sunlight.
- Never pour any liquid into the opening. Liquid can cause damage or electrical shock.
- Do not place anything over the power cord.
- Do not cover the ventilation holes. The openings on the enclosure protect the equipment from overheating

Box Contents and Ordering Information

VB7008-16

- 1 x VB7008 embedded board (with C7[®]-D 1.6 GHz NanoBGA2 processor)
- 1 x I/O bracket
- 1 x SATA cable

Table of Contents

1.	Product Overview	1
1.1.	Key Features and Benefits	1
1.1.1.	VIA C7 [®] -D 1.6GHz NanoBGA2 Processor	1
1.1.2.	VIA VX900 MSP Chipset	2
1.1.3.	Modular Expansion Options	2
1.2.	Product Specifications	3
1.3.	Layout Diagram	6
1.4.	Product Dimensions	7
1.5.	Height Distribution	8
2.	I/O Interface	9
2.1.	External I/O Ports	9
2.1.1.	PS/2 Port	10
2.1.2.	HDMI [®] Port	10
2.1.3.	VGA Port	12
2.1.4.	COM Port	13
2.1.5.	USB 2.0 Port	14
2.1.6.	RJ45 LAN port: Gigabit Ethernet	15
2.1.7.	Audio Ports	16
2.2.	Onboard Connectors	17
2.2.1.	ATX Power Connector	17
2.2.2.	CMOS Battery Slot	18
2.2.3.	Front Panel Pin Header	19
2.2.4.	SMBus Pin Header	20
2.2.5.	CPU and System Fan Connectors	20
2.2.6.	SATA Connectors	22
2.2.7.	USB 2.0 Pin Headers	23
2.2.8.	COM Pin Header	25
2.2.9.	PS/2 Keyboard and Mouse Pin Header	26
2.2.10.	Front Audio Pin Header	27

2.2.11.	SPDIF Connector	28
2.2.12.	SPI Pin Header	29
2.2.13.	LPC Pin Header	30
2.2.14.	LPT Pin Header	31
2.2.15.	SIR Pin Header	33
2.2.16.	Temperature Sensor Pin Header	34
2.2.17.	Composite + S-Video Out Pin Header (optional)	35
3.	Jumpers	37
3.1.	Clear CMOS Jumper	37
3.2.	COM2 Voltage Select Jumper	39
3.3.	SATA DOM Voltage Select Jumper	40
4.	Expansion Slots	41
4.1.	DDR3 Memory Slots	41
4.1.1.	Installing a Memory Module	42
4.1.2.	Removing a Memory Module	44
4.1.3.	PCI Slot	45
5.	Hardware Installation	47
5.1.	Installing into a Chassis	47
5.1.1.	Suggested minimum chassis dimensions	47
5.1.2.	Suggested minimum chassis height	48
5.1.3.	Suggested keepout areas	49
6.	BIOS Setup Utility	51
6.1.	Entering the BIOS Setup Utility	51
6.2.	Control Keys	51
6.3.	Navigating the BIOS Menus	52
6.4.	Getting Help	52
6.5.	Main Menu	53
6.5.1.	Standard CMOS Features	53
6.5.2.	Advanced BIOS Features	53

6.5.3.	Advanced Chipset Features	53
6.5.4.	Integrated Peripherals	53
6.5.5.	Power Management Setup	53
6.5.6.	PnP/PCI Configurations.....	54
6.5.7.	PC Health Status.....	54
6.5.8.	Frequency/Voltage Control	54
6.5.9.	Load Optimized Defaults.....	54
6.5.10.	Set Supervisor Password	54
6.5.11.	Set User Password	54
6.5.12.	Save & Exit Setup	54
6.5.13.	Exit Without Saving.....	54
6.6.	Standard CMOS Features	55
6.6.1.	Date.....	55
6.6.2.	Time	55
6.6.3.	Halt On	55
6.7.	IDE Channels	56
6.8.	Advanced BIOS Features	58
6.8.1.	Quick Power On Self-Test.....	58
6.8.2.	First/Second/Third Boot Device	58
6.8.3.	Boot Other Device.....	59
6.8.4.	Boot Up NumLock Status	59
6.8.5.	Security Option	59
6.8.6.	Full Screen Logo Show.....	59
6.8.7.	Summary Screen Show	59
6.9.	Hard Disk Boot Priority.....	60
6.10.	Advanced Chipset Features	61
6.11.	PCIE Bus Control	62
6.11.1.	PCIE Root Port.....	62
6.11.2.	PCIE Target Link Speed.....	62
6.12.	UMA & P2P Bridge Control.....	63
6.12.1.	UMA Enable	63
6.12.2.	VGA Share Memory Size.....	63
6.12.3.	CPU Direct Access FB	63

6.12.4.	Select Display Device	64
6.12.5.	Select Display Device 1	64
6.12.6.	Select Display Device 2	64
6.12.7.	TV_Type	64
6.12.8.	TV_Connector: Composite	64
6.12.9.	TV_Connector: S-Video	64
6.13.	CPU & PCI Bus Control	65
6.13.1.	PCI Master 0 WS Write	65
6.13.2.	PCI Delay Transaction	65
6.13.3.	SB P2P Bridge	65
6.14.	Integrated Peripherals	66
6.15.	VIA OnChip IDE Device	67
6.15.1.	OnChip SATA	67
6.16.	VIA OnChip PCI Device	68
6.16.1.	Onboard PCIE LAN	68
6.16.2.	OnBoard LAN Boot ROM	68
6.16.3.	OnChip HDAC Device	68
6.16.4.	NB HD Audio Codec 1	68
6.16.5.	Hide D1F1	68
6.17.	SuperIO Device	69
6.17.1.	Onboard Serial Port 1	69
6.17.2.	Onboard Serial Port 2	69
6.17.3.	SIR Function Setting	69
6.17.4.	Onboard Parallel Port	69
6.17.5.	Parallel Port Mode	69
6.17.6.	ECP Mode Use DMA	70
6.18.	USB Device Setting	71
6.18.1.	USB 1.0 Controller	71
6.18.2.	USB 2.0 Controller	71
6.18.3.	USB Operation Mode	71
6.18.4.	USB Keyboard Function	71
6.18.5.	USB Mouse Function	72
6.18.6.	USB Storage Function	72

6.19.	Power Management Setup	73
6.19.1.	EuP/ErP Lot6	73
6.19.2.	ACPI Suspend Type	73
6.19.3.	Soft-Off by PWRBTN	73
6.19.4.	Run VGABIOS if S3 Resume	74
6.19.5.	AC Loss Auto Restart	74
6.19.6.	HPET Support	74
6.19.7.	WDRT Support	74
6.19.8.	WDRT Run/Stop	74
6.19.9.	WDRT Count	74
6.20.	Wakeup Event Detect	75
6.20.1.	PS2KB Wakeup Select	75
6.20.2.	PS2KB Wakeup Key Select	75
6.20.3.	PS2MS Wakeup Key Select	75
6.20.4.	PS2 Keyboard Power ON	75
6.20.5.	PS2 Mouse Power ON	76
6.20.6.	RTC Alarm Resume	76
6.20.7.	Date (of Month)	76
6.20.8.	Resume Time (hh:mm:ss)	76
6.21.	PnP/PCI Configurations	77
6.21.1.	Init Display First	77
6.21.2.	Reset Configuration Data	77
6.21.3.	Resources Controlled By	77
6.22	PC Health Status	79
6.23	Frequency/Voltage Control	80
6.23.1	DRAM Clock	80
6.23.2	DRAM Timing	80
6.23.3	DRAM Init Method	80
6.23.4	DRAM REMAP	80
6.23.5	Spread Spectrum	80
6.24	Load Optimized Defaults	82
6.25	Set Supervisor/User Password	83
6.26	Save & Exit Setup	85

6.27	Exit Without Saving.....	86
7	Driver Installation.....	87
7.1	Microsoft Driver Support.....	87
7.2	Linux Driver Support.....	87
Appendix A.	Power Consumption Report.....	89
A.1.	VB7008-16.....	89
A.1.1.	Playing DVD-Windows Media Player 12 (+HDMI).....	89
A.1.2.	Playing MP3-Media Player	90
A.1.3.	Running Network Application – Files Copy	90
A.1.4.	Idle	90
A.1.5.	Run Burn-in Test V6.0	91
A.1.6.	S3.....	91
Appendix B.	Mating Connector Vendor Lists.....	93

Lists of Figures

Figure 1: Layout diagram of the VB7008 mainboard (top view)	6
Figure 2: Mounting holes and dimensions of the VB7008 mainboard	7
Figure 3: External I/O port dimensions of the VB7008 mainboard	7
Figure 4: Height distribution of the VB7008 mainboard	8
Figure 5: External I/O ports	9
Figure 6: PS/2 port pinout diagram	10
Figure 7: HDMI® port pinout diagram	10
Figure 8: VGA port pinout diagram	12
Figure 9: COM port pinout diagram	13
Figure 10: USB port pinout diagram	14
Figure 11: Gigabit Ethernet port pinout diagram	15
Figure 12: Audio jack receptacle stack	16
Figure 13: ATX power connector	17
Figure 14: CMOS battery slot	18
Figure 15: Front panel pin header	19
Figure 16: SMBus pin header pinout	20
Figure 17: Fan connectors	21
Figure 18: SATA connectors	22
Figure 19: USB pin headers	23
Figure 20: COM pin header	25
Figure 21: PS/2 keyboard and mouse pin header	26
Figure 22: Front audio pin header	27
Figure 23: SPDIF connector	28
Figure 24: SPI pin header	29
Figure 25: LPC pin header	30
Figure 26: LPT pin header	31
Figure 27: SIR pin header	33
Figure 28: Temperature sensor pin header	34
Figure 29: Composite + S-Video pin header	35
Figure 30: CLEAR CMOS jumper	37
Figure 31: COM2 voltage select jumper	39

Figure 32: SATA DOM voltage select jumper	40
Figure 33: DDR3 memory slots	41
Figure 34: Unlocking the memory DIMM slot.....	42
Figure 35: Inserting the memory module.....	42
Figure 36: Locking the memory module	43
Figure 37: Removing the memory module	44
Figure 38: PCI slot	45
Figure 39: Suggested minimum chassis dimensions	47
Figure 40: Suggested minimum internal chassis ceiling height.....	48
Figure 41: Suggested keepout areas	49
Figure 42: Illustration of the Main menu screen.....	53

Lists of Tables

Table 1: PS/2 port pinout	10
Table 2: HDMI® port pinout	11
Table 3: VGA port pinout	12
Table 4: COM port pinout	13
Table 5: USB port pinout.....	14
Table 6: Gigabit Ethernet port pinout	15
Table 7: Gigabit Ethernet LED color definition	15
Table 8: Audio jack receptacle pinout.....	16
Table 9: ATX power connector pinout.....	17
Table 10: CMOS battery slot pinout	18
Table 11: Front panel pin header pinout.....	19
Table 12: SMBus pin header	20
Table 13: Fan connector pinouts	21
Table 14: SATA connector pinouts.....	22
Table 15: USB pin header pinouts.....	24
Table 16: COM pin header pinout.....	25
Table 17: PS/2 keyboard and mouse pin header pinout.....	26
Table 18: Front audio pin header pinout.....	27
Table 19: SPDIF connector pinout	28
Table 20: SPI pin header pinout	29
Table 21: LPC pin header pinout.....	30
Table 22: LPT pin header pinout	32
Table 23: SIR pin header pinout	33
Table 24: Temperature sensor pin header pinout	34
Table 25: Composite + S-Video pin header pinout	35
Table 26: CLEAR CMOS jumper settings	37
Table 27: COM2 voltage select jumper settings	39
Table 28: SATA DOM voltage select jumper settings	40
Table 29: VB7008 mating connector vendor lists	93

1. Product Overview

The VIA VB7008 Mini-ITX mainboard is an entry-level native x86 mainboard designed mainly for embedded and thin client applications. It can also be used for various domain applications such as desktop PC, industrial PC, etc. The mainboard is based on the VIA VX900 MSP (Media System Processor) chipset that features the VIA Chrome9™ HD DX9 with 2D/3D graphics and video accelerators for rich digital media performance.

The VIA VB7008 includes a secure and power efficient VIA C7®-D 1.6 GHz NanoBGA2 processor. The VIA C7®-D NanoBGA2 processor includes the VIA Padlock Security Engine, VIA StepAhead™ Technology Suite, VIA PowerSaver, and VIA CoolStream™ technology.

The VIA VB7008 has one 1066 MHz DDR3 DIMM slot that support up to 4 GB memory size. The VIA VB7008 provides support for high fidelity audio with its included VIA VT1708S High Definition Audio codec. In addition it supports two SATA 3Gb/s storage devices.

The VIA VB7008 is compatible with a full range of Mini-ITX chassis as well as FlexATX and MicroATX enclosures and power supplies. The VIA VB7008 is fully compatible with Microsoft® and Linux operating systems.

1.1. Key Features and Benefits

1.1.1. VIA C7®-D 1.6GHz NanoBGA2 Processor

The VIA C7®-D NanoBGA2 is a 32-bit processor in x86 platform using a 90 nanometer process technology. It is the world's first Carbon Free processor and perfectly fit for embedded system applications. Packed into an ultra compact NanoBGA2 package (measuring 21mm x 21mm), it delivers an energy-efficient yet powerful performance, with cool and quiet operation.

1.1.2. VIA VX900 MSP Chipset

The VIA VX900 media system processor is designed to enable high quality digital video streaming and DVD playback. The VIA VX900 features VIA Chrome9™ HD DX9 with 2D/3D graphics and video accelerators, DDR3 1066 MHz support, motion compensation and dual display support to ensure a rich overall entertainment experience.

1.1.3. Modular Expansion Options

The VIA VB7008 ensures long-term usability with its support for industry standard expansion options. Its support for legacy PCI expansion cards helps to smooth and reduce the costs of transitioning to newer expansion technologies. The VIA VB7008 enables companies to slowly roll out upgrades as necessary instead of having to replace everything all at once. This ensures that companies using the VB7008 obtain the maximum benefits from its past investments in PCI expansion cards.

1.2. Product Specifications

- **Processor**
 - VIA C7®-D 1.6 GHz NanoBGA2
 - Supports 800MHz Front Side Bus
 - 21 mm x 21 mm FCBGA
- **Chipset**
 - VIA VX900 MPS chipset
 - 31 mm x 31 mm FCBGA
- **System Memory**
 - 1 x DIMM slot supporting DDR3 1066 MHz
 - Supports up to 4 GB memory size
- **Graphics**
 - Integrated VIA Chrome9™ HD DX9 3D/2D Graphics and Video Processor
 - MPEG-2, VC-1 and H.264 video decoding acceleration
 - DirectX 9 support
- **Onboard Peripherals**
 - **Serial ATA**
 - 2 SATA connectors
 - Supports up to 3 Gb/s
 - **Onboard LAN**
 - VIA VT6130 PCIe Gigabit Ethernet controller
 - **Onboard HDTV**
 - VIA VT1625 HDTV encoder (manufacturing option)
 - **Onboard Audio**
 - VIA VT1708S High Definition Audio Codec
 - **Onboard Super I/O**
 - Fintek F71869E Super I/O controller
 - Supports up to two COM ports
- **Onboard I/O Connectors**
 - 3 x USB 2.0 pin header for 6 USB ports (including 2 optional port)
 - 2 x SATA 2.0 HDD connectors
 - 1 x Composite + S-Video out pin header supported by VT162 (manufacturing option)
 - 1 x Front audio pin header for Line-out and MIC-in
 - 1 x PS/2 Keyboard and Mouse pin header

- 1 x Front panel pin header
 - 1 x CPU fan connector
 - 1 x System fan connector
 - 1 x COM pin header
 - 1 x LPC pin header
 - 1 x LPT pin header
 - 1 x SPDIF connector
 - 1 x SMBus pin header
 - 1 x Temperature sensor pin header
 - 1 x SIR pin header
 - 1 x SPI pin header
 - 1 x PCI slot
 - 1 x Clear CMOS jumper
 - 1 x COM voltage select jumper
 - 1 x SATA DOM voltage select jumper
 - 1 x Buzzer
 - 1 x ATX (20-pin) power connector
- **Back Panel I/O**
 - 1 x HDMI® port
 - 1 x VGA port
 - 1 x COM port
 - 1 x RJ45 (GigaLAN) port
 - 2 x USB 2.0 ports
 - 1 x PS/2 Keyboard port
 - 1 x PS/2 Mouse port
 - 1 x Audio port stack with Line-in, Line-out, MIC-in (Horizontal, Smart 5.1 support)
- **BIOS**
 - Award BIOS
 - 8 Mbit SPI flash memory
- **Supported Operating System**
 - Windows 7
 - Windows Embedded Standard 7
 - Windows Embedded Standard
 - Windows XP
 - Windows CE
 - Linux

- **System Monitoring & Management**
 - Wake-on-LAN
 - Keyboard and Mouse Power-on
 - Timer Power-on
 - System voltage monitoring
 - AC power failure recovery

- **Operating Conditions**
 - **Operating Temperature**
 - 0°C up to 50°C
 - **Operating Humidity**
 - 0% ~ 95% (relative humidity; non-condensing)

- **Form Factor**
 - Mini-ITX (4-Layer)
 - 17 cm x 17 cm

- **Compliance**
 - CE
 - FCC
 - RoHS

1.3. Layout Diagram




Figure 1: Layout diagram of the VB7008 mainboard (top view)

1.4. Product Dimensions




Figure 2: Mounting holes and dimensions of the VB7008 mainboard




Figure 3: External I/O port dimensions of the VB7008 mainboard

1.5. Height Distribution




Figure 4: Height distribution of the VB7008 mainboard

2. I/O Interface

The VIA VB7008 has a wide selection of interfaces integrated into the board. It includes a selection of frequently used ports as part of the external I/O coastline.

2.1. External I/O Ports




Figure 5: External I/O ports

2.1.1. PS/2 Port

The mainboard has two integrated PS/2 ports for keyboard and mouse. Each port is using the 6-pin Mini-DIN connector. The color purple is use for a PS/2 keyboard while the color green is use for a PS/2 mouse. The pinout of the PS/2 port are shown below.

Pin	Signal
1	Data
2	NC
3	Ground
4	+5V
5	Clock
6	NC

Table 1: PS/2 port pinout




Figure 6: PS/2 port pinout diagram

2.1.2. HDMI® Port

The integrated 19-pin HDMI® port uses an HDMI® Type A receptacle connector. The HDMI® (High Definition Multimedia Interface) port is for connecting the high definition video and digital audio. It allows you to connect the digital video devices which utilize a high definition video signal. The pinout of the HDMI® port is shown below.




Figure 7: HDMI® port pinout diagram

Pin	Signal	Pin	Signal
1	TX2+	2	Ground
3	TX2-	4	TX1+
5	Ground	6	TX1-
7	TX0+	8	Ground

9	TX0-	10	TXC+
11	Ground	12	TXC-
13	key	14	key
15	DDCSCL	16	DDCSDA
17	Ground	18	+5V
19	Hot Plug Detect		

Table 2: HDMI® port pinout

2.1.3. VGA Port

The integrated 15-pin VGA port uses a female DE-15 connector. The VGA port is for connecting to analog displays. The pinout of the VGA port is shown below.




Figure 8: VGA port pinout diagram

Pin	Signal
1	RED
2	GREEN
3	BLUE
4	NC
5	Ground
6	Ground
7	Ground
8	Ground
9	+5V
10	NC
11	NC
12	SDA
13	HSync
14	VSynC
15	SCL

Table 3: VGA port pinout

2.1.4. COM Port

The integrated 9-pin COM port uses a male DE-9 connector. The COM (COM1) port supports the RS-232 standard. The pinout of the COM port is shown below.




Figure 9: COM port pinout diagram

Pin	Signal	Pin	Signal
1	DCD	6	DSR
2	RxD	7	RTS
3	TxD	8	CTS
4	DTR	9	RI
5	GND		

Table 4: COM port pinout

2.1.5. USB 2.0 Port

There are two integrated USB 2.0 ports in VB7008 mainboard. The USB-interface port gives complete Plug and Play and hot swap capability for external devices and it complies with USB UHCI, rev. 2.0. Each USB port is using the USB Type A receptacle connector. The pinout of the typical USB port is shown below.

Pin	Signal
1	+5VSUS
2	Data-
3	Data+
4	Ground

Table 5: USB port pinout




Figure 10: USB port pinout diagram

2.1.6. RJ45 LAN port: Gigabit Ethernet

The integrated 8-pin Gigabit Ethernet port is using an 8 Position 8 Contact (8P8C) receptacle connector (commonly referred to as RJ45). The pinout of the Gigabit Ethernet port is shown below.

Pin	Signal
1	Signal pair 1+
2	Signal pair 1-
3	Signal pair 2+
4	Signal pair 3+
5	Signal pair 3-
6	Signal pair 2-
7	Signal pair 4+
8	Signal pair 4-

Table 6: Gigabit Ethernet port pinout




Figure 11: Gigabit Ethernet port pinout diagram

The RJ-45 port has two individual LED indicators located on the front side to show its Active/Link status and Speed status.

	Link LED (Left LED on RJ-45 connector)	Active LED (Right LED on RJ-45 connector)
Link Off	Off	Off
Speed_10Mbit	The LED is always On in either Green or Orange colors	Flash in Yellow color
Speed_100Mbit	The LED is always On in Green color	Flash in Yellow color
Speed_1000Mbit	The LED is always On in Orange color	Flash in Yellow color

Table 7: Gigabit Ethernet LED color definition

2.1.7. Audio Ports

There are three audio jack receptacles integrated into a single stack on the I/O coastline. Each receptacle can fit a 3.5 mm Tip Ring Sleeve (TRS) connector to enable connections to Line-Out Line-In, and MIC-in. The Line-Out jack is for connecting to external speakers or headphones. The Line-In jack is for connecting an external audio devices such as CD player, tape player and etc.. The MIC-In jack is for connecting to a microphone.

Wiring	Line-Out	Line-In	MIC-In
Tip	Left channel	Left channel in	Left channel
Ring	Right channel	Right channel in	Right channel
Sleeve	Ground	Ground	Ground

Table 8: Audio jack receptacle pinout




Figure 12: Audio jack receptacle stack

2.2. Onboard Connectors

2.2.1. ATX Power Connector

The mainboard has a 20-pin ATX power connector onboard. The ATX power connector is labeled as "ATX_POWER1". The pinout of the ATX power connector is shown below.




Figure 13: ATX power connector

Pin	Signal	Pin	Signal
1	+3.3V	11	+3.3V
2	+3.3V	12	-12V
3	Ground	13	Ground
4	+5V	14	Power Supply On
5	Ground	15	Ground
6	+5V	16	Ground
7	Ground	17	Ground
8	Power OK	18	-5V
9	+5VSB	19	+5V
10	+12V	20	+5V

Table 9: ATX power connector pinout

2.2.2. CMOS Battery Slot

The mainboard is equipped with a CMOS battery slot, which is compatible with CR2032 coin batteries. The CMOS battery slot is labeled as "BAT2". When inserting a CR2032 coin battery, be sure that the positive side is facing the locking clip.




Figure 14: CMOS battery slot

Pin	Signal
1	Ground
2	+3V
3	Ground

Table 10: CMOS battery slot pinout

2.2.3. Front Panel Pin Header

The front panel pin header consists of 15 pins in a 16-pin block. Pin 15 is keyed. The front panel pin header is labeled as "F_PANEL1". It provides access to system LEDs, power, reset, system speaker and HDD LED. The pinout of the front panel pin header is shown below.




Figure 15: Front panel pin header

Pin	Signal	Pin	Signal
1	+5VDUAL	2	+5V
3	+5VDUAL	4	SATA_LED
5	PWR_LED	6	PWR_BTN
7	+5V	8	Ground
9	NC	10	-RST_SW
11	NC	12	Ground
13	SPEAK	14	+5V
15	key	16	NC

Table 11: Front panel pin header pinout

2.2.4. SMBus Pin Header

The SMBus pin header consists of three pins that allow connecting the SMBus devices. Devices communicate with a SMBus host and/or other SMBus devices using the SMBus interface. It is labeled as "SMBUS". The pinout of the SMBus pin header is shown below.

Pin	Signal
1	SMBCK
2	SMBDT
3	Ground

Table 12: SMBus pin header




Figure 16: SMBus pin header pinout

2.2.5. CPU and System Fan Connectors

There are two fan connectors on board: one for the CPU and one for the chassis. The fan connector for the CPU is labeled as "CPUFAN1" and the fan connector for the system is labeled as "SYSFAN1". The fans provide variable fan speeds controlled by the BIOS. The pinout of the fan connectors is shown below.

CPU fan (CPUFAN1)	
Pin	Signal
1	FANIN1
2	FANCTL
3	Ground

System fan (SYSFAN1)	
Pin	Signal
1	FANIN2
2	FANCTL
3	Ground

Table 13: Fan connector pinouts




Figure 17: Fan connectors

2.2.6. SATA Connectors

The two SATA connectors on board can support up to 3 Gb/s transfer speeds. The SATA connectors are labeled as "SATA1" and "SATA2". The pinout of the SATA connectors are shown below.

SATA1	
Pin	Signal
1	Ground
2	STXP_1
3	STXN_1
4	Ground
5	SRXN_1
6	SRXP_1
7	Ground

SATA2	
Pin	Signal
1	Ground
2	STXP_2
3	STXN_2
4	Ground
5	SRXN_2
6	SRXP_2
7	SATA2_+5V




Table 14: SATA connector pinouts

Figure 18: SATA connectors



Note:

If the users want to use the SATA Disk-on-Module flash drive on the board, please use the SATA2 connector.

2.2.7. USB 2.0 Pin Headers

The mainboard has three USB 2.0 pin header blocks that support up to six USB 2.0 ports. The pin header blocks are labeled as “USB_2”, USB_3, and “USB_4”. The pinout of the USB pin headers are shown below.




Figure 19: USB pin headers

USB_2			
Pin	Signal	Pin	Signal
1	VUSB2	2	VUSB2
3	USBD_T3-	4	USB_T2-
5	USBD_T3+	6	USB_T2+
7	Ground	8	Ground
9	Key	10	Ground

USB_3			
Pin	Signal	Pin	Signal
1	VUSB4	2	VUSB4
3	USBD_T5-	4	USB_T4-
5	USBD_T5+	6	USB_T4+
7	Ground	8	Ground
9	Key	10	Ground

USB_4			
Pin	Signal	Pin	Signal
1	VUSB6	2	VUSB6
3	USBD_T6-	4	USB_T7-
5	USBD_T6+	6	USB_T7+
7	Ground	8	Ground
9	Key	10	Ground

Table 15: USB pin header pinouts

2.2.8. COM Pin Header

The mainboard include one onboard COM pin header in addition to the COM port 1 on the external I/O. The onboard COM pin header labeled as "COM2" is used to attach additional COM port that supports RS-232 standard. The pinout of the COM2 pin header is shown below.




Figure 20: COM pin header

Pin	Signal	Pin	Signal
1	COM_DCD	2	COM_RXD
3	COM_TXD	4	COM_DTR
5	Ground	6	COM_DSR
7	COM_RTS	8	COM_CTS
9	COM_RI	10	key

Table 16: COM pin header pinout

2.2.9. PS/2 Keyboard and Mouse Pin Header

The mainboard has a pin header for a PS/2 keyboard and mouse. The pin header is labeled as "KBMS1". The pinout of the pin header is shown below.




Figure 21: PS/2 keyboard and mouse pin header

Pin	Signal	Pin	Signal
1	+5VDUAL	2	Ground
3	KB_CLK	4	KB_DATA
5	EKBCLK	6	EKBDATA
7	MS_CLK	8	MS_DATA
9	EMSCLK	10	EMSDATA

Table 17: PS/2 keyboard and mouse pin header pinout



Note:

When the pin header is not in use, please short pin 3&5, pin 4&6, pin 7&9 and pin 8&10

2.2.10. Front Audio Pin Header

In addition to the TRS audio jacks on the external I/O coastline, the mainboard has a pin header for Line-Out and MIC-In. The pin header is labeled as "F_AUDIO1". The pinout of the pin header is shown below.




Figure 22: Front audio pin header

Pin	Signal	Pin	Signal
1	MIC2IN_L	2	AGND
3	MIC2IN_R	4	AGND
5	HPOUTR	6	MIC2_JD
7	F_AUDIO_SENSE	8	Key
9	HPOUTL	10	HPOUT_JD

Table 18: Front audio pin header pinout

2.2.11. SPDIF Connector

The mainboard has one 3-pin SPDIF (Sony Philips Digital Interface) connector. The SPDIF output provides digital audio to external speakers or compressed AC3 data to an external Dolby Digital Decoder. The connector is labeled as “SPDIF1”. The pinout of the connector is shown below.




Figure 23: SPDIF connector

Pin	Signal
1	VDD
2	SPDIFO
3	Ground

Table 19: SPDIF connector pinout

2.2.12. SPI Pin Header

The mainboard has one 8-pin SPI pin header. The SPI (Serial Peripheral Interface) pin-header is used to connect to the SPI BIOS programming fixture. The pin header is labeled as "SPI1". The pinout of the pin header is shown below.




Figure 24: SPI pin header

Pin	Signal	Pin	Signal
1	SPIVCC	2	Ground
3	MSPISS0	4	MSPICK
5	MSPIDI	6	MSPIDO
7	key	8	-PCIRST

Table 20: SPI pin header pinout

2.2.13. LPC Pin Header

The mainboard has one LPC pin header for connecting LPC devices. The pin header is labeled as "LPC". The pinout of the pin header is shown below.




Figure 25: LPC pin header

Pin	Signal	Pin	Signal
1	LAD1	2	LPCIF_33_CLK
3	-PCIRSTX	4	Ground
5	LAD0	6	LPCIF_48_CLK
7	LAD2	8	_LFRAME
9	SERIRQ	10	LAD3
11	-LDRQ1	12	-EXTSMI
13	+5V	14	+3.3V
15	+5V	16	+3.3V
17	Ground	18	Ground
19	Ground	20	NC

Table 21: LPC pin header pinout

2.2.14. LPT Pin Header

The mainboard has one LPT pin header for connecting 25-pin LPT female external connector for parallel port. A parallel port is a standard printer port that supports Enhanced Parallel Port (EPP) and Extended Capabilities Parallel Port (ECP) modes. The pin header is labeled as "LPT1". The pinout of the pin header is shown below.




Figure 26: LPT pin header

Pin	Signal	Pin	Signal
1	-LP_STB	2	-LP_AFD
3	LP_D0	4	-LP_ERR
5	LP_D1	6	-LP_INIT
7	LP_D2	8	-LP-SLIN
9	LP_D3	10	Ground
11	LP_D4	12	Ground
13	LP_D5	14	Ground
15	LP_D6	16	Ground
17	LP_D7	18	Ground

19	-LP_ACK	20	Ground
21	LP_BUSY	22	Ground
23	LP_PE	24	Ground
25	LP_SLCT	26	Key

Table 22: LPT pin header pinout

2.2.15. SIR Pin Header

The mainboard has SIR (Serial Infrared) pin header. This pin header is used to connect to a serial infrared module. The pin header is labeled as "SIR1". The pinout of the SIR pin header is shown below.




Figure 27: SIR pin header

Pin	Signal
1	+5V
2	NC
3	IRRX
4	Ground
5	IRTX

Table 23: SIR pin header pinout



Note:

Microsoft Windows Vista and Windows 7 do not support the Infrared driver.

2.2.16. Temperature Sensor Pin Header

The mainboard supports a pin header (3-pin) that allows the connection of a temperature sensor cable for detecting the system’s internal air temperature. The temperature reading can be seen in the BIOS Setup Utility. The pin header is labeled as “J5”. The pin out of the temperature sensor pin header is shown below.




Figure 28: Temperature sensor pin header

Pin	Signal
1	TMPIN2
2	TMPIN2
3	HWMGND

Table 24: Temperature sensor pin header pinout

2.2.17. Composite + S-Video Out Pin Header (optional)

The mainboard provide an optional Composite + S-Video out pin header that allows connecting the TV port/jack connector in order to interface TV monitor or S-Video device to the mainboard. The pin header is labeled as "JTV1". The pinout of the pin header is shown below.




Figure 29: Composite + S-Video pin header

Pin	Signal	Pin	Signal
1	CVBS	2	Ground
3	CHROMA	4	key
5	LUMA	6	Ground

Table 25: Composite + S-Video pin header pinout

3. Jumpers

3.1. Clear CMOS Jumper

The onboard CMOS RAM stores system configuration data and has an onboard battery power supply. To reset the CMOS settings, set the jumper on pins 2 and 3 while the system is off. Return the jumper to pins 1 and 2 afterwards. Setting the jumper while the system is on will damage the mainboard. The default setting is on pins 1 and 2.




Figure 30: CLEAR CMOS jumper

Setting	Pin 1	Pin 2	Pin 3
Regular (default)	On	On	Off
Clear CMOS	Off	On	On

Table 26: CLEAR CMOS jumper settings

**Note:**

Except when clearing the RTC RAM, never remove the cap from the CLEAR_CMOS jumper default position. Removing the cap will cause system boot failure. Avoid clearing the CMOS while the system is on; it will damage the mainboard.

3.2. COM2 Voltage Select Jumper

The additional COM port (available through the onboard COM2 pin header, see page 25) can support both +5V and +12V. The COM2 voltage select pin jumper is a selector to determine the input voltage of COM2 pin header connector. The voltage can be either +5V or +12V. +5V is the default setting. The pin jumper is labeled as "J6". The jumper settings are shown below.




Figure 31: COM2 voltage select jumper

Setting	Pin 1	Pin 2	Pin 3
+5V	On	On	Off
+12V	Off	On	On

Table 27: COM2 voltage select jumper settings

3.3. SATA DOM Voltage Select Jumper

The SATA2 connector (see page 22) can be used to support Disk-on-Module (DOM) flash drive. When the jumper is set, +5V will be delivered to the 7th pin of the SATA2 connector. The pin jumper is labeled as “J2”. The jumper settings are shown below.




Figure 32: SATA DOM voltage select jumper

SATA2 Setting	Pin 2	Pin 4	Pin 6
DOM support	On	On	Off
Regular (default)	Off	On	On

Table 28: SATA DOM voltage select jumper settings



Note:

The default settings of “SATA DOM Voltage Select Jumper”: short pin 3&5 and pin 4&6

4. Expansion Slots

4.1. DDR3 Memory Slots

The mainboard provide one DDR3 DIMM memory slot. The memory slot can accommodate up to 4 GB of 1066 MHz memory. The memory slot is labeled as "DIMM1". The location of the DDR3 memory slot is shown below.




Figure 33: DDR3 memory slots

4.1.1. Installing a Memory Module

Step 1

Disengage the locking mechanism at both ends of the DIMM slot by pressing the retaining clips outward.




Figure 34: Unlocking the memory DIMM slot

Step 2

Align the notch on the DIMM memory module with the counter part on the DIMM slot.




Figure 35: Inserting the memory module

Step 3

Insert the DIMM memory module into the slot and push down at both ends until the locking clips lock the DIMM memory module into place.




Figure 36: Locking the memory module

4.1.2. Removing a Memory Module

Step 1

To disengage the locking clips, push outward the locking clips on both ends of memory slot. When the locking clips have cleared, the DIMM memory module will automatically pop up. Remove the memory module.




Figure 37: Removing the memory module

4.1.3. PCI Slot

The onboard PCI slot, labeled as “PCI_SLOT1”, supports 5V 32-bit PCI cards. It is not compatible with PCI cards requiring 3.3V signaling. The location of the PCI slot is shown below.




Figure 38: PCI slot



Note:

1. The orientation of PCI card can be changed from vertical to horizontal using a riser card module.
2. When adding or removing expansion card, unplug first the power supply.

5. Hardware Installation

5.1. Installing into a Chassis

The VB7008 can be fitted into any chassis that has the mounting holes for compatible with the standard Mini-ITX mounting hole locations. Additionally, the chassis must meet the minimum height requirements for specified areas of the mainboard. If a riser card module is being used, the chassis will need to accommodate the additional space requirements.

5.1.1. Suggested minimum chassis dimensions

The figure below shows the suggested minimum space requirements that a chassis should have in order to work well with the VB7008.




Figure 39: Suggested minimum chassis dimensions

Each side of the mainboard should have a buffer zone from the internal wall of the chassis. The side of the mainboard that accommodates the I/O coastline should have a buffer of 1.00 mm. The side on the opposite end of the I/O

coastline should have a buffer of at least 5.00 mm. The two sides adjacent to the I/O coastline should have at least a 10.00 mm buffer.

For the side that is close to the PCI slot, the buffer should be at least 100.00 mm if a riser card module will be used.

5.1.2. Suggested minimum chassis height

The figure below shows the suggested minimum height requirements for the internal space of the chassis. It is not necessary for the internal ceiling to be evenly flat. What is required is that the internal ceiling height must be strictly observed for each section that is highlighted. The highest part of the ceiling will be above the PCI slot.




Figure 40: Suggested minimum internal chassis ceiling height

5.1.3. Suggested keepout areas

The figure below shows the areas of the mainboard that is highly suggested to leave unobstructed.




Figure 41: Suggested keepout areas

6. BIOS Setup Utility

6.1. Entering the BIOS Setup Utility

Power on the computer and press **Delete** during the beginning of the boot sequence to enter the BIOS Setup Utility. If the entry point has passed, restart the system and try again.

6.2. Control Keys

- Up** Move up one row
- Down** Move down one row
- Left** Move to the left in the navigation bar
- Right** Move to the right in the navigation bar
- Enter** Access the highlighted item / Select the item
- Esc** Jumps to the Exit screen or returns to the previous screen
- Page up / +¹** Increase the numeric value
- Page down / -¹** Decrease the numeric value
- F1** General help²
- F5** Restore the previous CMOS value
- F7** Load optimized defaults
- F10** Save all the changes and exit



Note:

1. Must be pressed using the 10-key pad.
2. The General help contents are only for the Status Page and Option Page setup menus.

6.3. Navigating the BIOS Menus

The main menu displays all the BIOS setup categories. Use the <Left>/<Right> and <Up>/<Down> arrow keys to select any item or sub-menu. Descriptions of the selected/highlighted category are displayed at the bottom of the screen.

The small triangular arrowhead symbol next to a field indicates that a sub-menu is available (see figure below). Press <Enter> to display the sub-menu. To exit the sub-menu, press <Esc>.

6.4. Getting Help

The BIOS Setup Utility provides a “**General Help**” screen. This screen can be accessed at any time by pressing **F1**. The help screen displays the keys for using and navigating the BIOS Setup Utility. Press **Esc** to exit the help screen.

6.5. Main Menu

The Main Menu contains thirteen setup functions and two exit choices. Use arrow keys to select the items and press **<Enter>** to accept or enter Sub-menu.




Figure 42: Illustration of the Main menu screen

6.5.1. Standard CMOS Features

Use this menu to set basic system configurations.

6.5.2. Advanced BIOS Features

Use this menu to set the advanced features available on your system.

6.5.3. Advanced Chipset Features

Use this menu to set chipset specific features and optimize system performance.

6.5.4. Integrated Peripherals

Use this menu to set onboard peripherals features.

6.5.5. Power Management Setup

Use this menu to set onboard power management functions.

6.5.6. PnP/PCI Configurations

Use this menu to set the PnP and PCI configurations.

6.5.7. PC Health Status

This menu shows the PC health status.

6.5.8. Frequency/Voltage Control

Use this menu to set the system frequency and voltage control.

6.5.9. Load Optimized Defaults

Use this menu option to load BIOS default settings for optimal and high performance system operations.

6.5.10. Set Supervisor Password

Use this menu option to set the BIOS supervisor password.

6.5.11. Set User Password

Use this menu option to set the BIOS user password.

6.5.12. Save & Exit Setup

Save BIOS setting changes and exit setup.

6.5.13. Exit Without Saving


Discard all BIOS setting changes and exit setup

The specifications of your drive must match with the drive table. The hard disk will not work properly if you enter incorrect information in this category. Select **"Auto"** whenever possible. If you select **"Manual"**, make sure the information is from your hard disk vendor or system manufacturer.

Below is a table that details required hard drive information when using the **"Manual"** mode.

Settings	Description
[storage] Channel	The name of this match the name of the menu. Settings: [None, Auto, Manual]
Access Mode	Settings: [CHS, LBA, Large, Auto]
Capacity	Formatted size of the storage device
Cylinder	Number of cylinders
Head	Number of heads
Precomp	Write precompensation
Landing Zone	Cylinder location of the landing zone
Sector	Number of sectors

6.8. Advanced BIOS Features



The Advanced BIOS Features section includes the following submenus:

- Hard Disk Boot Priority

6.8.1. Quick Power On Self-Test

Shortens Power On Self-Test (POST) cycle to enable shorter boot up time.

Settings	Description
Disabled	Standard Power On Self Test (POST)
Enabled	Shorten Power On Self Test (POST) cycle and boot up time

6.8.2. First/Second/Third Boot Device

Set the boot device sequence as BIOS attempts to load the disk operating system.

Settings	Description
Removable	Boot from external drive
Hard Disk	Boot from the HDD
CDROM	Boot from CDROM
Legacy LAN	Boot from network drive
VIA Networking	Boot from network drive
Disabled	Disable the boot device sequence

6.8.3. Boot Other Device

Enables the system to boot from alternate devices if the system fails to boot from the “First/Second/Third Boot Device” lists.

Settings	Description
Disabled	No alternate boot device allowed
Enabled	Enable alternate boot device

6.8.4. Boot Up NumLock Status

Set the NumLock status when the system is powered on.

Settings	Description
Off	Forces keypad to behave as arrow keys
On	Forces keypad to behave as 10-key

6.8.5. Security Option

Selects whether the password is required every time the System boots, or only when you enter Setup.

Settings	Description
Setup	Password prompt appears only when end users try to run BIOS Setup
System	Password prompt appears every time when the computer is powered on and when end users try to run BIOS Setup

6.8.6. Full Screen Logo Show

Show full screen logo during BIOS boot up process.


Settings: [Disabled, Enabled]

6.8.7. Summary Screen Show

Show summary screen.


Settings: [Disabled, Enabled]

6.9. Hard Disk Boot Priority



This is for setting the priority of the hard disk boot order when the “Hard Disk” option is selected in the “[First/Second/Third] Boot Device” menu item.

6.10. Advanced Chipset Features




Caution:

The Advanced Chipset Features menu is used for optimizing the chipset functions. Do not change these settings unless you are familiar with the chipset.

The Advanced Chipset Features section includes the following submenus:

- PCIE Bus Control
- UMA & P2P Bridge Control
- CPU & PCI Bus Control

6.11. PCIE Bus Control




6.11.1. PCIE Root Port

Settings: [Disabled, Enabled]

6.11.2. PCIE Target Link Speed

Settings: [Auto, Force Gen1]

6.12. UMA & P2P Bridge Control



6.12.1. UMA Enable

Settings: [Disabled, Enabled]

6.12.2. VGA Share Memory Size

This setting allows you to select the amount of system memory that is allocated to the integrated graphics processor.

Settings	Description
64M	Minimum amount of memory that can be allocated to the graphics processor.
128M	Maximum amount of memory that can be allocated to the graphics processor if the system memory size is less than 1GB.
256M	Maximum amount of memory that can be allocated to the graphics processor if the system memory size is 1GB but less than 2GB.
512M	Maximum amount of memory that can be allocated to the graphics processor if the system memory size is 2GB or above.

6.12.3. CPU Direct Access FB

Settings: [Disabled, Enabled]

6.12.4. Select Display Device

This setting refers to the type of display being used with the system.

Settings: [Auto, Manual]

6.12.5. Select Display Device 1

This setting refers to the type of display device 1 being used with the system.

Settings: [CRT, TV, HDMI]

6.12.6. Select Display Device 2

This setting refers to the type of display device 2 being used with the system.

Settings: [CRT, TV, HDMI]

6.12.7. TV_Type

This setting refers to the native resolution of the display being used with the system.

Settings: [NTSC, PAL]

6.12.8. TV_Connector: Composite

This setting refers to enable or disable the Composite video interface being used with the system. The default setting is enabled.

Settings: [Enabled, Disabled]

6.12.9. TV_Connector: S-Video

This setting refers to enable or disable the S-Video interface being used with the system. The default setting is enabled.


Settings: [Enabled, Disabled]



Note:

The TV-out function is available as a manufacturing option. The default SKU does not include the TV-out.

6.13. CPU & PCI Bus Control



6.13.1. PCI Master 0 WS Write

Settings: [Enabled, Disabled]


6.13.2. PCI Delay Transaction

Settings: [Disabled, Enabled]

6.13.3. SB P2P Bridge

Settings: [Disabled, Enabled]


6.14. Integrated Peripherals



The Integrated Peripherals section includes the following submenus:

- VIA OnChip IDE Device
- VIA OnChip PCI Device
- SuperIO Device
- USB Device Setting


6.15. VIA OnChip IDE Device



6.15.1. OnChip SATA

Settings: [Disabled, Enabled]

6.16. VIA OnChip PCI Device



6.16.1. Onboard PCIE LAN

Settings: [Enabled, Disabled]

6.16.2. OnBoard LAN Boot ROM

Settings: [Enabled, Disabled]

6.16.3. OnChip HDAC Device

Settings: [Enabled, Disabled]


6.16.4. NB HD Audio Codec 1

Settings: [Enabled, Disabled]

6.16.5. Hide D1F1

Settings: [Enabled, Disabled]

6.17. SuperIO Device



6.17.1. Onboard Serial Port 1

Settings: [Disabled, 3F8/IRQ4, 2F8/IRQ3, 3E8/IRQ4, 2E8/IRQ3, Auto]

6.17.2. Onboard Serial Port 2

Settings: [Disabled, 3F8/IRQ4, 2F8/IRQ3, 3E8/IRQ4, 2E8/IRQ3, Auto]

6.17.3. SIR Function Setting

Settings: [Disabled, IrDA]

6.17.4. Onboard Parallel Port

This specifies the I/O port address and IRQ of the onboard parallel port.

Settings: [Disabled, 378/IRQ7, 278/IRQ5, 3BC/IRQ7]

6.17.5. Parallel Port Mode

Set the parallel port mode. To operate the onboard parallel port as Standard Parallel Port, choose SPP. To operate the onboard parallel port in the EPP mode, choose EPP. By choosing ECP, the onboard parallel port will operate in

ECP mode. Choosing ECP + EPP will allow the onboard parallel port to support both the ECP and EPP modes simultaneously.


Settings: [SPP, EPP, ECP, ECP + EPP]

6.17.6. ECP Mode Use DMA

ECP (Extended Capabilities Port) has two DMA channels that it can use. The default channel is 3. However, some expansion cards may use channel 3 as well. To solve this conflict, change the ECP channel to 1. Select a DMA channel for the port.

Settings: [1, 3]

6.18. USB Device Setting



6.18.1. USB 1.0 Controller

Enable or disable Universal Host Controller Interface for Universal Serial Bus.

Settings: [Disabled, Enabled]

6.18.2. USB 2.0 Controller

Enable or disable Enhanced Host Controller Interface for Universal Serial Bus.

Settings: [Disabled, Enabled]

6.18.3. USB Operation Mode

Auto decide USB device operation mode.

Settings	Description
Full/Low Speed	All of USB Device operated on full/low speed mode
High Speed	If USB device was high speed device, then it operated on high speed mode.

6.18.4. USB Keyboard Function

Enable or disable legacy support of USB keyboard.

Settings: [Disabled, Enabled]

6.18.5. USB Mouse Function


Settings: [Disabled, Enabled]

6.18.6. USB Storage Function

Enable or disable legacy support of USB mass storage.

Settings: [Disabled, Enabled]

6.19. Power Management Setup



The Power Management Setup section includes the following submenus:

- Wakeup Event Detect

6.19.1. EuP/ErP Lot6

Settings: [Disabled, Enabled]

6.19.2. ACPI Suspend Type

Settings	Description
S1(POS)	S1/Power On Suspend (POS) is a low power state. In this state, no system context (CPU or chipset) is lost and hardware maintains all system contexts.
S3(STR)	S3/Suspend To RAM (STR) is a power-down state. In this state, power is supplied only to essential components such as main memory and wakeup-capable devices. The system context is saved to main memory, and context is restored from the memory when a "wakeup" event occurs.
S1 & S3	Depends on the OS to select S1 or S3.

6.19.3. Soft-Off by PWRBTN

Settings	Description
----------	-------------

Delay 4 Sec	System is turned off if power button is pressed for more than four seconds.
Instant-Off	Power button functions as a normal power-on/-off button.

6.19.4. Run VGABIOS if S3 Resume

Select whether to run VGA BIOS if resuming from S3 state. This is only necessary for older VGA drivers.

Settings: [Auto, Yes, No]

6.19.5. AC Loss Auto Restart

The field defines how the system will respond after an AC power loss during system operation.

Settings	Description
Off	Keeps the system in an off state until the power button is pressed
On	Restarts the system when the power is back
Former-Sts	Former-Sts

6.19.6. HPET Support

Settings: [Disabled, Enabled]

6.19.7. WDRT Support

Settings: [Disabled, Enabled]

6.19.8. WDRT Run/Stop

Settings: [Stop, Run]

6.19.9. WDRT Count

Key in a DEC number.

Settings: [Min = 0, Max = 1023]

6.20. Wakeup Event Detect

Phoenix - AwardBIOS CMOS Setup Utility		Item Help
Wakeup Event Detect		
PS2KB Wakeup Select	[Hot Key]	
PS2KB Wakeup Key Select	[Any Key]	
PS2MS Wakeup Key Select	[Any Button]	
PS2 Keyboard Power ON	[Disabled]	
PS2 Mouse Power On	[Disabled]	
RTC Alarm Resume	[Disabled]	
x Date (of Month)	0	Menu Level >
x Resume Time (hh:mm:ss)	0 : 0 : 0	

↑↓→←: Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help
 F5: Previous Values F7: Optimized Defaults

6.20.1. PS2KB Wakeup Select

This feature has two settings: Hot Key and Password. To select the Password option, press <Page Up> or <Page Down>. To set the password, enter up to eight digits and press <Enter>.

Settings: [Hot Key]

6.20.2. PS2KB Wakeup Key Select

This feature is only available when "Hot Key" is chosen in "PS2KB Wakeup Select".

Settings: [Ctrl+F1, Ctrl+F2, Ctrl+F3, Ctrl+F4, Ctrl+F5, Ctrl+F6, Ctrl+F7, Ctrl+F8, Ctrl+F9, Ctrl+F10, Ctrl+F11, Ctrl+F12, Power, Wake, Any Key]

6.20.3. PS2MS Wakeup Key Select

Settings: [Any Button, Left Button, Right Button]

6.20.4. PS2 Keyboard Power ON

Settings: [Disabled, Enabled]

6.20.5. PS2 Mouse Power ON

Settings: [Disabled, Enabled]

6.20.6. RTC Alarm Resume

Set a scheduled time and/or date to automatically power on the system.

Settings: [Disabled, Enabled]

6.20.7. Date (of Month)

This field can only be set if "RTC Alarm Resume" is enabled. The field specifies the date for "RTC Alarm Resume".

6.20.8. Resume Time (hh:mm:ss)

This field can only be set if "RTC Alarm Resume" is enabled. The field specifies the time for "RTC Alarm Resume".

6.21. PnP/PCI Configurations

Phoenix - AwardBIOS CMOS Setup Utility		Item Help
PnP/PCI Configurations		
Init Display First	[Onboard]	Menu Level >
Reset Configuration Data	[Disabled]	
Resources Controlled By x IR@ Resources	[Auto(ESCD)] Press Enter	
↑↓→←: Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help F5: Previous Values F7: Optimized Defaults		



Note:

This section covers some very technical items and it is strongly recommended to leave the default settings as is unless you are an experienced user.

6.21.1. Init Display First

Settings: [Onboard, PCI slot]

6.21.2. Reset Configuration Data


Settings	Description
Disabled	Default setting
Enabled	Resets the ESCD (Extended System Configuration Data) after exiting BIOS Setup if a newly installed PCI card or the system configuration prevents the operating system from loading

6.21.3. Resources Controlled By

Enables the BIOS to automatically configure all the Plug-and-Play compatible devices.

Settings	Description
Auto(ESCD)	BIOS will automatically assign IRQ, DMA and memory base address fields
Manual	Unlocks "IRQ Resources" for manual configuration

6.23 Frequency/Voltage Control



6.23.1 DRAM Clock

This chipset supports synchronous and asynchronous mode between host clock and DRAM clock frequency.

Settings: [By SPD, 400 MHz, 533 MHz]

6.23.2 DRAM Timing

Setting: [Auto By SPD]

6.23.3 DRAM Init Method

Settings: [Auto: Hardware Init, Force software]

6.23.4 DRAM REMAP

Settings: [Disabled, Enabled]


6.23.5 Spread Spectrum

When the mainboard's clock generator pulses, the extreme values (spikes) of the pulses create EMI (Electromagnetic Interference). The Spread Spectrum

function reduces the EMI generated by modulating the pulses so that the spikes of the pulses are reduced to flatter curves.

Settings: [Disabled, +/- 0.1%, +/- 0.2%, +/- 0.3%, +/- 0.4%, +/- 0.5%, +/- 0.6%, +/- 0.7%, +/- 0.8%, +/- 0.9%]

6.24 Load Optimized Defaults




This option is for restoring all the default optimized BIOS settings. The default optimized values are set by the mainboard manufacturer to provide a stable system with optimized performance.

Entering “**Y**” and press <Enter> to load the default optimized BIOS values.

Entering “**N**” will cancel the load optimized defaults request.

6.25 Set Supervisor/User Password



This option is for setting a password for entering BIOS Setup. When a password has been set, a password prompt will be displayed whenever BIOS Setup is run. This prevents an unauthorized person from changing any part of your system configuration.


There are two types of passwords you can set. A supervisor password and a user password. When a supervisor password is used, the BIOS Setup program can be accessed and the BIOS settings can be changed. When a user password is used, the BIOS Setup program can be accessed but the BIOS settings cannot be changed.

To set the password, type the password (up to eight characters in length) and press **<Enter>**. The password typed now will clear any previously set password from CMOS memory. The new password will need to be reentered to be confirmed. To cancel the process press **<Esc>**.

To disable the password, press **<Enter>** when prompted to enter a new password. A message will show up to confirm disabling the password. To cancel the process press **<Esc>**.

Additionally, when a password is enabled, the BIOS can be set to request the password each time the system is booted. This would prevent unauthorized use of the system. See "Security Option" in the "Advanced BIOS Features" section for more details.


6.26 Save & Exit Setup



Entering “**Y**” saves any changes made, and exits the program.

Entering “**N**” will cancel the exit request.

6.27 Exit Without Saving



Entering “**Y**” discards any changes made and exits the program.

Entering “**N**” will cancel the exit request

7 Driver Installation

7.1 Microsoft Driver Support

The VIA VB7008 mainboard is compatible with Microsoft operating systems. The latest Windows drivers can be downloaded from the VEPD website at www.viaembedded.com.

For embedded operating systems, the related drivers can be found in the VIA Embedded website at www.viaembedded.com.

7.2 Linux Driver Support

The VIA VB7008 mainboard is highly compatible with many Linux distributions.

Support and drivers are provided through various methods including:

- Drivers provided by VIA
- Using a driver built into a distribution package
- Visiting www.viaembedded.com for the latest updated drivers
- Installing a third party driver (such as the ALSA driver from the Advanced Linux Sound Architecture project for integrated audio)

For OEM clients and system integrators developing a product for long term production, other code and resources may also be made available. Contact VEPD to submit a request.

Appendix A.

Power Consumption Report

Power consumption tests were performed on the VIA VB7008. The following tables represent the breakdown of the voltage, amp and wattage values while running common system applications.

A.1. VB7008-16

The tests were performed based on the following additional components:

- **CPU:** VIA C7[®]-D 1.6 GHz
- **Chipset:** VX900
- **Memory:** Corsair 4GB DDR3 1600MHz DIMM
- **HDD:** Seagate 500GB ST3500514NS
- **DVD-ROM:** DVR-115BK
- **Power supply:** ATX power supply
- **Operating System:** Windows 7

A.1.1. Playing DVD-Windows Media Player 12 (+HDMI)

Power Plane	Volts	Amperes	Watts
+3.3V	2.771	1.049	2.907
+5V	4.690	3.141	14.731
+5VSB	4.739	0.261	1.237
+12V	11.922	0.056	0.668
		Total Power Consumption	19.543

A.1.2. Playing MP3-Media Player

Power Plane	Volts	Amperes	Watts
+3.3V	2.761	0.908	2.507
+5V	4.737	1.888	8.943
+5VSB	4.790	0.259	1.241
+12V	12.039	0.068	0.819
		Total Power Consumption	13.510

A.1.3. Running Network Application – Files Copy

Power Plane	Volts	Amperes	Watts
+3.3V	2.627	0.886	2.328
+5V	4.605	2.059	9.482
+5VSB	4.635	0.395	1.831
+12V	11.913	0.062	0.739
		Total Power Consumption	14.380

A.1.4. Idle

Power Plane	Volts	Amperes	Watts
+3.3V	2.875	0.896	2.576
+5V	4.784	1.380	6.602
+5VSB	4.828	0.258	1.246
+12V	12.065	0.072	0.869
		Total Power Consumption	11.293

A.1.5. Run Burn-in Test V6.0

Power Plane	Volts	Amperes	Watts
+3.3V	2.897	0.881	2.552
+5V	4.728	2.036	9.626
+5VSB	4.785	0.256	1.225
+12V	12.032	0.068	0.818
		Total Power Consumption	14.221

A.1.6. S3

Power Plane	Volts	Amperes	Watts
+3.3V	0.000	0.000	0.000
+5V	0.000	0.000	0.000
+5VSB	5.035	0.242	1.218
+12V	0.000	0.000	0.000
		Total Power Consumption	1.218

Appendix B. Mating Connector Vendor Lists

The following tables listed the mating connector vendor lists of VB7008 mainboard.

Connectors	Part No.	Mating Vendor & P/N	
F_Audio	99G30-05126I	Neltron	SAMTEC SSW Series
		2214S-XXG-85	
		2214R-XXG-85	
F_PANEL	99G30-05005I	Neltron	SAMTEC SSW Series
		2212S-XXG-85	
		2212R-XXG-85	
FAN	99G30-020035	Neltron	N/A
		2218H-03	N/A
USB	99G30-05072K	Neltron	SAMTEC SSW Series
		2214S-XXG-85	
		2214R-XXG-85	

Table 29: VB7008 mating connector vendor lists

 **Taiwan Headquarters**


1F, 531 Zhong-Zheng Road
Xindian District, New Taipei City 231,
Taiwan

TEL: 886.2.2218.5452
FAX: 886.2.2218.5453
Email: embedded@via.com.tw

 **USA**


940 Mission Court
Fremont, CA 94539
USA

TEL: 1.510.683.3300
FAX: 1.510.687.4654
Email: embedded@viatech.com

 **Europe**

In den Dauen 6
53117 Bonn
Germany

TEL: 49.228.688565.0
FAX: 49.228.688565.19
Email: embedded@via-tech.de

 **China**

Tsinghua Science Park Bldg. 7
No. 1 Zongguancun East Road
Haiden District, Beijing, 100084
China

TEL: 86.10.59852288
FAX: 86.10.59852299
Email: embedded@viatech.com.cn

 **Japan**

3-15-7 Ebisu MT Bldg. 6F
Higashi, Shibuya-ku
Tokyo 150-0011
Japan

TEL: 81.3.5466.1637
FAX: 81.3.5466.1638
Email: embedded@viatech.co.jp

 **Korea**

2F, Sangjin Bldg., 417
Dogok Dong, Gangnam-Gu
Seoul 135-854
South Korea

TEL: 82.2.571.2986
FAX: 82.2.571.2987
Email: embedded@via-korea.com